

The visual signal will always be indicated by a flashing **RPM** warning light. The audio signals heard through the pilot headset earphones vary depending on the fault condition as follows:

FAULT CONDITION	AUDIO SIGNAL
N_{R0} Low - 75 to 95 %	Beeping tone
N_{R0} High - 103 %	None
N_{R0} High - 108 %	Steady, high-pitched tone
N_1 Differential $\geq$ 12 %	Beeping tone

NOTE The N_{R0} High - 108 % RPM warning applies only for those helicopters equipped with a two-stage warning unit.

7.13 FLIGHT INSTRUMENTS

The instruments discussed under this subject are, for the most part, those that directly measure flight performance.

7.13.1 Pitot-static System

An electrically heated pitot tube is installed at the fuselage lower RH nose area. Two associated static ports are installed flush with the fuselage; one on the right and one on the left. The pitot tube supplies ram air to the airspeed indicator. The pitot heater is powered from the Main Bus via a fuse. The PITOT HEATING switch on the center console switch panel controls the heating element as indicated by the PITOT HEATING indicator on the instrument panel. The static ports provide static air pressure to the barometric altimeter, vertical speed indicator and airspeed indicator.

7.13.2 Barometric Altimeter

The barometric altimeter reacts to changes in barometric pressure delivered via the static ports. The altimeter scale is graduated in fifty-foot increments and numbered at hundred-foot intervals. The long needle indicates 100 feet intervals, the short needle indicates 1000 feet intervals and the rotating scale to the right of center indicates 10,000 feet intervals. The scale window at the lower center of the instrument face indicates barometric pressure setting in hectopascals (millibars) adjustable by use of the knob on the lower left corner of the instrument case.

7.13.3 Vertical Speed Indicator

The vertical speed indicator presents the rate of climb or descent from 0 to 6000 feet per minute. The instrument scale is graduated in 100 feet per minute increments from 0 up to 1000 feet per minute, and in 500 feet per minute increments from 1000 to 6000 feet per minute.

7.13.4 Airspeed Indicator

The airspeed indicator presents airspeed from 0 to 150 knots. The indicator dial is scaled in five-knot increments above 10 knots.

7.13.5 **Clock**

The mechanical clock on the instrument panel is wound and set with a knob at the lower center of the clock face. Below the knob is a lever used for starting, stopping and resetting (zeroing) an elapsed-time counter. A small lever to the right of the knob is used for stopping the sweep second-hand.

7.13.6 **Standby Magnetic Compass**

The standby magnetic compass is attached to the windshield center frame above the instrument panel. A compass correction card is affixed to the windshield frame above the compass.

7.13.7 **Outside Air Temperature (OAT) Indicator**

The OAT indicator is a self-contained unit mounted to the RH cabin roof window. A probe extends through the window to sense outside free air temperature. The dial has two scales to indicate temperature in degrees Celsius and degrees Fahrenheit.