

8.2.3 Mooring

When parking the helicopter in the open during periods of forecast high winds of 50 kt or higher, the helicopter should be headed in the direction from which the forecast winds are expected and then moored (anchored) as follows:

- Secure helicopter to ramp tie-downs or mooring anchors using ropes or cables wrapped around the landing gear cross tubes at both the fuselage and skid tube junctures.
- Secure rotor blades and install protective covers.
- Fill fuel tanks to max capacity and place sand bags on the skid tubes to add weight to the helicopter.

8.3 SERVICING

8.3.1 Refueling

Park helicopter on level, even surface and perform engine shutdown. Keep fire extinguisher ready at hand.

WARNING • ALWAYS ESTABLISH ELECTRICAL GROUND CONNECTION BETWEEN HELICOPTER, FUELING VEHICLE AND EXTERNAL POWER UNIT (AS REQUIRED) BEFORE STARTING REFUELING OPERATION AND DISCONNECT ONLY WHEN OPERATION IS COMPLETED.

- DO NOT CONNECT, DISCONNECT OR REMOVE BATTERY DURING OR IMMEDIATELY FOLLOWING REFUELING.

1. Establish electrical ground connection.
2. Apply power (battery or EPU) to the helicopter electrical system and check supply tank (S) fuel quantity.
3. Unlock and remove fuel filler cap.
4. Electrically ground fuel nozzle to helicopter and then insert nozzle in filler neck.
5. Service fuel tanks to required level.

NOTE If supply tank is not full (less than 75 kg), switch on the main tank fuel pumps during refueling until supply tank is full.

6. Switch off electrical power.
7. Remove fuel nozzle and disconnect its ground cable.
8. Install fuel filler cap and check locked.
9. Remove electrical ground connection.

8.3.2 Defueling

For defueling purposes, the helicopter fuel pumps are used. An external power unit should be used whenever possible to conserve battery power. Position external power unit at a safe distance (approx 10m) and connect to helicopter. If a container is used to collect the fuel during the defueling operation, that container must be electrically grounded. Keep a fire extinguisher ready at hand.

WARNING • ALWAYS ESTABLISH ELECTRICAL GROUND CONNECTION BETWEEN HELICOPTER, DEFUELING VEHICLE, CONTAINERS AND EXTERNAL POWER UNIT (AS REQUIRED) BEFORE STARTING DEFUELING OPERATION AND DISCONNECT ONLY WHEN OPERATION IS COMPLETED.

- DO NOT CONNECT, DISCONNECT OR REMOVE BATTERY DURING OR IMMEDIATELY FOLLOWING DEFUELING.

1. Establish electrical ground connection.
2. Release latches and open LH/RH engine compartment access panels.
3. Disconnect fuel supply line at the engine deck coupling of one or both engines.
4. Connect defueling line(s) of suitable length to the coupling(s) and route free-end of line to defueling vehicle or container.
5. Power helicopter electrical system (battery or EPU) and switch on respective fuel pumps.

NOTE If EPU is not available, operate only one fuel pump at a time alternating between supply and main tank pumps.

6. Monitor fuel quantity indicator. When both tanks are emptied switch off fuel pumps and de-energize helicopter electrical system.
7. Disconnect and remove defueling line(s) and connect fuel supply line(s).
8. Close LH/RH engine compartment access panels.
9. Position containers and open fuel tank drain valves.
10. Disconnect electrical ground connection.
11. Remove containers and dispose of fuel accordingly.

8.3.3 Engine Oil System

Both engine oil tanks are located in the RH transmission compartment beneath the oil cooler assembly. The left engine oil tank is located forward of the right engine oil tank. Each tank is serviced through a gravity filler neck having a screen-type filter. An oil level sight gage is located on the outer face of each tank. When the oil level falls to the ADD OIL mark, replenish with correct oil (see Section 2) until the level reaches the MAX mark on the sight gage or until an internal float blocks off the filler neck opening.

8.3.4 Main Transmission

Access to the main transmission oil filler neck is best achieved from the engine air inlet at the cabin top. The oil level sight gage is visible from the RH transmission compartment. When the oil level falls to the MIN mark, replenish with correct oil (see Section 2) until the level reaches the MAX mark on the sight gage.

8.3.5 Rotor Hub Reservoir

The oil level of the transparent rotor hub reservoir must be between the MIN and MAX markings when viewed from the nose of the helicopter. Replenishing instructions are in the BO 105 Maintenance Manual.

8.3.6 Intermediate Gearbox

The oil level sight gage for the intermediate gearbox is viewed on the left side at the base of the vertical fin fairing. The oil level is full when the bottom half of the sight gage is filled. The oil filler cap is accessible after opening a flap above and to the right of the sight gage. Replenish with correct oil (see Section 2).

NOTE When the sight gage glass is stained, the oil level may be best verified by grasping the tail skid and shortly shaking the tail boom while carefully observing the sight gage.

8.3.7 Tail Rotor Gearbox

The oil level sight gage for the tail rotor gearbox is located on the aft end of the gearbox housing. The oil level is full when the bottom half of the sight gage is filled. The oil filler cap is located above the sight gage. Replenish with correct oil (see Section 2).

NOTE When the sight gage glass is stained, the oil level may be best verified by grasping the tail skid and shortly shaking the tail boom while carefully observing the sight gage.

8.3.8 Hydraulic Systems

The hydraulic systems should only be serviced with approved fluids (see Section 2). Since the systems are of the closed-circuit type, only trained personnel are authorized to replenish the fluids following servicing instructions in the BO 105 Maintenance Manual.