

8.4.4 Oils

CAUTION DO NOT MIX MIL-L-23699 AND MIL-L-7808 OILS.

When temperatures are below -40°C (-40°F) OAT or MIL-L-23699 oils are not available, use MIL-L-7808G and subsequent oils.

8.4.5 Preheating

WARNING DO NOT USE AN OPEN FLAME HEATER TO PREHEAT THE ENGINES OR BATTERY.

At temperatures below -18°C OAT, preheat the engines concentrating heat application on the fuel controls.

CAUTION WHEN ENGINE AND MAIN TRANSMISSION OIL TEMPERATURES ARE BELOW -25°C PREHEAT THE OILS TO A TEMPERATURE OF -25°C OR HIGHER.

At temperatures below -30°C OAT, preheat the cockpit to a temperature of -10°C or higher for a duration of at least 15 minutes.

8.5 MAINTENANCE

The component retirement life limitations in the Airworthiness Limitations Section of the BO 105 Maintenance Manual shall be complied with.

Refer to the BO 105 Maintenance Manual for information on the helicopter inspection periods and special inspections for helicopter systems.

