

2. LIMITATIONS

2.1 ROTOR BRAKE SYSTEM LIMITATIONS

Apply rotor brake only when rotor RPM is below 50% and with both engines shutdown.

Minimum operating OAT –30 °C

Approved oil MIL-L-23699

2.2 PLACARDS AND DECALS

Text:

ROTORBREMSE/ROTORBRAKE
ACHTUNG! BETÄTIGEN NICHT ÜBER 50% ROTORDREHZAHL UND UNTER –30°C OAT
ATTENTION! DO NOT PULL OVER 50% ROTOR RPM AND BELOW –30°C OAT

Location: Rotor brake lever

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

- | | |
|---------------------------|---------------------------------|
| Rotor brake lever | – Full down |
| Rotor brake oil reservoir | – Oil level, filler cap secured |
| Rotor brake assembly | – Condition |

4.2 ENGINE SHUTDOWN

- CAUTION**
- DO NOT ACTIVATE ROTOR BRAKE WHEN OAT IS BELOW –30°C.
 - SLOWLY ACTIVATE ROTOR BRAKE WHEN PARKED ON ICE OR SNOW COVERED SURFACES.

After placing both power levers to OFF and N_{R0} is below 50%:

- | | |
|-------------|------------|
| Rotor brake | – Activate |
|-------------|------------|

After rotor comes to a complete stop:

- | | |
|-------------|-----------|
| Rotor brake | – Release |
|-------------|-----------|