

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

- | | |
|----------------------------------|----------------------|
| Seat | – Condition, secured |
| Safety belts | – Condition |
| If seat is unoccupied in flight: | |
| Safety belts | – Stowed |

5. PERFORMANCE DATA

No change in the basic Flight Manual data.

6. MASS AND BALANCE

6.1 LOADING DATA

When calculating CG of passengers seated on the bench, use an arm of 2690 mm.

6.2 EQUIPMENT LIST ENTRIES

System/Equipment Designation	Part No.	Mass (kg)	Arm (mm)	Massmoment (kgmm)
Passenger Bench Seat	105-71122	17.0	2800	47600
Passenger Bench Seat	105-71123	17.0	2800	47600
Passenger Bench Seat	D136-41	17.0	2800	47600