

 PT. MNA SERANG	WORKING INSTRUCTION	W/MNASRG-E&I-19-111	
	Manual Instrument Reactive Maintenance	Dept. ENGINEERING Section E&I Revision 0 Effective Date Page 1	

Instruksi / <i>Instruction</i>	
Persiapan Alignment / <i>Prepare of Alignment Process</i>	
	
Siapkan peralatan dan APD (<i>Prepare equipment and APD</i>)	Identification: Pembacaan temperatur keluar dari limit <i>Sesnsor Temperature Out Of Limit</i>
Pengecekan Elemen Sensor/ <i>Sensor Element Checking</i>	
	
1. Periksa tekanan yang diterapkan untuk memastikan itu di dalam batas sensor. <i>Check the pressure applied to ensure it is within the sensor limits.</i>	2. Periksa sambungan tekanan perangkat <i>Check the device pressure connection</i>
	
3. Periksa proses dan suhu sekitar rentang operasi perangkat. <i>Verify process and ambient temperature is within the device's operating range.</i>	4. Pasang perangkat jauh dari proses dan keadaan lingkungan. <i>Remote mount the device away from process and environmental conditions.</i>
	
5. Akui kondisi tekanan berlebih untuk dihapus indikasi terkunci, dan verifikasi integritas sensor. <i>Acknowledge the over pressure condition to clear the latched indication, and verify the integrity of the sensor.</i>	6. Jika kondisi ini terus berlanjut, ganti perangkat. <i>If the condition persists, replace the device.</i>