

 PT. MNA SERANG	WORKING INSTRUCTION PRESSURE GAUGE CALIBRATION	WI/MNASRG-E&I-19-113	
		Dept.	ENGINEERING
		Section	E&I
		Revision	0
		Effective Date	
		Page	2 of 2

Instruksi / Instruction <i>Zero point of the pressure gauge needle.</i>



Craftsman 2 pc 16" Rubber Strap Wrench



7. Buka penutup kaca pada pressure gauge dengan menggunakan Cearftsman 2pcs 16" Rubber Starp Wrench set. (*Open the glass cover on the pressure gauge using 2pcs Cearftsman 2pcs 16" Rubber Starp Wrench set.*)

8. Lepaskan jarum dari pressure gauge menggunakan penjepit dan pasang pada posisi nol pada pressure gauge. (*Remove the needle from the pressure gauge using a clamp and attach it to position 0 on the pressure gauge*)



3. Pasang kembali kaca penutup dan lakukan kalibrasi.
Replace the cover glass and calibrate it.