

DELTA V DCS PSU CHECKING

First step: Periksa indikasi error pada DC-DC Power supply (*Check the error indication on DC-DC power supply*)



Second step: Koordinasi dengan tim operasional (*Coordination with operational team*)



Third step: Check nominal Arus & tegangan (*Check the Voltage & Current Nominal*)

System Power Supply	12 VDC Local I/O Bus Power
AC/DC	2.1 Amps @ 60 °C (Load Sharing)
Dual DC/DC – 12 VDC	13 Amps @ 60 °C (Load Sharing)
Dual DC/DC – 24 VDC	8 Amps @ 60 °C (Load Sharing)

Fourth step: Periksa indikasi error pada AC-DC Power supply (*Check the error indication on AC-DC power supply*)



Fifth step : Check nominal Arus & tegangan (*Check the Voltage & Current Nominal*)

System Power Supply	12 VDC Local I/O Bus Power
AC/DC	2.1 Amps @ 60 °C (Load Sharing)
Dual DC/DC – 12 VDC	13 Amps @ 60 °C (Load Sharing)
Dual DC/DC – 24 VDC	8 Amps @ 60 °C (Load Sharing)

Sixth step: Catat Nominal Tegangan & lakukan penggantian jika tegangan jatuh > 10% (*Note the Voltage Nominal & do replacement if Drop Voltage > 10%*)

