

IO List - Coal Boiler

Wilmar Industrial Complex PT MNA Serang, Indonesia

End Customer: Wilmar Industrial Complex PT MNA
Serang, Indonesia

End Customer Reference Number:

Document File Name: 3258585-PSS-PASH-DWG-00045
Document Status: For Final

Authorisations

	Name	Function	Signature
Developed By:	Zul Hasyidi Hassan	Project Engineer	ZHH
Reviewed By:	Liow Kok Loong	Lead Engineer	LKL
Released By:	Mohd. Nazim Ismail	Project Manager	MNI

Distribution

Name	Company	Name	Company

Revision History

Rev	Status	Description	Date	Developed By	Reviewed By
A	For Review	Issued for Review	24-Oct-18	DRY	LKL
B	For Review	Issued for Review	9-Nov-18	DRY	LKL
0	For Final	Issued for Final	15-Oct-19	ZHH	LKL

© Emerson Automation Solution. All rights reserved. Unauthorized duplication, in whole or in part, is prohibited. Trademarks identified in this document are owned by one of the Emerson Process Management group of companies. Unless otherwise agreed to in writing by the parties, any information provided in this document is confidential or proprietary and may not be used or disclosed without the expressed written permission of Emerson Process Management.

Emerson Automation Solution
Process System and Solutions
No. 1, Block A, Jalan SS13/5, SS13
Subang Jaya, 47500, Selangor
Malaysia
T +60 (3) 5624-2888
F +60 (3) 5638-1010
www.EmersonProcess.com

										RIO CABINET										SYSTEM CABINET									
Vendor's tags		Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	RangeProposed	Signal Type	Electrical Connection Type	Cabinet Name	TB Name	Marshalling	Term. (+)	Term. (-)	24V(+) Term	24V(-) Term	Term. (+)	Term. (-)	Relay	Term. (+)	Term. (-)	DELTA V		DELTA V		Cabinet Name	Controller	
																						Slot	Channel	Term. (+)	Term. (-)				
AIT1028	PH1028	BL1-PH1028	BL1_PH1028	BL1_PH1028	1# Boiler water PH	PH analytical instrument	AI	5-16	4-20 mA HART	4 wire (with 230VAC supply)	UTI-DCS-001.1 (R)	TB-AI	1	2		L	N					S1	1	1	2	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
AIT1027A	COT1027A	BL1-COT1027A	BL1_COT1027A	BL1_COT1027A	1# Boiler water Conductivity	Conductivity analytical instrument	AI	1-1000µS/cm	4-20 mA HART	4 wire (with 230VAC supply)	UTI-DCS-001.1 (R)	TB-AI	3	4		L	N					S1	2	3	4	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
AIT1027B	COT1027B	BL1-COT1027B	BL1_COT1027B	BL1_COT1027B	1# Boiler steam Conductivity	Conductivity analytical instrument	AI	1-1000µS/cm	4-20 mA HART	4 wire (with 230VAC supply)	UTI-DCS-001.1 (R)	TB-AI	5	6		L	N					S1	3	5	6	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
AIR1040A	QTI1040A	BL1-QTI1040A	BL1_QTI1040A	BL1_QTI1040A	Carbon dioxide detection	Analysis instrument	AI	0-45%	4-20 mA HART	4 wire (with 230VAC supply)	UTI-DCS-001.1 (R)	TB-AI	7	8		L	N					S1	4	7	8	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
AIR1040B	QTI1040B	BL1-QTI1040B	BL1_QTI1040B	BL1_QTI1040B	Oxygen content detection	Analysis instrument	AI	0-21%	4-20 mA HART	4 wire (with 230VAC supply)	UTI-DCS-001.1 (R)	TB-AI	9	10		L	N					S1	5	9	10	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
AIR1040C	QTI1040C	BL1-QTI1040C	BL1_QTI1040C	BL1_QTI1040C	Sulfur oxides detection	Analysis instrument	AI	0-3000mg/m³	4-20 mA HART	4 wire (with 230VAC supply)	UTI-DCS-001.1 (R)	TB-AI	11	12		L	N					S1	6	11	12	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
AIR1040D	QTI1040D	BL1-QTI1040D	BL1_QTI1040D	BL1_QTI1040D	Nitrogen oxides detection	Analysis instrument	AI	0-3000mg/m³	4-20 mA HART	4 wire (with 230VAC supply)	UTI-DCS-001.1 (R)	TB-AI	13	14		L	N					S1	7	13	14	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
AIR1040E	QTI1040E	BL1-QTI1040E	BL1_QTI1040E	BL1_QTI1040E	Carbon monoxide detection	Analysis instrument	AI	0-3000mg/m³	4-20 mA HART	4 wire (with 230VAC supply)	UTI-DCS-001.1 (R)	TB-AI	15	16		L	N					S1	8	15	16	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
AIT038	QTI038	BL1-QTI038	BL1_QTI038	BL1_QTI038	1# Boiler outlet oxygen content	Oxygen Analyzer	AI	0-21%	4-20 mA HART	4 wire (with 230 VAC supply)	UTI-DCS-001.1 (R)	TB-AI	17	18		L	N					S1	9	17	18	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
MV1003-SY	V2003	BL2-V2003	BL1_V1003	BL1_V1003	Electric bypass feedwater valve	Electric Valve	AI	0-100%	4-20 mA	2 wire AI + 2 wire380VAC Power	UTI-DCS-001.1 (R)	TB-AI	19	20		L	N					S1	10	19	20	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
FT1051	WE1051	BL1-WE1051	BL1_WE1051	BL1_WE1051	1# Boiler coal feeder coal flow rate	Load Cell	AI	0-15T/H		4 wire (with 230 VAC supply)	UTI-DCS-001.1 (R)	TB-AI	21	22		L	N					S1	11	21	22	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
FT1052	WE1052	BL1-WE1052	BL1_WE1052	BL1_WE1052	2# Boiler coal feeder coal flow rate	Load Cell	AI	0-15T/H		4 wire (with 230 VAC supply)	UTI-DCS-001.1 (R)	TB-AI	23	24		L	N					S1	12	23	24	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010A	TT1010A	BL1-TT1010A	BL1_TT1010A	BL1_TT1010A	#1 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	1	2	+	-	-					S1	13	25	26	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010B	TT1010B	BL1-TT1010B	BL1_TT1010B	BL1_TT1010B	#2 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	3	4	+	-	-					S1	14	27	28	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010C	TT1010C	BL1-TT1010C	BL1_TT1010C	BL1_TT1010C	#3 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	5	6	+	-	-					S1	15	29	30	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010D	TT1010D	BL1-TT1010D	BL1_TT1010D	BL1_TT1010D	#4 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	7	8	+	-	-					S1	16	31	32	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010E	TT1010E	BL1-TT1010E	BL1_TT1010E	BL1_TT1010E	#5 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	9	10	+	-	-					S2	1	1	2	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010F	TT1010F	BL1-TT1010F	BL1_TT1010F	BL1_TT1010F	#6 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	11	12	+	-	-					S2	2	3	4	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010G	TT1010G	BL1-TT1010G	BL1_TT1010G	BL1_TT1010G	#7 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	13	14	+	-	-					S2	3	5	6	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010H	TT1010H	BL1-TT1010H	BL1_TT1010H	BL1_TT1010H	#8 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	15	16	+	-	-					S2	4	7	8	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010I	TT1010I	BL1-TT1010I	BL1_TT1010I	BL1_TT1010I	#9 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	17	18	+	-	-					S2	5	9	10	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
TT1010J	TT1010J	BL1-TT1010J	BL1_TT1010J	BL1_TT1010J	#10 Ignition control cabinet temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	4 wire	UTI-DCS-001.1 (R)	TB-AI	19	20	+	-	-					S2	6	11	12	UTI-DCS-001.1 (F)	UTI-CTRL 1.1		
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001.1 (R)	TB-AI									S2	7	13	14	UTI-DCS-001.1 (F)	UTI-CTRL 1.1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001.1 (R)	TB-AI									S2	8	15	16	UTI-DCS-001.1 (F)	UTI-CTRL 1.1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001.1 (R)	TB-AI									S2	9	17	18	UTI-DCS-001.1 (F)	UTI-CTRL 1.1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001.1 (R)	TB-AI									S2	10	19	20	UTI-DCS-001.1 (F)	UTI-CTRL 1.1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001.1 (R)	TB-AI									S2	11	21	22	UTI-DCS-001.1 (F)	UTI-CTRL 1.1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001.1 (R)	TB-AI									S2	12	23	24	UTI-DCS-001.1 (F)	UTI-CTRL 1.1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001.1 (R)	TB-AI									S2	13	25	26	UTI-DCS-001.1 (F)	UTI-CTRL 1.1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001.1 (R)	TB-AI									S2	14	27	28	UTI-DCS-001.1 (F)	UTI-CTRL 1.1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001.1 (R)	TB-AI									S2	15	29	30	UTI-DCS-001.1 (F)	UTI-CTRL 1.1			
SPARE	SPARE	SPARE																											

										RIO CABINET										SYSTEM CABINET									
										Relay				DELTA V				DELTA V				DELTA V							
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range/Proposed	Signal Type	Electrical Connection Type	Cabinet Name	TB Name	Marshalling	Term. (+)	Term. (-)	24V(+) Term	24V(-) Term	Term. (+)	Term. (-)	Relay	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller		
VT1003	VT1003	BL1-VT1003	BL1_VT1003	1# Boiler induced draft fan vibration signal	Vibration transmitter	AI	0-20mm/s	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	195	196								S8	8	15	16	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
RI1061	AM1061	BL1-AM1061	BL1_AM1061	1# Boiler NO.1 Electric field secondary current	ESP Control cabinet	AI	0-300mA	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	197	198								S8	9	17	18	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
VI1061	VM1061	BL1-VM1061	BL1_VM1061	1# Boiler NO.1 Electric field secondary voltage	ESP Control cabinet	AI	0-72kV	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	199	200								S8	10	19	20	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
RI1062	AM1062	BL1-AM1062	BL1_AM1062	1# Boiler NO.2 Electric field secondary current	ESP Control cabinet	AI	0-300mA	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	201	202								S8	11	21	22	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
VI1062	VM1062	BL1-VM1062	BL1_VM1062	1# Boiler NO.2 Electric field secondary voltage	ESP Control cabinet	AI	0-72kV	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	203	204								S8	12	23	24	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
RI1063	AM1063	BL1-AM1063	BL1_AM1063	1# Boiler NO.3 Electric field secondary current	ESP Control cabinet	AI	0-300mA	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	205	206								S8	13	25	26	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
VI1063	VM1063	BL1-VM1063	BL1_VM1063	1# Boiler NO.3 Electric field secondary voltage	ESP Control cabinet	AI	0-72kV	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	207	208								S8	14	27	28	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
BT1001	BT1001	BL1-FLD1001	BL1_FLD1001	Burner Signal	1# Boiler 1# burner flame intensity signal	AI		4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	209	210								S8	15	29	30	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
BT1002	BT1002	BL1-FLD1002	BL1_FLD1002	Burner Signal	1# Boiler 2# burner flame intensity signal	AI		4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	211	212								S8	16	31	32	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001_1 (R)	TB-AI	213	214								S9	1	1	2	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001_1 (R)	TB-AI	215	216								S9	2	3	4	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SC241A	CP0041A-CU	BL1-CP0041A-CU	BL1_CP0041A	1# Air compressor	Motor Current Feedback	AI		4-20 mA	2 wire	UTI-DCS-001_1 (R)	TB-AI	217	218								S9	3	5	6	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
HT1064	PWS1064-CU	BL1-PWS1064-CU	#N/A	#1-Transformer-power-supply	Motor-Current-Feedback	AI		4-20mA	2-wire	UTI-DCS-001_1 (R)	TB-AI	219	220								S9	4	7	8	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
HT1064	PWS1064-CU	BL1-PWS1064-CU	#N/A	#2-Transformer-power-supply	Motor-Current-Feedback	AI		4-20mA	2-wire	UTI-DCS-001_1 (R)	TB-AI	221	222								S9	5	9	10	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
HT1064	PWS1064-CU	BL1-PWS1064-CU	#N/A	#3-Transformer-power-supply	Motor-Current-Feedback	AI		4-20mA	2-wire	UTI-DCS-001_1 (R)	TB-AI	223	224								S9	6	11	12	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
LCV1020-SY	LCV1020-SY	BL1-LCV1020-SY	BL1_FT1020	1# Boiler feedwater control valve	Pneumatic control valve	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	225	226								S9	7	13	14	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
LCV1021-SY	LCV1021-SY	BL1-LCV1021-SY	BL1_LCV1021	1# Boiler feedwater bypass control valve	Pneumatic control valve	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	227	228								S9	8	15	16	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
TCV1022-SY	TCV1022-SY	BL1-TCV1022-SY	BL1_T1022	1# Boiler desuperheat water control valve	Pneumatic control valve	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	229	230								S9	9	17	18	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
PCV1023-SY	PCV1023-SY	BL1-PCV1023-SY	BL1_PCV1023	1# Boiler continuous blowdown control valve	Pneumatic control valve	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	231	232								S9	10	19	20	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
PCV1024-SY	PCV1024-SY	BL1-PCV1024-SY	BL1_PCV1024	1# Boiler take fire blow off control valve	Pneumatic control valve	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AI	233	234								S9	11	21	22	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001_1 (R)	TB-AI	235	236								S9	12	23	24	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001_1 (R)	TB-AI	237	238								S9	13	25	26	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001_1 (R)	TB-AI	239	240								S9	14	27	28	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001_1 (R)	TB-AI	241	242								S9	15	29	30	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001_1 (R)	TB-AI	243	244								S9	16	31	32	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
LCV1020	LCV1020	BL1-LCV1020-ZO	BL1_FT1020	1# Boiler feedwater control valve	Pneumatic control valve	AO	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AO	1	2								S11	1	1	2	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
LCV1021	LCV1021	BL1-LCV1021-ZO	BL1_LCV1021	1# Boiler feedwater bypass control valve	Pneumatic control valve	AO	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AO	3	4								S11	2	3	4	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
TCV1022	TCV1022	BL1-TCV1022-ZO	BL1_T1022	1# Boiler desuperheat water control valve	Pneumatic control valve	AO	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AO	5	6								S11	3	5	6	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
PCV1023	PCV1023	BL1-PCV1023-ZO	BL1_PCV1023	1# Boiler continuous blowdown control valve	Pneumatic control valve	AO	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AO	7	8								S11	4	7	8	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
PCV1024	PCV1024	BL1-PCV1024-ZO	BL1_PCV1024	1# Boiler take fire blow off control valve	Pneumatic control valve	AO	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_1 (R)	TB-AO	9	10								S11	5	9	10	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
MV1003-ZO	V2003	BL2-V2003	BL1_V1003	Electric bypass feedwater valve	Electric Valve	AO	0-100%	4-20 mA	2 wire AO + 2 wire 380VAC Power	UTI-DCS-001_1 (R)	TB-AO	11	12								S11	6	11	12	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001_1 (R)	TB-AO	13	14								S11	7	13	14	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	UTI-DCS-001_1 (R)	TB-AO	15	16								S11	8	15	16	UTI-DCS-001_1 (F)	UTI-CTRL_1_1			
LSH1061	LSH1061	BL1-LSH1061	BL1_LSH1061	1# Boiler NO.1 Electric field ash hopper higher level	Tuning fork limit switch	DI		DI dry contact	2 wire 230VAC+2 wire dry contact	UTI-DCS-001_1 (R)	TB-DI	1	2	L		N					S13	1	1						

										RIO CABINET														SYSTEM CABINET																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													
Vendor's tags		Wilmar's Tags		Emerson's Tag		Module Name		Description		Type		I/O Type		RangeProposed		Signal Type		Electrical Connection Type		Cabinet Name		TB Name		Marshalling		Term. (+)		Term. (-)		24V(+) Term		24V(-) Term		Term. (+)		Term. (-)		Relay		Name		Term. (+)		Term. (-)		Slot		Channel		Term. (+)		Term. (-)		Cabinet Name		Controller																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													
AR1061	VB1061A-XA	BL1-VB1061A-XA	BL1_VB1061A	#1 Anode rapping	Motor trip feedback	DI		DI Dry Contact	2 wire	UTI-DCS-001_1 (R)	TB-DI	157	158							UTI-DCS-001_1 (R)	TB-DI	157	158																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																														

											RIO CABINET										SYSTEM CABINET							
Vendor's tags		Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range	Proposed	Signal Type	Electrical Connection Type	Cabinet Name	TB Name	Marshallng		Relay		Delta V		Delta V		Cabinet Name	Controller					
														Term. (+)	Term. (-)	24V(+) Term	24V(-) Term	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)					
MV10101	V10101	BL1-V10101	BL1_V10101	BL1_V10101	9# Ignition control cabinet air door valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	91	92			14	11	RD01-46	A1	A2	S19	14	14	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10101	V10101	BL1-V10101	BL1_V10101	BL1_V10101	10# Ignition control cabinet air door valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	93	94			14	11	RD01-47	A1	A2	S19	15	15	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	1# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	95	96			14	11	RD01-48	A1	A2	S19	16	16	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	2# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	97	98			14	11	RD01-49	A1	A2	S19	17	17	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	3# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	99	100			14	11	RD01-50	A1	A2	S19	18	18	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	4# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	101	102			14	11	RD01-51	A1	A2	S19	19	19	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	5# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	103	104			14	11	RD01-52	A1	A2	S19	20	20	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	6# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	105	106			14	11	RD01-53	A1	A2	S19	21	21	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	7# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	107	108			14	11	RD01-54	A1	A2	S19	22	22	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	8# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	109	110			14	11	RD01-55	A1	A2	S19	23	23	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	9# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	111	112			14	11	RD01-56	A1	A2	S19	24	24	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV10102/3	V10102	BL1-V10102	BL1_V10102	BL1_V10102	10# Ignition control cabinet acetylene solenoid valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	113	114			14	11	RD01-57	A1	A2	S19	25	25	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010A	IG1010A	BL1-IG1010A	BL1_IG1010A	BL1_IG1010A	1# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	115	116			14	11	RD01-58	A1	A2	S19	26	26	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010B	IG1010B	BL1-IG1010B	BL1_IG1010B	BL1_IG1010B	2# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	117	118			14	11	RD01-59	A1	A2	S19	27	27	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010C	IG1010C	BL1-IG1010C	BL1_IG1010C	BL1_IG1010C	3# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	119	120			14	11	RD01-60	A1	A2	S19	28	28	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010D	IG1010D	BL1-IG1010D	BL1_IG1010D	BL1_IG1010D	4# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	121	122			14	11	RD01-61	A1	A2	S19	29	29	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010E	IG1010E	BL1-IG1010E	BL1_IG1010E	BL1_IG1010E	5# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	123	124			14	11	RD01-62	A1	A2	S19	30	30	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010F	IG1010F	BL1-IG1010F	BL1_IG1010F	BL1_IG1010F	6# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	125	126			14	11	RD01-63	A1	A2	S19	31	31	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010G	IG1010G	BL1-IG1010G	BL1_IG1010G	BL1_IG1010G	7# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	127	128			14	11	RD01-64	A1	A2	S19	32	32	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010H	IG1010H	BL1-IG1010H	BL1_IG1010H	BL1_IG1010H	8# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	129	130			14	11	RD01-65	A1	A2	S20	1	1	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010I	IG1010I	BL1-IG1010I	BL1_IG1010I	BL1_IG1010I	9# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	131	132			14	11	RD01-66	A1	A2	S20	2	2	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
SPI1010J	IG1010J	BL1-IG1010J	BL1_IG1010J	BL1_IG1010J	10# Ignition control cabinet igniting transformer control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	133	134			14	11	RD01-67	A1	A2	S20	3	3	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV101004	V101004	BL1-V101004	BL1_V101004	BL1_V101004	1# Ignition control cabinet blow valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	135	136			14	11	RD01-68	A1	A2	S20	4	4	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV101004	V101004	BL1-V101004	BL1_V101004	BL1_V101004	2# Ignition control cabinet blow valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	137	138			14	11	RD01-69	A1	A2	S20	5	5	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV101004	V101004	BL1-V101004	BL1_V101004	BL1_V101004	3# Ignition control cabinet blow valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	139	140			14	11	RD01-70	A1	A2	S20	6	6	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV101004	V101004	BL1-V101004	BL1_V101004	BL1_V101004	4# Ignition control cabinet blow valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	141	142			14	11	RD01-71	A1	A2	S20	7	7	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV101004	V101004	BL1-V101004	BL1_V101004	BL1_V101004	5# Ignition control cabinet blow valve control	Switch signal	DO			24VDC Wet Supply	2 wire	UTI-DCS-001_1 (R)	TB-DO	143	144			14	11	RD01-72	A1	A2	S20	8	8	NA	UTI-DCS-001_1 (F)	UTI-CTRL_1_1
MV101004	V10																											

										RIO CABINET														SYSTEM CABINET	
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	RangeProposed	Signal Type	Electrical Connection Type	Marshalling				Relay				DELTA V				DELTA V		Cabinet Name	Controller
										Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term	24V(-) Term	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	
PU001	PU0001-SC	BL1-PU0001-SC	BL1_PU0001	#1 feeder water pump	Motor Speed Command	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
PU001	PU0001-CU	BL1-PU0001-CU	BL1_PU0001	#1 feeder water pump	Motor Current Feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
PU001	PU0001-SP	BL1-PU0001-SP	BL1_PU0001	#1 feeder water pump	Motor Speed Feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
PU002	PU0002-HS	BL1-PU0002-HS	BL1_PU0002	#2 feeder water pump	Motor start command	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
PU002	PU0002-XL	BL1-PU0002-XL	BL1_PU0002	#2 feeder water pump	Motor run feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
PU002	PU0002-XA	BL1-PU0002-XA	BL1_PU0002	#2 feeder water pump	Motor trip feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
PU002	PU0002-SC	BL1-PU0002-SC	BL1_PU0002	#2 feeder water pump	Motor Speed Command	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
PU002	PU0002-CU	BL1-PU0002-CU	BL1_PU0002	#2 feeder water pump	Motor Current Feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
PU002	PU0002-SP	BL1-PU0002-SP	BL1_PU0002	#2 feeder water pump	Motor Speed Feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
RF231	RL231-HS	BL1-RL231-HS	BL1_RL231	2# Limestone rotary feeder	Motor start command	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
RF231	RL231-XL	BL1-RL231-XL	BL1_RL231	2# Limestone rotary feeder	Motor run feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
RF231	RL231-XA	BL1-RL231-XA	BL1_RL231	2# Limestone rotary feeder	Motor trip feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
RF231	RL231-SC	BL1-RL231-SC	BL1_RL231	2# Limestone rotary feeder	Motor Speed Command	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
RF231	RL231-CU	BL1-RL231-CU	BL1_RL231	2# Limestone rotary feeder	Motor Current Feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1
RF231	RL231-SP	BL1-RL231-SP	BL1_RL231	2# Limestone rotary feeder	Motor Speed Feedback	Profinet				UTI-DCS-001_1 (R)														UTI-DCS-001_1 (F)	UTI-CTRL_1_1

Emerson Automation Solution - Confidential and Proprietary

										RIO CABINET										SYSTEM CABINET									
										DELTA V										DELTA V									
Vendor's tags	Wilmart's Tags	Emerson's Tags	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal Type	Electrical Connection Type	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term	24V(-) Term	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller			
TT020	TT0200	BL0-TT0200	BL0-TT0200	Deaerator water temperature	Temperature Transmitter	AI	0-150°C	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	241	242								S9	15	29	30	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
TT230	TT0300	BL0-TT0300	BL0-TT0300	Limestone gasification wind heating temperature	Temperature Transmitter	AI	0-200°C	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	243	244								S9	16	31	32	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
VT001	VT0001	BL0-VT0001	BL0-VT0001	1# feedwater pump vibration signal	Vibration transmitter	AI	0-20mm/s	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	245	246								S10	1	1	2	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
VT002	VT0002	BL0-VT0002	BL0-VT0002	2# feedwater pump vibration signal	Vibration transmitter	AI	0-20mm/s	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	247	248								S10	2	3	4	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
VT003	VT0003	BL0-VT0003	BL0-VT0003	3# feedwater pump vibration signal	Vibration transmitter	AI	0-20mm/s	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	249	250								S10	3	5	6	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
VT004	VT0004	BL0-VT0004	BL0-VT0004	4# feedwater pump vibration signal	Vibration transmitter	AI	0-20mm/s	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	251	252								S10	4	7	8	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PUB081A_FB	PUB0081AFB	BL0-PUB0081AFB	BL0-PUB081A	1# Ammonia pump frequency feedback signal	Dosing System Component	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	253	254								S10	5	9	10	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PUB081B_FB	PUB0081BFB	BL0-PUB0081BFB	BL0-PUB081B	2# Ammonia pump frequency feedback signal	Dosing System Component	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	255	256								S10	6	11	12	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PUB082A_FB	PUB0082AFB	BL0-PUB0082AFB	BL0-PUB082A	1# Sodium sulfite pump frequency feedback signal	Dosing System Component	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	257	258								S10	7	13	14	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PUB082B_FB	PUB0082BFB	BL0-PUB0082BFB	BL0-PUB082B	2# Sodium sulfite pump frequency feedback signal	Dosing System Component	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	259	260								S10	8	15	16	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PUB083A_FB	PUB0083AFB	BL0-PUB0083AFB	BL0-PUB083A	1# Phosphate pump frequency feedback signal	Dosing System Component	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	261	262								S10	9	17	18	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PUB083B_FB	PUB0083BFB	BL0-PUB0083BFB	BL0-PUB083B	2# Phosphate pump frequency feedback signal	Dosing System Component	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	263	264								S10	10	19	20	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PUB084A_FB	PUB0084AFB	BL0-PUB0084AFB	BL0-PUB084A	3# Phosphate pump frequency feedback signal	Dosing System Component	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	265	266								S10	11	21	22	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PUB084B_FB	PUB0084BFB	BL0-PUB0084BFB	BL0-PUB084B	4# Phosphate pump frequency feedback signal	Dosing System Component	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	267	268								S10	12	23	24	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	269	270								S10	13	25	26	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	271	272								S10	14	27	28	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
FT-1323	FT1323	BL0-FT1323	BL0-FT1323	Flow Transmitter	Flow Transmitter	AI			2 Wire	UTI-DCS-001_2 (R)	TB-AI	273	274								S10	15	29	30	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
FT-1439	FT1439	BL0-FT1439	BL0-FT1439	Flow Transmitter	Flow Transmitter	AI			2 Wire	UTI-DCS-001_2 (R)	TB-AI	275	276								S10	16	31	32	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
LT-609	LT609	BL0-LT609	BL0-LT609	Level Transmitter	Ultrasonic	AI		4-20 mA HART	2 Wire	UTI-DCS-001_2 (R)	TB-AI	277	278								S11	1	1	2	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
LT-16010	LT16010	BL0-LT6010	BL0-LT6010	Level Transmitter	Ultrasonic	AI		4-20 mA HART	2 Wire	UTI-DCS-001_2 (R)	TB-AI	279	280								S11	2	3	4	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PT-1323	PT1323	BL0-PT1323	BL0-PT1323	Pressure Transmitter	Pressure Transmitter	AI		4-20 mA HART	2 Wire	UTI-DCS-001_2 (R)	TB-AI	281	282								S11	3	5	6	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
TT-1323	TT1323	BL0-TT1323	BL0-TT1323	Temperature Transmitter	Temperature Transmitter	AI		4-20 mA HART	2 Wire	UTI-DCS-001_2 (R)	TB-AI	283	284								S11	4	7	8	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
LCV2020-SY	LCV2020-SY	BL2-LCV2020-SY	BL2-FT2020	2# Boiler feedwater control valve	Pneumatic control valve	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	285	286								S11	5	9	10	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
LCV2021-SY	LCV2021-SY	BL2-LCV2021-SY	BL2-LCV2021	2# Boiler feedwater bypass control valve	Pneumatic control valve	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	287	288								S11	6	11	12	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
TCV2022-SY	TCV2022-SY	BL2-TCV2022-SY	BL2-TCV2022	2# Boiler desuperheat water control valve	Pneumatic control valve	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	289	290								S11	7	13	14	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PCV2023-SY	PCV2023-SY	BL2-PCV2023-SY	BL2-PCV2023	2# Boiler continuous blowdown control valve	Pneumatic control valve	AI	0-100%	4-20 mA HART	2 wire	UTI-DCS-001_2 (R)	TB-AI	291	292								S11	8	15	16	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
FT-1467	FT1467	CP1-FT1467	CP1-FT1467	Flow Meter	Flow Meter	AI		4-20 mA	2 Wire	UTI-DCS-001_2 (R)	TB-AI	293	294								S11	9	17	18	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
FT-1471	FT1471	CP1-FT1471	CP1-FT1471	Flow Meter	Flow Meter	AI		4-20 mA	2 Wire	UTI-DCS-001_2 (R)	TB-AI	295	296								S11	10	19	20	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
FT-1475	FT1475	CP1-FT1475	CP1-FT1475	Flow Meter	Flow Meter	AI		4-20 mA	2 Wire	UTI-DCS-001_2 (R)	TB-AI	297	298								S11	11	21	22	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
FT-1633	FT1633	CP1-FT1633	CP1-FT1633	Flow Meter	Flow Meter	AI		4-20 mA	2 Wire	UTI-DCS-001_2 (R)	TB-AI	299	300								S11	12	23	24	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
FT-1471	FT1471	CP1-FT1471	CP1-FT1471	Flow Meter	Flow Meter	AI		4-20 mA	2 Wire	UTI-DCS-001_2 (R)	TB-AI	301	302								S11	13	25	26	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PT-701	PT701	CP1-PT701	CP1-PT701	Pressure Transmitter & Indicator	Pressure Transmitter & Indicator	AI		4-20 mA	2 Wire	UTI-DCS-001_2 (R)	TB-AI	303	304								S11	14	27	28	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PT-702	PT702	CP1-PT702	CP1-PT702	Pressure Transmitter & Indicator	Pressure Transmitter & Indicator	AI		4-20 mA	2 Wire	UTI-DCS-001_2 (R)	TB-AI	305	306								S11	15	29	30	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PT-704	PT704	CP1-PT704	CP1-PT704	Pressure Transmitter & Indicator	Pressure Transmitter & Indicator	AI		4-20 mA	2 Wire	UTI-DCS-001_2 (R)	TB-AI	307	308								S11	16	31	32	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
PT-1633	PT1633	CP1-PT1633	CP1-PT1633	Pressure Transmitter & Indicator	Pressure Transmitter & Indicator	AI		4-20 mA	2 Wire	UTI-DCS-001_2 (R)	TB-AI	309	310								S12	1	1	2	UTI-DCS-001_2 (F)	UTI-CTRL 1_2			
SC241C	DC0041C-CU	BL0-DC0041C-CU	BL0-CP0041C	3# Air compressor	Temperature Transmitter	AI		4-20 mA HART	2 wire																				

RIO CABINET																				SYSTEM CABINET						
										DELTA V																
Vendor's tags	Wilmor's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal Type	Electrical Connection Type	Cabinet Name	T8 Name	Term. (+)	Term. (-)	24V(+) Term	24V(-) Term	Term. (+)	Term. (-)	Relay	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller
GAH2010B	IG2010B	BL2-IG2010B	BL2_IG2010B	#2 Ignition control cabinet acetylene leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	73	74							S18	21	21	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
GAH2010C	IG2010C	BL2-IG2010C	BL2_IG2010C	#3 Ignition control cabinet acetylene leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	75	76							S18	22	22	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
GAH2010D	IG2010D	BL2-IG2010D	BL2_IG2010D	#4 Ignition control cabinet acetylene leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	77	78							S18	23	23	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
GAH2010E	IG2010E	BL2-IG2010E	BL2_IG2010E	#5 Ignition control cabinet acetylene leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	79	80							S18	24	24	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
GAH2010F	IG2010F	BL2-IG2010F	BL2_IG2010F	#6 Ignition control cabinet acetylene leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	81	82							S18	25	25	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
GAH2010G	IG2010G	BL2-IG2010G	BL2_IG2010G	#7 Ignition control cabinet acetylene leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	83	84							S18	26	26	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
GAH2010H	IG2010H	BL2-IG2010H	BL2_IG2010H	#8 Ignition control cabinet acetylene leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	85	86							S18	27	27	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
GAH2010I	IG2010I	BL2-IG2010I	BL2_IG2010I	#9 Ignition control cabinet acetylene leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	87	88							S18	28	28	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
GAH2010J	IG2010J	BL2-IG2010J	BL2_IG2010J	#10 Ignition control cabinet acetylene leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	89	90							S18	29	29	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
GAH2010K	IG2010K	BL2-IG2010K	BL2_IG2010K	Acetylene Cabinet Acetylene Leakage signal	Switch signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	91	92							S18	30	30	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
BT2001_DI	BT1001DI	BL2-BT1001DI	BL2_BR1001I	Burner Signal	1# Flame signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	93	94							S18	31	31	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
BT2002_DI	BT1002DI	BL2-BT1002DI	BL2_BR1001I	Burner Signal	2# Flame signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	95	96							S18	32	32	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
BZ2001_IEE	B1001IEE	BL2-BR1001IEE	BL2_BR1001IEE	Burner Signal	Ignition enter enough	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	97	98							S19	1	1	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
BZ2001_IBE	B1001IBE	BL2-BR1001IBE	BL2_BR1001IBE	Burner Signal	Ignition enter enough	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	99	100							S19	2	2	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
MV012_ZSO	MV012ZSO	BL2-TCV012ZSO	BL2_TCV012I	Burner Signal	Oil valve opened	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	101	102							S19	3	3	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
MV012_ZSC	MV012ZSC	BL2-TCV012ZSO	BL2_TCV012I	Burner Signal	Oil valve closed	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	103	104							S19	4	4	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
MV013_ZSO	MV013ZSO	BL2-FCV013ZSO	BL2_FCV015I	Burner Signal	Purge valve opened	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	105	106							S19	5	5	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
MV013_ZSC	MV013ZSC	BL2-FCV013ZSO	BL2_FCV015I	Burner Signal	Purge valve closed	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	107	108							S19	6	6	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
BZ2001_AUTO	B1001AU	BL2-BR1001AU	BL2_BR1001AU	Burner Signal	Automatic signal	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	109	110							S19	7	7	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
BZ2001_SA	B1001SA	BL2-BR1001SA	BL2_BR1001I	Burner Signal	Start allowed	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	111	112							S19	8	8	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
BZ2001_FL	B1001FL	BL2-BR1001FL	BL2_BR1001I	Burner Signal	Fire alarm	DI		24VDC Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	113	114							S19	9	9	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2011	FN2011-XL	BL2-FN2011-XL	BL2_FN2011I	Motor run feedback	Primary air fan cooling fan	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	115	116							S19	10	10	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2011	FN2011-XA	BL2-FN2011-XA	BL2_FN2011I	Motor trip feedback	Primary air fan cooling fan	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	117	118							S19	11	11	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2012	FN2012-XL	BL2-FN2012-XL	BL2_FN2012I	Motor run feedback	Secondary air fan cooling fan	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	119	120							S19	12	12	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2012	FN2012-XA	BL2-FN2012-XA	BL2_FN2012I	Motor trip feedback	Secondary air fan cooling fan	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	121	122							S19	13	13	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2013	FN2013-XL	BL2-FN2013-XL	BL2_FN2013I	Motor run feedback	Induced draft fan cooling fan	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	123	124							S19	14	14	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2013	FN2013-XA	BL2-FN2013-XA	BL2_FN2013I	Motor trip feedback	Induced draft fan cooling fan	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	125	126							S19	15	15	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2004	FN2004-XL	BL2-FN2004-XL	BL2_FN2004I	Motor run feedback	Return air fan	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	127	128							S19	16	16	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2004	FN2004-XA	BL2-FN2004-XA	BL2_FN2004I	Motor trip feedback	Return air fan	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	129	130							S19	17	17	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2014	FN2014-XL	BL2-FN2014-XL	BL2_FN2014I	#1 Belt coal feeder cooling fan	Motor run feedback	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	131	132							S19	18	18	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2014	FN2014-XA	BL2-FN2014-XA	BL2_FN2014I	#1 Belt coal feeder cooling fan	Motor trip feedback	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	133	134							S19	19	19	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2015	FN2015-XL	BL2-FN2015-XL	BL2_FN2015I	#2 Belt coal feeder cooling fan	Motor run feedback	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	135	136							S19	20	20	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
FN2015	FN2015-XA	BL2-FN2015-XA	BL2_FN2015I	#2 Belt coal feeder cooling fan	Motor trip feedback	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	137	138							S19	21	21	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
CM2001	BC2001A-XL	BL2-BC2001A-XL	BL2_BC2001I	#1 cleaning motor	Motor run feedback	DI		Di Dry Contact	2 wire	UTI-DCS-001_2 (R)	TB-DI	139	140							S19	22	22	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2	
CM2001	BC2001A-XA																									

RIO CABINET																							SYSTEM CABINET			
										Marshalling				Relay				DELTA V				DELTA V				
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal Type	Electrical Connection Type	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term	24V(-) Term	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term. (+)	Term. (-)	Cabinet Name	Controller
BC053	BC053_RN	BL0-BC053_RN	BL0-BC053	3# Coal belt conveyor	3# Coal belt conveyor run signal	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	357	358								S23	3	3	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
BC053	BC053_AD	BL0-BC053_AD	BL0-BC053_AD	3# Coal belt conveyor anti-deviation device signal		DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	359	360								S23	4	4	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
BC053	BC053_ARW	BL0-BC053_ARW	BL0-BC053_ARW	3# Coal belt conveyor two-way accident rope switch signal		DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	361	362								S23	5	5	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
BC053	BC053_SS	BL0-BC053_SS	BL0-BC053_SS	3# Coal belt conveyor speed monitoring device signal		DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	363	364								S23	6	6	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
BC054	BC054_FL	BL0-BC054_FL	BL0-BC054	4# Coal belt conveyor	4# Coal belt conveyor fault signal	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	365	366								S23	7	7	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
BC054	BC054_RN	BL0-BC054_RN	BL0-BC054	4# Coal belt conveyor	4# Coal belt conveyor run signal	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	367	368								S23	8	8	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
BC054	BC054_AD	BL0-BC054_AD	BL0-BC054_AD	4# Coal belt conveyor anti-deviation device signal		DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	369	370								S23	9	9	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
BC054	BC054_ARW	BL0-BC054_ARW	BL0-BC054_ARW	4# Coal belt conveyor two-way accident rope switch signal		DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	371	372								S23	10	10	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
BC054	BC054_SS	BL0-BC054_SS	BL0-BC054_SS	4# Coal belt conveyor speed monitoring device signal		DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	373	374								S23	11	11	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051A	CR051A_FBA	BL0-CR051A_FBA	BL0-CR051A_FBA	1# Four-Roller crusher	1# Four-Roller crusher Flash back and soft and report to the police alarm	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	375	376								S23	12	12	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051A	CR051AHRN	BL0-CR051A_HRN	BL0-CR051A	1# Four-Roller crusher	1# Four-Roller crusher 1# host run signal	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	377	378								S23	13	13	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051A	CR051AMP	BL0-CR051A_MP	BL0-CR051A	1# Four-Roller crusher	1# Four-Roller crusher motor protector alarm	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	379	380								S23	14	14	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051A	CR051APS	BL0-CR051A_PS	BL0-CR051A_PS	1# Four-Roller crusher	1# Four-Roller crusher remote power signal	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	381	382								S23	15	15	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051A	CR051ARC	BL0-CR051A_RC	BL0-CR051A_RC	1# Four-Roller crusher	1# Four-Roller crusher remote control signal	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	383	384								S23	16	16	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051A	CR051ARN	BL0-CR051A_RN	BL0-CR051A_RN	1# Four-Roller crusher	1# Four-Roller crusher 2# host run signal(Enter to anticipate to allow)	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	385	386								S23	17	17	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051A	CR051ASIA	BL0-CR051A_SIA	BL0-CR051A_SIA	1# Four-Roller crusher	1# Four-Roller crusher speed alarm	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	387	388								S23	18	18	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051A	CR051ATO	BL0-CR051A_TO	BL0-CR051A_TO	1# Four-Roller crusher	1# Four-Roller crusher temperature/over-current alarm	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	389	390								S23	19	19	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051B	CR051BFA	BL0-CR051B_FBA	BL0-CR051B_FBA	2# Four-Roller crusher	2# Four-Roller crusher Flash back and soft and report to the police alarm	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	391	392								S23	20	20	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051B	CR051BHRN	BL0-CR051B_HRN	BL0-CR051B	2# Four-Roller crusher	2# Four-Roller crusher 2# host run signal	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	393	394								S23	21	21	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051B	CR051BMP	BL0-CR051B_MP	BL0-CR051B	2# Four-Roller crusher	2# Four-Roller crusher motor protector alarm	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	395	396								S23	22	22	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051B	CR051BPS	BL0-CR051B_PS	BL0-CR051B_PS	2# Four-Roller crusher	2# Four-Roller crusher remote power signal	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	397	398								S23	23	23	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051B	CR051BRC	BL0-CR051B_RC	BL0-CR051B_RC	2# Four-Roller crusher	2# Four-Roller crusher remote control signal	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	399	400								S23	24	24	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051B	CR051BRN	BL0-CR051B_RN	BL0-CR051B_RN	2# Four-Roller crusher	2# Four-Roller crusher 3# host run signal(Enter to anticipate to allow)	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	401	402								S23	25	25	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051B	CR051BSIA	BL0-CR051B_SIA	BL0-CR051B_SIA	2# Four-Roller crusher	2# Four-Roller crusher speed alarm	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	403	404								S23	26	26	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
CR051B	CR051BTO	BL0-CR051B_TO	BL0-CR051B_TO	2# Four-Roller crusher	2# Four-Roller crusher temperature/over-current alarm	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	405	406								S23	27	27	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
PS-801	PSH801	CP1-PSH801	CP1_PSH801	Pressure Switch		DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	407	408								S23	28	28	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
PS-802	PSH802	CP1-PSH802	CP1_PSH802	Pressure Switch		DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	409	410								S23	29	29	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
PS-803	PSH803	CP1-PSH803	CP1_PSH803	Pressure Switch		DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	411	412								S23	30	30	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
FN003	FN003-XL	BL2-FN003-XL	BL2_FN003	#3 feeder water pump cooling fan	Motor run feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	413	414								S23	31	31	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
FN003	FN003-XA	BL2-FN003-XA	BL2_FN003	#3 feeder water pump cooling fan	Motor trip feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	415	416								S23	32	32	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
FN004	FN004-XL	BL2-FN004-XL	BL2_FN004	#4 feeder water pump cooling fan	Motor run feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	417	418								S24	1	1	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
FN004	FN004-XA	BL2-FN004-XA	BL2_FN004	#4 feeder water pump cooling fan	Motor trip feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	419	420								S24	2	2	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
PU005B	BL2-PU005B-XL	BL2_PU005B	BL2_PU005B	2# Deaerator water pump	Motor run feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	421	422								S24	3	3	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
PU005B	BL2-PU005B-XA	BL2_PU005B	BL2_PU005B	2# Deaerator water pump	Motor trip feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	423	424								S24	4	4	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
PU012	BL2-PU012-XL	BL2_PU012	BL2_PU012	#2 Oil pump	Motor run feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	425	426								S24	5	5	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
PU012	BL2-PU012-XA	BL2_PU012	BL2_PU012	#2 Oil pump	Motor trip feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	427	428								S24	6	6	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
MV052	SG0052-XY	BL2-SG0052-XY	BL2_SG0052	2# Side-side plough discharger	Motor right run feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	429	430								S24	7	7	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
MV052	SG0052-XZ	BL2-SG0052-XZ	BL2_SG0052	2# Side-side plough discharger	Motor Left run feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	431	432								S24	8	8	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
MV052	SG0052-XA	BL2-SG0052-XA	BL2_SG0052	2# Side-side plough discharger	Motor Trip feedback	DI			2 wire	UTI-DCS-001.2 (R)	TB-DI	433	434								S24	9	9	NA	UTI-DCS-001.2 (F)	UTI-CTRL1.2
SC241C	CP041C-XL	BL0-CP041C-XL	BL0_CP041C	3# Air compressor		DI				UTI-DCS-001.2 (R)	TB-DI	435	4													

													RIO CABINET										SYSTEM CABINET																									
Vendor's tags		Wilmar's Tags		Emerson's Tag		Module Name		Description		Type		I/O Type		Range Proposed (kg/H)		Signal Type		Electrical Connection Type		Cabinet Name		TB Name		Term. (+)		Term. (-)		24V(+) Term		24V(-) Term		Term. (+)		Term. (-)		Relay		Channel		DELTA V		DELTA V		Cabinet Name		Controller		
BP2071_ALM	PU2071ALM	BL2-PU2071ALM	BL2_PU2071ALM	NO.1 Bin pump fault alarm		BL2_PU2071ALM	NO.1 Bin pump fault alarm	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	45	46					RD01-23	A1	A2	S27	23	23	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
BP2072_AM_ON	PU2072ON	BL2-PU2072ON	BL2_PU2072ON	NO.2 Bin pump automatic / manual Instructions		BL2_PU2072ON	NO.2 Bin pump automatic / manual Instructions	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	47	48					RD01-24	A1	A2	S27	24	24	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
BP2072_ALM	PU2072ALM	BL2-PU2072ALM	BL2_PU2072ALM	NO.2 Bin pump fault alarm		BL2_PU2072ALM	NO.2 Bin pump fault alarm	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	49	50					RD01-25	A1	A2	S27	25	25	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
BP2073_AM_ON	PU2073ON	BL2-PU2073ON	BL2_PU2073ON	NO.3 Bin pump automatic / manual Instructions		BL2_PU2073ON	NO.3 Bin pump automatic / manual Instructions	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	51	52					RD01-26	A1	A2	S27	26	26	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
BP2073_ALM	PU2073ALM	BL2-PU2073ALM	BL2_PU2073ALM	NO.3 Bin pump fault alarm		BL2_PU2073ALM	NO.3 Bin pump fault alarm	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	53	54					RD01-27	A1	A2	S27	27	27	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010A	FN2010A	BL2-FN2010A	BL2_FN2010A	18 Ignition control cabinet fan control		BL2_FN2010A	18 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	55	56					RD01-28	A1	A2	S27	28	28	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010B	FN2010B	BL2-FN2010B	BL2_FN2010B	28 Ignition control cabinet fan control		BL2_FN2010B	28 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	57	58					RD01-29	A1	A2	S27	29	29	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010C	FN2010C	BL2-FN2010C	BL2_FN2010C	38 Ignition control cabinet fan control		BL2_FN2010C	38 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	59	60					RD01-30	A1	A2	S27	30	30	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010D	FN2010D	BL2-FN2010D	BL2_FN2010D	48 Ignition control cabinet fan control		BL2_FN2010D	48 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	61	62					RD01-31	A1	A2	S27	31	31	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010E	FN2010E	BL2-FN2010E	BL2_FN2010E	58 Ignition control cabinet fan control		BL2_FN2010E	58 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	63	64					RD01-32	A1	A2	S27	32	32	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010F	FN2010F	BL2-FN2010F	BL2_FN2010F	68 Ignition control cabinet fan control		BL2_FN2010F	68 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	65	66					RD01-33	A1	A2	S28	1	1	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010G	FN2010G	BL2-FN2010G	BL2_FN2010G	78 Ignition control cabinet fan control		BL2_FN2010G	78 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	67	68					RD01-34	A1	A2	S28	2	2	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010H	FN2010H	BL2-FN2010H	BL2_FN2010H	88 Ignition control cabinet fan control		BL2_FN2010H	88 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	69	70					RD01-35	A1	A2	S28	3	3	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010I	FN2010I	BL2-FN2010I	BL2_FN2010I	98 Ignition control cabinet fan control		BL2_FN2010I	98 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	71	72					RD01-36	A1	A2	S28	4	4	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
FN2010J	FN2010J	BL2-FN2010J	BL2_FN2010J	108 Ignition control cabinet fan control		BL2_FN2010J	108 Ignition control cabinet fan control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	73	74					RD01-37	A1	A2	S28	5	5	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
V2010A1	V2010A1	BL2-V2010A1	BL2_V2010A1	18 Ignition control cabinet air door valve control		BL2_V2010A1	18 Ignition control cabinet air door valve control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	75	76					RD01-38	A1	A2	S28	6	6	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
V2010B1	V2010B1	BL2-V2010B1	BL2_V2010B1	28 Ignition control cabinet air door valve control		BL2_V2010B1	28 Ignition control cabinet air door valve control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	77	78					RD01-39	A1	A2	S28	7	7	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
V2010C1	V2010C1	BL2-V2010C1	BL2_V2010C1	38 Ignition control cabinet air door valve control		BL2_V2010C1	38 Ignition control cabinet air door valve control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	79	80					RD01-40	A1	A2	S28	8	8	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
V2010D1	V2010D1	BL2-V2010D1	BL2_V2010D1	48 Ignition control cabinet air door valve control		BL2_V2010D1	48 Ignition control cabinet air door valve control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	81	82					RD01-41	A1	A2	S28	9	9	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
V2010E1	V2010E1	BL2-V2010E1	BL2_V2010E1	58 Ignition control cabinet air door valve control		BL2_V2010E1	58 Ignition control cabinet air door valve control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	83	84					RD01-42	A1	A2	S28	10	10	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
V2010F1	V2010F1	BL2-V2010F1	BL2_V2010F1	68 Ignition control cabinet air door valve control		BL2_V2010F1	68 Ignition control cabinet air door valve control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	85	86					RD01-43	A1	A2	S28	11	11	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
V2010G1	V2010G1	BL2-V2010G1	BL2_V2010G1	78 Ignition control cabinet air door valve control		BL2_V2010G1	78 Ignition control cabinet air door valve control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	87	88					RD01-44	A1	A2	S28	12	12	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			
V2010H1	V2010H1	BL2-V2010H1	BL2_V2010H1	88 Ignition control cabinet air door valve control		BL2_V2010H1	88 Ignition control cabinet air door valve control	Switch signal	DO		24VDC Wet Supply	2 wire	UTI-DCS-001_2 (R)	TB-DD	89	90					RD01-45	A1	A2	S28	13	13	NA	UTI-DCS-001_2 (F)	UTI-CTRL_1_2																			

