

BODY ELECTRICAL - COMBINATION METER

A13 - Ground	Ignition switch ON and passenger door is opened	No voltage
A13 - Ground	Ignition switch ON and passenger door is closed	Battery positive voltage
A14 - Ground	Constant	Continuity
A17 - Ground	Constant	Continuity
A18 - Ground	Ignition switch ON and fuel sender gauge float UP	0.3 - 0.6 V
A18 - Ground	Ignition switch ON and fuel sender gauge float DOWN	4.9 - 6.9 V
A19 - Ground	Ignition switch ON and slowly move the wheel	4.5 - 5.5 V
A20 - Ground	Ignition switch ON and slowly move the wheel	Battery positive voltage
A21 - Ground	Key unlock warning switch ON (Key is inserted)	No voltage
A21 - Ground	Key unlock warning switch OFF (Key is removed)	Battery positive voltage
A22 - Ground	Ignition switch ON and passenger's seat belt is unfastened	No voltage
A22 - Ground	Ignition switch ON and passenger's seat belt is fastened	Battery positive voltage
B2 - Ground	Ignition switch ON and rheostat light control volume CANCEL position	No voltage
B2 - Ground	Ignition switch ON and rheostat light control volume maximum	Battery positive voltage
B4 - Ground	Light control switch OFF	No voltage
B4 - Ground	Light control switch TAIL or HEAD	Battery positive voltage
B5 - Ground	Ignition switch ON and engine coolant temperature HOT (Red) warning light light up	No voltage
B5 - Ground	Ignition switch ON and engine coolant temperature HOT (Red) warning light does not light up	Battery positive voltage
B6 - Ground	Ignition switch ON and engine coolant temperature COOL (Blue) warning light light up	No voltage
B6 - Ground	Ignition switch ON and engine coolant temperature COOL (Blue) warning light does not light up	Battery positive voltage
B7 - Ground	Ignition switch ON and engine oil level warning light up	No voltage
B7 - Ground	Ignition switch ON and engine oil level warning does not light up	Battery positive voltage
B8 - Ground	Ignition switch ON and engine is stopped	No voltage
B8 - Ground	Ignition switch ON and engine is running	Battery positive voltage
B11 - Ground	Constant	Continuity
B12 - Ground	Ignition switch OFF	No voltage
B12 - Ground	Ignition switch ON	Battery positive voltage
B13 - Ground	Ignition switch ON and engine is stopping	No voltage
B13 - Ground	Ignition switch ON and engine is running	Battery positive voltage
B14 - Ground	Ignition switch ON and SRS indicator light light up	No voltage
B14 - Ground	Ignition switch ON and SRS indicator does not light up	Battery positive voltage
B15 - Ground	Ignition switch ON, parking brake lever is released and brake fluid level warning switch float DOWN	No voltage