

BODY ELECTRICAL - COMBINATION METER

B15 - Ground	Ignition switch ON, parking brake lever is released and brake fluid level warning switch float UP	Battery positive voltage
B16 - Ground	Ignition switch ON and turn signal switch OFF or RIGHT	No voltage
B16 - Ground	Ignition switch ON and turn signal switch LEFT	Battery positive voltage
B17 - Ground	Ignition switch ON and ABS is error	No voltage
B17 - Ground	Ignition switch ON and ABS is normal	Battery positive voltage
B18 - Ground	Ignition switch ON and passenger's seat belt warning light up	No voltage
B18 - Ground	Ignition switch ON and passenger's seat belt warning does not light up	Battery positive voltage

If circuit is not as specified, wiring diagram and inspect the circuits connected to other parts.

2. INSPECT SPEEDOMETER ON-VEHICLE

Using a speedometer tester, inspect the speedometer for allowable indication error and check the operation of the odometer.

HINT:

Tire wear and tire over or under inflation will increase the indication error.

USA (mph)		CANADA (km/h)	
Standard indication	Allowable range	Standard indication	Allowable range
20	18 - 24	20	17 - 24
40	38 - 44	40	38 - 46
60	58 - 66	60	57.5 - 67
80	78 - 88	80	77 - 88
100	98 - 110	100	96 - 109
		120	115 - 130
		140	134 - 151.5
		160	153 - 173

If error is excessive, replace the speedometer.