

**Meter Gauges and Illumination:
COMBINATION METER**

Symptom	Suspect Area	See page
Tachometer, Fuel Gauge and Engine coolant Temperature Gauge does not operate.	1. GAUGE Fuse 2. Meter Circuit Plate 3. Wire Harness	- BE-44 -
Speedometer does not operate.	1. Vehicle Speed Sensor 2. Meter Circuit Plate 3. Wire Harness	BE-47 BE-44 -
Tachometer does not operate.	1. Igniter 2. ECM 3. Meter Circuit Plate 4. Wire Harness	- - BE-44 -
Fuel Gauge does not operate or abnormal operation.	1. Fuel Receiver Gauge 2. Fuel Sender Gauge 3. Meter Circuit Plate 4. Wire Harness	BE-47 BE-47 BE-44 -
All illumination lights do not light up.	1. TAIL Fuse 2. Meter Circuit Plate 3. Wire Harness	- BE-47 -
Brightness does not change even when rheostat turned.	1. Bulb 2. Wire Harness	- -
Only one illumination light does not light up.	1. Bulb 2. Wire Harness	- -