

Airtel DTH Troubleshooting Guide

Error Code: B001

Error: NO SIGNAL (Error:B001)

Reason:

- Heavy rainfall or cloudy skies
- Dish misalignment
- Cable or connector issue
- Obstruction in front of the dish

Troubleshooting:

- Wait for weather to improve
- Remove obstructions near the dish
- Check/reset cable connections and restart the set-top box
- Contact Airtel if channel 099 or 121 info isn't visible

Error Code: 2

Error: Please check, the viewing card is not inserted properly (Error Code:4)

Reason:

- Viewing card is not properly inserted or not detected

Troubleshooting:

- Gently pull out and clean the card
- Reinsert with gold chip down and arrow toward the box
- Contact Airtel customer care if issue persists

Error Code: 4

Error: This channel is not subscribed by you (Error: 4)

Reason:

- Channel not in your subscription pack

Troubleshooting:

- Add a top-up by sending SMS 'Add <top-up name>' to 54325
- Contact Airtel support to upgrade package

Error Code: 6

Error: Account is suspended due to low balance (Error Code: 6)

Reason:

- Account balance is less than zero

Troubleshooting:

- Recharge immediately
- Keep set-top box on for 20 minutes after recharge

General Troubleshooting Tips

Airtel DTH Troubleshooting Guide

Problem: No picture, No sound, no front panel display

Cause: STB not plugged in or switched off

Action: Check mains, press ON/OFF on STB

Problem: No picture, No sound, display on front panel

Cause: STB is in standby

Action: Press power on remote to wake it

Problem: Correct STB display but no TV output

Cause: Wrong AV source, faulty cables, or external source selected

Action: Press AV, check connections and cables

Problem: Irregular/bad reception

Cause: Broken or damaged cables

Action: Check connections, contact customer service

Problem: Blank screen for some services

Cause: Encrypted/unsubscribed service

Action: Switch to another channel or contact support

Problem: Remote works with TV not STB

Cause: STB not selected on remote

Action: Press 'STB' on remote

Problem: Remote doesn't work

Cause: Dead batteries, STB off

Action: Check batteries and STB power

Problem: Forgotten PIN

Action: Contact customer care

Problem: Cannot exit EPG

Action: Press 'exit' key on remote