st-util

Run GDB (GNU Debugger) server to interact with STM32 ARM Cortex microcontoller.

• Run GDB server on port 4500:

```
st-util -p {{4500}}
```

• Connect to GDB server:

```
(gdb) target extended-remote {{localhost}}:{{4500}}
```

• Write firmware to device:

```
(gdb) load {{firmware.elf}}
```