## st-info

Provides information about connected STLink and STM32 devices.

• Display amount of program memory available:

st-info --flash

• Display amount of sram memory available:

st-info --sram

• Display summarized information of the device:

st-info --probe