

TwinCatAdsTool, a manual

This tool reads the **PERSISTENT** variables out of a Beckhoff TwinCAT controller into a file, writes them back, and compares the two. It also watches live values and plots them.

The reason it exists is that persistent variables are the part of a machine that is **not** in the PLC project. Calibration measured on site, recipes, homing positions, counters, whatever was tuned by hand during commissioning: none of that is in source control, and none of it survives a controller swap, a change to the layout of a persistent structure, or a firmware upgrade. The program comes back in five minutes. Those values do not come back at all unless somebody has a copy.

Contents

1. [Before you start](#)
 2. [Connecting](#)
 3. [Taking a backup](#)
 4. [Restoring](#)
 5. [Proving a restore worked](#)
 6. [Comparing](#)
 7. [Watching values](#)
 8. [The scope](#)
 9. [Watch sets](#)
 10. [From the command line](#)
 11. [Where the files are](#)
 12. [When something goes wrong](#)
 13. [What is verified, and what is not](#)
-

1. Before you start

On the machine running this tool you need the TwinCAT ADS runtime installed. That is what provides the router every ADS message goes through. TwinCAT 4024 and 4026 both work, and the same executable serves them.

An ADS route to the controller must exist. A route is a permanent, named, authenticated path between two ADS machines. It is not the same as being able to ping the controller: you can have a perfect network connection and no route, and then nothing works.

Routes are made in the TwinCAT system tray icon, under *Router*, *Edit Routes*, or from the controller side. You need the controller's **AMS net id**, which is six numbers separated by dots such as `5.24.108.31.1.1`, and normally its password.

The controller needs a PLC runtime that is started. A controller in Config mode publishes no PLC symbols, and this tool has nothing to read.

What counts as persistent

Only variables declared `PERSISTENT` are read and written. In Structured Text that is

```
VAR_GLOBAL PERSISTENT
    rCalibration : REAL;
    stRecipe     : ST_Recipe;
END_VAR
```

A structure declared persistent makes **every member of it persistent in its own right**, which is why a backup of one `STRUCT PERSISTENT` shows up as an object with all of its members inside.

`RETAIN` variables are a different mechanism and are not covered.

2. Connecting

The bar across the top of the window is the connection, and it applies to every tab.

1. **Device** lists the controllers found by an ADS broadcast on the local network. Pick yours if it appears. The search only finds machines that answer a broadcast, so a controller behind a router will not be in the list even when it is perfectly reachable.
2. **Address** is the AMS net id. You can type it in directly, which is what you do when the broadcast did not find the controller.
3. **Port** is the PLC runtime. `851` is the first PLC task in TwinCAT 3 and is almost always the right answer. `801` is TwinCAT 2.
4. **Connect**.

When the state shows *Connected* together with the controller's ADS state (`Run` , `Stop` , `Config`), the tabs on the left become usable.

A controller in **Run** can be backed up and restored. Whether restoring onto a running machine is wise is a question about your plant, not about the tool: the values change under you while they are being written, and the program may overwrite what you just wrote. For anything you intend to verify afterwards, stop the PLC first.

3. Taking a backup

Backup tab, then **Read from PLC**.

Every persistent variable is read and shown as JSON. Then **Save to file** writes it where you say.

A backup file looks like this:

```
{
  "MAIN": {
    "nCycleCount": 18422,
    "stAxis": {
      "fHomeOffset": 12.75,
      "bCalibrated": true
    }
  },
  "GVL": {
    "aRecipe": [ 10, 20, 30, 40 ]
  }
}
```

It is ordinary JSON, on purpose. You can read it, edit it in a text editor, put it in version control, diff two of them with any tool you like, or generate one from a script.

Read the report

Report shows what happened to every variable, and it is worth reading rather than assuming.

```
71 ok, 0 failed, 0 skipped in 0.1 s
```

- **ok** means the variable is in the file.
- **failed** means it could not be read, with the ADS error that says why.
- **skipped** means it was left out.

A backup that says anything other than `0 failed, 0 skipped` **is not a full backup**, and the file will be missing exactly the variables named in the report. Save it if you want, but write down what is missing from it.

How often

A backup takes a fraction of a second, so there is no reason to be sparing. Sensible moments:

- at the end of commissioning, when the machine is right
- before any download that changes the declaration of a persistent variable
- before a TwinCAT or firmware upgrade
- before swapping a controller
- on a schedule, which is what the [command line](#) is for

4. Restoring

Restore tab, then **Load from file**. The variables from the file are listed. **Write to PLC** asks for confirmation, then writes.

Restoring writes each individual value to the symbol that owns it. That matters for a reason worth knowing: the ADS library hands out a **copy** of the buffer when you step into a structure member or an array element, so the older approach of reading a variable, changing it in memory and writing it back could not reach anything below the first level, and reported success anyway. Writing every leaf to its own symbol takes that copy out of the path.

Read the report, again

```
49 ok, 0 failed, 0 skipped in 1.9 s
```

- **failed**: the value was refused, with the ADS error.
- **skipped**: the variable is on the PLC but not in the file, so it was **left alone**. Skipped is not an error, but it does mean the plant now holds a mixture of the file and whatever was there before.

Variables in the file that no longer exist on the PLC are reported too. That is the usual sign of a file taken from a different version of the program.

What can go wrong at the value level

The report names the variable and the path within it, for example:

```
MAIN.stAxis.fHomeOffset: backup value 'abc' does not fit the plc type
```

This is what you get when a file has been hand edited into something the PLC type cannot hold. The rest of the restore still runs; only that leaf is refused.

5. Proving a restore worked

A report saying success is not proof that the plant holds what the file says. That is not a theoretical worry: it is the defect this fork was written to fix, and it went unnoticed for a long time precisely because the report looked fine.

The way to be sure is to read the plant back and compare it against the file:

1. Restore the file.
2. Take a fresh backup into a second file.
3. Compare the two.

The [Compare tab](#) does this by eye, and `compare` on the [command line](#) does it by exit code.

Do this with the PLC stopped. On a running machine the program writes its own values while you are comparing, and there is no way to tell a value the restore failed to write from one the program has changed since. That distinction cost a wrong conclusion once already.

6. Comparing

Compare tab. Each side can be filled either from the PLC or from a file, so you can compare

- a file against the plant, which is the verification above
- two files, for instance last month's backup against today's
- the plant against a file taken from another machine of the same type

The count of differing lines is shown at the top. Differences are coloured: added, removed, changed. Both panes scroll together, with the wheel or the scrollbar.

The comparison is textual, line by line. The command line's `compare` instead compares leaf by leaf and names each difference by its path, which is the better answer when there are many.

7. Watching values

Explore tab. This is where you look at live values and change them.

The left panel is the symbol tree. **Search** finds a symbol by any part of its path, which is usually faster than opening the tree. The circular arrow re-reads the symbol list from the PLC, which you need after downloading a new program.

The **+** next to a symbol adds it to the watch list on the right. Only leaves can be watched: a structure or an array has no single value to show.

The watch list shows, for each symbol:

Column	
Name	hover for the full path and the comment from the declaration
Value	live, updated from the PLC
Type	the PLC type as declared
P	the variable is persistent, so it is one of those the Backup and Restore tabs act on
New value	type a value here and press the send button to write it

The editor offered under *New value* follows the type: a switch for a `BOOL`, a number box for numeric types, a time picker for `TIME` and `DATE_AND_TIME`, a text box for strings.

Writing a value here writes it to the running machine immediately. There is no confirmation.

8. The scope

The lower half of the Explore tab plots the values you are watching. The chart button next to a symbol puts it on the plot; the minus takes it off.

Recording and viewing are two different spans

Memory	how far back the recording is kept
Window	how much of it is on screen

This separation is the whole point. Scrolling and zooming move the window **inside** the recording, so you can stop and go back to look at something that has already scrolled past.

The controls

Stop / Start	Stop freezes the view as well as the recording. Start returns to the live edge.
◀ ▶	move by a quarter of a window
🔍	halve or double the window
Live	appears once the view has left the present; takes you back to it
🗑️	discard the recording
CSV	export the window being shown
PNG	save the plot as a picture
window icon	move the scope into a window of its own, as large as you like

The **mouse wheel zooms**, and **shift with the wheel scrolls**.

Digital signals

A B00L gets a lane of its own along the bottom and is drawn as steps. Analogue signals share the band above, each with its own scale. A bit does not travel through the values between 0 and 1, so drawing a transition as a slope would be a lie about the machine.

Sample ms

This is the **ADS notification cycle**: how often the controller looks at the symbol to see whether it changed. The default is 200 ms, which is also what this tool used to be fixed at without saying so. Lower it to see shorter events.

Two things this number does not promise:

- it is how often the server **looks**, not how often it transmits. The mode is still on change.
- the timestamps are taken when the notification **reaches the PC**. Going down to 10 ms makes the *order* of edges visible, not their *duration* to the millisecond. For faithful timing you need code inside the PLC, which is what TwinCAT Scope is for.

Trigger

The question actually asked of a scope on a machine is not what the last ten minutes looked like, but what happened around the moment something changed.

Pick a plotted signal and a condition, *goes TRUE*, *goes FALSE*, *rises above*, *falls below*, then **Arm**. When it fires, the recording carries on for **half a window** so the aftermath is captured too, and only then does everything hold still with the event in the middle, marked by a line.

Every condition is a crossing and never a state. A signal already TRUE when you arm has not just gone TRUE, so it will not fire; otherwise arming would fire instantly every time and catch nothing.

CSV export

The exported file covers the **window being shown**, not the whole recording, because the slice on screen was framed deliberately.

The layout is one column per signal and one row per instant at which any of them was read. Signals do not change together, so every cell carries the value its signal **was holding** at that instant, which is what the signal actually was and what makes the file plottable in a spreadsheet without further work.

The field separator follows your regional settings: where the decimal mark is a comma, a semicolon separates the fields.

9. Watch sets

Save set writes the symbols you are watching to a JSON file. **Load set** reads one back.

```
{
  "variables": [
    { "path": "MAIN.bEnable", "graph": true },
    { "path": "GVL.rSpeed",    "graph": true },
    { "path": "MAIN.sState",   "graph": false }
  ]
}
```

The format is deliberately flat and meant to be edited by hand. `graph` says whether the symbol also goes on the scope.

Values are not saved. A watch set says what to look at; carrying stale readings in the same file would invite reading them as measurements.

Paths the PLC does not have are collected and reported together with what ADS answered. A set written against another version of the program is exactly when knowing which symbols have gone matters.

10. From the command line

Everything the Backup and Restore tabs do can be asked for without opening the window.

```
TwinCatAdsTool backup <netid> <port> <file>
TwinCatAdsTool restore <netid> <port> <file>
TwinCatAdsTool compare <netid> <port> <file>
TwinCatAdsTool --help
TwinCatAdsTool --version
```

Same executable, same engine as the window. With no arguments it opens the window as usual.

Exit codes

A script has no other way of learning how a run went, so the codes separate the cases a script would treat differently.

0	done, and every variable was processed
1	the command line could not be understood
2	the PLC could not be reached, worth retrying
3	the run finished, but variables failed or were skipped
4	something unexpected went wrong
5	compare only: the PLC and the file differ

3 is the one that matters. An incomplete backup still writes what it managed to read, and a script that only checks whether the file exists would keep it as though it were whole.

Making errorlevel work

The application is a Windows program rather than a console one, so `cmd` moves straight to the next line while it is still running. `start /wait /b` is what makes the exit code readable. In PowerShell the equivalent is `Start-Process -Wait`. Neither is needed for a scheduled task or for `NT_StartProcess` called from the PLC.

A nightly backup

```
for /f "tokens=2 delims==" %d in ('wmic os get localdatetime /value') do set t=%d
start /wait /b TwinCatAdsTool.exe backup 5.24.108.31.1.1 851 D:\backups\plant_%t:~0,8%.json
if errorlevel 3 echo INCOMPLETE BACKUP >> D:\backups\alarm.txt
```

`if errorlevel 3` is true for 3 and anything above it, which is what you want here.

A restore that verifies itself

```
start /wait /b TwinCatAdsTool.exe restore 5.24.108.31.1.1 851 D:\backups\plant.json
start /wait /b TwinCatAdsTool.exe compare 5.24.108.31.1.1 851 D:\backups\plant.json
if errorlevel 1 echo THE PLC DOES NOT MATCH THE FILE
```

The second line is the one worth having.

Started by the PLC

`NT_StartProcess` from the TwinCAT PLC library will run it, which lets the machine take its own backup before it does something risky to itself.

Coming from Beckhoff's Symbol Explorer

`--SnapshotFromPlc`, `--SyncPlcToSnapshot` and `--SyncSnapshotToPlc` are accepted as spellings of `backup`, `backup` and `restore`, so an existing script can be pointed here without being rewritten.

11. Where the files are

Backups go wherever you saved them. The tool suggests `Backup_yyyy-MM-dd-HHmmss.json`.

The log goes to `logs\` beside the executable. If that folder cannot be written, which is normal when the executable sits somewhere protected, it goes to `%LOCALAPPDATA%\TwinCatAdsTool\logs` instead. The window tells you which on startup if there is a problem.

`log.config` beside the executable is optional. Without it the tool configures its own rolling log file. It is there for anyone who wants to change what is logged.

The theme you choose is remembered between runs.

12. When something goes wrong

AdsException: Cannot register Port '0'

The ADS 5.x client library against TwinCAT 4026. This fork uses ADS 7, which serves both 4024 and 4026, so you should not see it here. If you do, you are running an older build.

Connected, but no symbols

The PLC runtime is not started, or you are on the wrong port. Check the ADS state in the connection bar: `Config` means there is no running PLC to read.

The connection never comes up

Almost always the route rather than the network. Check *Router*, *Edit Routes* in the TwinCAT tray icon, and check that the local machine has an AMS net id of its own. A machine without one cannot open an ADS connection at all, and the error it gives does not say so.

A backup says `failed` or `skipped`

Read the report. It names each variable and the ADS error. A common cause is a symbol the PLC declares but will not hand over, for instance one that is write only.

A restore says `does not fit the plc type`

The value in the file cannot be converted into what the PLC declares. Usually a hand edited file, or a file from a version of the program where that variable had a different type.

The restore is slow

The log carries a breakdown:

```
Restore timing: scan 0.04 s, read 0.13 s, plan 1.32 s, prepare 0.00 s,
                transfer 0.39 s for 103234 values in 12 commands
```

`transfer` is set by the **number of commands** far more than by how many values they carry. If you see many commands, values are being split more than they need to be, which happens when a controller refuses a large one and the tool halves and retries. The retries are logged as well.

The scope shows nothing for a signal

Only numeric and boolean types can be plotted. Strings and times are watchable but not plottable.

A watch set will not load some symbols

The message says what ADS answered for each. A path that exists in the tree but not in the flat symbol list, which is normal for anything below an array element, is resolved by asking the server directly, so this is usually a symbol that has genuinely gone from the program.

13. What is verified, and what is not

Verified on a real installation: connection on TwinCAT 4026 with ADS 7; a backup of 71 variables in 0.1 s; a restore of 10,978 leaves in which every leaf was given a distinct value, written, read back and compared one by one, with **10,978 out of 10,978 correct**; nested branches, arrays of structures, arrays inside structures inside arrays, strings, REALs, BOOLs, TIME, LTIME and DT. Backup and restore from the command line against a running controller.

Verified by test: 154 unit tests on every build.

Not verified: multidimensional arrays, `ARRAY[0..n,0..m]`, which the installation used for the verification does not contain. The write path addresses elements by position and can no longer raise a dimension mismatch, but whether the flattened form in the file lines up with the order of the child symbols has not been measured. Also unverified: the accuracy of scope timings below roughly ten milliseconds, and `compare` from the command line against a plant.

If you have a machine with multidimensional persistent arrays, a restore on it is the single most useful thing anyone could report.