ElecLab Display Firmware Update Guide

Prepare:

Windows PC


Tweezers

HDMI display

USB Type-c cable and HDMI cable

1. Download the upgrade tools and firmware from github

https://github.com/eleclab-rpi/Display Firmware



2. Unzip Artery_ISP_Programmer_V2.0.11.zip


Artery ISP Programmer V2.0.11

Artery DFU DriverInstall

Document

RH ISP Programmer.pdf


3. Install Artery_DFU_DriverInstall.exe






4. The display MCU enters download mode

- 1. Power off display
- 2. Use tweezers to short the MCU BOOT0 pin to 3.3V
- 3. Use a USB Type-c cable to connect the 5V+Touch port of the display to the PC







5. Run ArterylSPProgrammer.exe







