
# ElecLab Display Firmware Update Guide

### Items to prepare:

- Windows PC
- LT1605\_I2C2SPI\_V2\_100k.exe(From LT6911\_download\_tool.rar)
- USB to IIC board(CH341), For example:




- XH2.54 3P cable
- MX1.27 3P programming probe (can be made using MX1.27\_Probe\_3P\_Gerber file)



- ElecLab 7.84"/8.8"/10.1"/10.3" (LT6911C)HDMI display
- USB Type-c cable

### 1. Download the upgrade tools and firmware from github


https://github.com/eleclab-rpi/Display\_Firmware/tree/main/HDMI\_101\_2560x1600



## 2. Unzip LT6911\_download\_tool.rar




#### 3. Install CH341 i2c driver.exe



### 4. Preparation

- 1. Power the display using the USB Type-c cable
- 2. Connect CH341 USB2IIC board to PC
- 3. Use a probe or directly solder a 3P cable to the 3P MX1.27 test point of the LT6911C.





#### 5. Open LT1605\_I2C2SPI\_V2\_100k.exe on PC.

