

A10 CPU供电脚标注

- PP_CPU_VAR
- PP_SOC_VAR
- PP0V9_SOC_FIXED
- PP1V8
- PP1V1
- PP1V1_SDRAM
- PP1V8_SDRAM
- PP_GPU_VAR
- PP_GPU_SRAM_VAR
- PP_CPU_SRAM_VAR
- PP0V8_AOP
- PP1V2_SOC
- PP1V2_REF

