

上天线接口

0	
0	0
361	0
474	310
474	371
0	361
0	257
0	

JUAT1

面部识别-发射
(点阵投影机)

451	
280	283
463	283
468	340
0	528
357	655
340	627
280	284
457	

J4500

开机和闪光灯接口

0	
0	572
644	354
644	354
597	631
0L	0L
700	539
572	570
570	

J4300

后置广角摄像头

0	
573	0
631	0
631	385
547	0
235	0L
0L	0L
362	0
508	0L
343	0L
343	0
0L	0L
565	0L
0	0
564	

J3900

后置长焦摄像头

540	
0	631
0	631
235	0
629	0
0L	385
362	0L
0	0L
342	0
342	0L
501	0L
0L	0
626	0L
0	0L
625	

J4000

听筒感光感距

0	
641	643
358	599
0	526
0	419
0	341
0	341
0	358
443	450
456	450
0	400
698	699
545	545
545	545
394	395
545	

J4600

面部识别-接收
(红外线相机镜头)

535	
0	523
420	0L
420	626
0	0
439	233
439	362
0	341
439	341
439	370
0	

J4530

前置相机

559	
0	0
420	341
420	341
0	233
439	0
439	626
0	360
439	0L
439	368
0	

J4200

侧边键、无线充电

695	
0L	0
695	357
695	341
0L	341
434	

J3500

电池

0	
0	633
0	361
650	361
0	

J3200

下天线接口

0	
255	0L
308	0
0	357
0	359
0L	484
0	482
481	0
481	0
0	

JLAT1

触控

0	
359	359
359	359
358	357
567	597
369	357
359	357
357	663
0	0
0L	648
0	0L
680	610
353	331
353	593
655	608
0	

J5800

尾插

545	
545	0
682	427
682	427
0	0
597	427
0L	438
647	0
647	343
0L	38
0L	702
0L	255
0L	387
0	348
646	348
647	384
0L	369
593	349
352	345
352	544
0	544
682	544
682	544
965	

J6400

显示屏接口

294	
234	294
655	299
357	0L
0L	618
675	0L
0L	443
0L	0L
0L	363
0	0L
322	360
322	0
0	0
322	325
322	325
0	0
322	325
322	325
0	

J5700

测量设备
福禄克
15B

Measuring equipment: fluke 15B