


### SDM439 GPIO Configuration For QRD439+PMI632

|         |                  |         |                  |          |                     |
|---------|------------------|---------|------------------|----------|---------------------|
| GPIO_0  | NFC_SPI_ESE_MOSI | GPIO_41 |                  | GPIO_82  | FM_DATA             |
| GPIO_1  | NFC_SPI_ESE_MISO | GPIO_42 | ACCL_INT1        | GPIO_83  | BT_CTL              |
| GPIO_2  | NFC_SPI_CS_N_0   | GPIO_43 | ALSP_INT_N       | GPIO_84  | BT_DATA             |
| GPIO_3  | NFC_SPI_ESE_CLK  | GPIO_44 | MAG_DRDY_INT     | GPIO_85  | FP_SPI_MOSI         |
| GPIO_4  | QUP_UART_TX_2    | GPIO_45 | GYRO_INT         | GPIO_86  | FP_SPI_MISO         |
| GPIO_5  | QUP_UART_RX_2    | GPIO_46 |                  | GPIO_87  | FP_SPI_CS           |
| GPIO_6  | WSA_SMB_I2C_SDA  | GPIO_47 | SENSOR_SPI_CS2_N | GPIO_88  | FP_SPI_CLK          |
| GPIO_7  | WSA_SMB_I2C_SCL  | GPIO_48 | FP_INT_N1        | GPIO_89  |                     |
| GPIO_8  | TP_SPI_MOSI      | GPIO_49 | UIM_BATT_ALARM   | GPIO_90  |                     |
| GPIO_9  | TP_SPI_MISO      | GPIO_50 |                  | GPIO_91  | KEY_VOL_UP_N        |
| GPIO_10 | TP_SPI_CS_SDA    | GPIO_51 | UIM1_DATA        | GPIO_92  |                     |
| GPIO_11 | TP_SPI_CLK_SCL   | GPIO_52 | UIM1_CLK         | GPIO_93  | NFC_ESE_PWR_REQ     |
| GPIO_12 | WSA_INTR         | GPIO_53 | UIM1_RESET       | GPIO_94  | WSA_IO_DATA         |
| GPIO_13 | LCD_ID           | GPIO_54 | UIM1_PRESENT     | GPIO_95  | WSA_IO_CLK          |
| GPIO_14 | SENSOR_I2C_SDA   | GPIO_55 | UIM2_DATA        | GPIO_96  | WSA_EN              |
| GPIO_15 | SENSOR_I2C_SCL   | GPIO_56 | UIM2_CLK         | GPIO_97  | HomeKey_FP_INT      |
| GPIO_16 | NFC_DISABLE      | GPIO_57 | UIM2_RESET       | GPIO_98  |                     |
| GPIO_17 | NFC_IRQ          | GPIO_58 | UIM2_PRESENT     | GPIO_99  |                     |
| GPIO_18 | NFC_I2C_SDA      | GPIO_59 |                  | GPIO_100 | RFFE1_CLK           |
| GPIO_19 | NFC_I2C_SCL      | GPIO_60 | LCD0_RESET_N     | GPIO_101 | RFFE1_DATA          |
| GPIO_20 | SENSOR_SPI_MOSI  | GPIO_61 | SMB_INT          | GPIO_102 | RFFE2_CLK           |
| GPIO_21 | SENSOR_SPI_MISO  | GPIO_62 |                  | GPIO_103 | RFFE2_DATA          |
| GPIO_22 | SENSOR_SPI_CS0_N | GPIO_63 |                  | GPIO_104 |                     |
| GPIO_23 | SENSOR_SPI_CLK   | GPIO_64 | TP_RST_N         | GPIO_105 |                     |
| GPIO_24 | LCD_TE0          | GPIO_65 | TP_INT_N         | GPIO_106 |                     |
| GPIO_25 | WSA_MCLK         | GPIO_66 |                  | GPIO_107 | GRFC3_SEL           |
| GPIO_26 | CAM_MCLK0        | GPIO_67 | SDCARD_DET_N     | GPIO_108 |                     |
| GPIO_27 | CAM_MCLK1        | GPIO_68 |                  | GPIO_109 | GRFC5_SEL           |
| GPIO_28 |                  | GPIO_69 | CDC_PDM_CLK      | GPIO_110 | GRFC6_SEL           |
| GPIO_29 | CAM_I2C_SDA0     | GPIO_70 | CDC_PDM_SYNC     | GPIO_111 | GRFC7_SEL           |
| GPIO_30 | CAM_I2C_SCL0     | GPIO_71 | CDC_PDM_TX       | GPIO_112 | GRFC8_SEL           |
| GPIO_31 | CAM_I2C_SDA1     | GPIO_72 | CDC_PDM_RX0      | GPIO_113 | GRFC9_SEL           |
| GPIO_32 | CAM_I2C_SCL1     | GPIO_73 | CDC_PDM_RX1      | GPIO_114 | GRFC10_SEL          |
| GPIO_33 |                  | GPIO_74 | CDC_PDM_RX2      | GPIO_115 |                     |
| GPIO_34 | FLASH_STROBE_NOW | GPIO_75 | BT_SSBI          | GPIO_116 |                     |
| GPIO_35 | CAM_AVDD_LDO_EN  | GPIO_76 | WL_CMD_DATA_2    | GPIO_117 |                     |
| GPIO_36 | MCAM_RST_N       | GPIO_77 | WL_CMD_DATA_1    | GPIO_118 | EXT_GPS_LNA_EN      |
| GPIO_37 | FORCE_USB_BOOT   | GPIO_78 | WL_CMD_DATA_0    | GPIO_119 | CH0_GSM_TX_PHASE_D0 |
| GPIO_38 | SCAM_RST_N       | GPIO_79 | WL_CMD_SET       | GPIO_120 | RFFE5_CLK           |
| GPIO_39 |                  | GPIO_80 | WL_CMD_CLK       | GPIO_121 | RFFE5_DATA          |
| GPIO_40 |                  | GPIO_81 | FM_SSBI          | GPIO_122 |                     |



|          |             |  |  |
|----------|-------------|--|--|
| GPIO_123 |             |  |  |
| GPIO_124 | FP_RESET    |  |  |
| GPIO_125 |             |  |  |
| GPIO_126 |             |  |  |
| GPIO_127 |             |  |  |
| GPIO_128 |             |  |  |
| GPIO_129 |             |  |  |
| GPIO_130 | NFC_DWL_REQ |  |  |
| GPIO_131 |             |  |  |
| GPIO_132 | RCM_MARKER1 |  |  |
| GPIO_133 | RCM_MARKER2 |  |  |

**PMI632 GPIO/MPP Configuration**

|        |                     |        |                  |
|--------|---------------------|--------|------------------|
| GPIO_1 | CONNECTOR_THERMAL   | GPIO_5 | FLASH_STROBE_NOW |
| GPIO_2 | SMB_PARALLEL_CHG_EN | GPIO_6 | NEBULA_PWM       |
| GPIO_3 | SKIN_THEREMAL       | GPIO_7 | SMB_VCHG_P       |
| GPIO_4 | SMB_THEREMAL        | GPIO_8 | SMB_VCHG_M       |

**PM439 GPIO/MPP Configuration**


|        |                |       |                      |
|--------|----------------|-------|----------------------|
| GPIO_1 |                | MPP_1 | VDD_FX_BIAS_MPP_1    |
| GPIO_2 | NFC_CLK_REQ    |       |                      |
| GPIO_3 | UIM_BATT_ALARM | MPP_3 | VREF_DAC_MPP_3       |
| GPIO_4 | WLLED_EN       | MPP_4 | QUIET_THERM_TP_LED_K |
| GPIO_5 |                |       |                      |
| GPIO_6 |                |       |                      |
| GPIO_7 |                |       |                      |
| GPIO_8 | LCM_BL_PWM     |       |                      |







## SDM439 EBI


SDM439










































| 厂家  | 12C 86AD | 12C 86C7E | 080508 12 |
|-----|----------|-----------|-----------|
| 后装微 | 08 21    | 08 20     | 080502    |
| 后装微 | 08 21    | 08 20     | 080506    |
|     |          |           |           |
|     |          |           | 030217    |







| 厂家  | 12C 86AD | 12C 86C7E | 080508 12 |
|-----|----------|-----------|-----------|
| 后装微 | 08 21    | 08 20     | 080502    |
| 后装微 | 08 21    | 08 20     | 080506    |
|     |          |           |           |
|     |          |           | 030217    |



| 厂家  | 12C 86AD | 12C 86C7E | 080508 12 |
|-----|----------|-----------|-----------|
| 后装微 | 08 21    | 08 20     | 080502    |
| 后装微 | 08 21    | 08 20     | 080506    |
|     |          |           |           |
|     |          |           | 030217    |




### Rear Camera Flash FH15B




|     |     |     |     |
|-----|-----|-----|-----|
| Rev | 001 | Rev | 001 |
| Doc | 001 | Doc | 001 |
| Rev | 001 | Rev | 001 |
| Doc | 001 | Doc | 001 |

AUDIO PA

|                |              |
|----------------|--------------|
| 厂家             | 11C A00800   |
| AWR1519 A00800 | 0008-0011000 |




American Standard EARPPHONE




Note: Place B2000,B2002,C2005,C2014 close to headset jack connector

RECEIVER




MIC -- Sub



Note: Place B2000,B2002,C2005,C2014 close to headset jack connector


## E-compass

| 厂家     | 12C A03662  |
|--------|-------------|
| A03662 | 076-0001100 |




## A sensor

| 厂家     | 12C A03662  |             |
|--------|-------------|-------------|
| A03662 | 076-0001100 | 076-0001100 |
| A03662 | 076-0001100 | 076-0001100 |




## ALS PS LTR2568


| 厂家             | 12C A03662  |
|----------------|-------------|
| LTR-2568ALS-00 | 063-0001100 |



## Finger Print




## IR







OVP 6.8V ET9552L  
OVP 10.5V ET9552



#### MAIN FPC BTB




#### KEY BTB




| Signal       | Description |
|--------------|-------------|
| KEY_VOL_UP_N | Volume Up   |
| FM_RESET_N   | Volume Down |
| KYPD_FWR_N   | Power On    |
| KEY_AI       | XIAOMI AI   |

#### Battery Connector



VBAT TEST POINT



USB TEST POINT




KEY TEST point




UART TEST point












Force USB boot

















## DPDT SWITCH



## SAR Sensor



DIV ANT

