

A10 CPU供电脚标注

-  PP_CPU_VAR
-  PP_SOC_VAR
-  PP0V9_SOC_FIXED
-  PP1V8
-  PP1V1
-  PP1V1_SDRAM
-  PP1V8_SDRAM
-  PP_GPU_VAR
-  PP_GPU_SRAM_VAR
-  PP_CPU_SRAM_VAR
-  PP0V8_AOP
-  PP1V2_SOC
-  PP1V2_REF

