



8. Level 3 Repair

8-1. Components Layout

MAIN PBA (TOP SIDE)




MAIN PBA (BOTTOM SIDE)






8. Level 3 Repair

SUB PBA (TOP SIDE)



SUB PBA (BOTTOM SIDE)





WLAN 2.4G : Tx 2412~2472 MHz
BT/BLE : Tx 2402 ~ 2480 MHz
GNSS : Rx 1592 ~ 1606 MHz
FM receiver : 88 ~ 108 MHz
GSM850 : Tx 824 ~ 849 MHz / Rx 840 ~ 845 MHz
GSM1900 : Tx 1850 ~ 1910 MHz / Rx 1930 ~ 1990 MHz
WCDMA850 : Tx 824 ~ 849 MHz / Rx 840 ~ 845 MHz
LTE B5 : Tx 824 ~ 849 MHz / Rx 840 ~ 845 MHz
LTE B41 : Tx 2496 ~ 2690 MHz

SM-A127F

SIM5001

SIM5002

SIM5000

SIM5003

SC7000

UCP4000

UME5000

SOC7001

SOC7002

SIDE_ETCHING

INT16001

INT16000

CON1001

CON7000

CON1002

INT16003

INT16004

INT16005

INT16006

INT16007

INT16008

INT16009

INT16010

INT16011

INT16012

INT16013

INT16014

INT16015

INT16016

INT16017

INT16018

INT16019

INT16020

INT16021

INT16022

INT16023

INT16024

INT16025

INT16026

INT16027

INT16028

INT16029

INT16030

INT16031

INT16032

INT16033

INT16034

INT16035

INT16036

INT16037

INT16038

INT16039

INT16040

INT16041

INT16042

INT16043

INT16044

INT16045

INT16046

INT16047

INT16048

INT16049

INT16050

INT16051

INT16052

INT16053

INT16054

INT16055

INT16056

INT16057

INT16058

INT16059

INT16060

INT16061

INT16062

INT16063

INT16064

INT16065

INT16066

INT16067

INT16068

INT16069

INT16070

INT16071

INT16072

INT16073

INT16074

INT16075

INT16076

INT16077

INT16078

INT16079

INT16080

INT16081

INT16082

INT16083

INT16084

INT16085

INT16086

INT16087

INT16088

INT16089

INT16090

INT16091

INT16092

INT16093

INT16094

INT16095

INT16096

INT16097

INT16098

INT16099

INT16100

INT16101

INT16102

INT16103

INT16104

INT16105

INT16106

INT16107

INT16108

INT16109

INT16110

INT16111

INT16112

INT16113

INT16114

INT16115

INT16116

INT16117

INT16118

INT16119

INT16120

INT16121

INT16122

INT16123

INT16124

INT16125

INT16126

INT16127

INT16128

INT16129

INT16130

INT16131

INT16132

INT16133

INT16134

INT16135

INT16136

INT16137

INT16138

INT16139

INT16140

INT16141

INT16142

INT16143

INT16144

INT16145

INT16146

INT16147

INT16148

INT16149

INT16150

INT16151

INT16152

INT16153

INT16154

INT16155

INT16156

INT16157

INT16158

INT16159

INT16160

INT16161

INT16162

INT16163

INT16164

INT16165

INT16166

INT16167

INT16168

INT16169

INT16170

INT16171

INT16172

INT16173

INT16174

INT16175

INT16176

INT16177

INT16178

INT16179

INT16180

INT16181

INT16182

INT16183

INT16184

INT16185

INT16186

INT16187

INT16188

INT16189

INT16190

INT16191

INT16192

INT16193

INT16194

INT16195

INT16196

INT16197

INT16198

INT16199

INT16200

INT16201

INT16202

INT16203

INT16204

INT16205

INT16206

INT16207

INT16208

INT16209

INT16210

INT16211

INT16212

INT16213

INT16214

INT16215

INT16216

INT16217

INT16218

INT16219

INT16220

INT16221

INT16222

INT16223

INT16224

INT16225

INT16226

INT16227

INT16228

INT16229

INT16230

INT16231

INT16232

INT16233

INT16234

INT16235

INT16236

INT16237

INT16238

INT16239

INT16240

INT16241

INT16242

INT16243

INT16244

INT16245

INT16246

INT16247

INT16248

INT16249

INT16250

INT16251

INT16252

INT16253

INT16254

INT16255

INT16256

INT16257

INT16258

INT16259

INT16260

INT16261

INT16262

INT16263

INT16264

INT16265

INT16266

INT16267

INT16268

INT16269

INT16270

INT16271

INT16272

INT16273

INT16274

INT16275

INT16276

INT16277

INT16278

INT16279

INT16280

INT16281

INT16282

INT16283

INT16284

INT16285

INT16286

INT16287

INT16288

INT16289

INT1

SM-A127F

SOC7003

SOC7004

SOC7000

U5000

SC7002

U1000

U2005

U3001

U1005

PAM1000

SC7001

SOC6000

SOC5000

HDC4000

SOC3000

RFS1000

ANT100

ANT101

CON1000

SIDE ETCHING

LED5000

CON7001

1
1
1

SM-A127M

SIM5001

SIM5002

SIM5000

SIM5003

SC7000

UCP4000

UME5000

SOC7001

SOC7002

CON7000

CON7002


BOTH7000


PNT7004

PNT7002

PNT7003


SIDE_ETCHING





8. Level 3 Repair

8-3. Flow chart of Troubleshooting.




Oscilloscope




Digital Multimeter



Power Supply



+ driver, ESD Safe Tweezer




8960 & Spectrum Analyzer



Soldering iron


8. Level 3 Repair

8-4-1. Power On




8. Level 3 Repair

8-4-2. Initial




8. Level 3 Repair

8-4-3. No Service




8. Level 3 Repair

8-4-4. SIM Part




8. Level 3 Repair

8-4-5. T-Flash Part




8. Level 3 Repair

8-4-6. Cable Charging Part (15W)




8. Level 3 Repair

8-4-7. OTG




8. Level 3 Repair

8-4-8-1. Grip Sensor




8. Level 3 Repair

8-4-8-2. Accelerometer Sensor




8. Level 3 Repair

8-4-8-3. Fingerprint Sensor




8. Level 3 Repair

8-4-9-1. Microphone Part – MAIN MIC




8. Level 3 Repair

8-4-9-2. Microphone Part – 2nd MIC




8. Level 3 Repair

8-4-10. Speaker Part




8. Level 3 Repair

8-4-11. Receiver Part




8. Level 3 Repair

8-4-12. Display




8. Level 3 Repair

8-4-13. Quad Camera




8. Level 3 Repair

8-4-14. FRONT CAMERA




8. Level 3 Repair

8-4-15. TSP




8. Level 3 Repair

8-4-16. Motor




8. Level 3 Repair

8-4-17. BT/WIFI




8. Level 3 Repair

8-7-18. GPS




8. Level 3 Repair

8-4-19. NFC




8. Level 3 Repair

8-4-20. FM radio part




8. Level 3 Repair

8-4-21. GSM 850/900/DCS/PCS, WCDMA B1/2/4/5/8, LTE 1/2/3/4/5/7/8/12/17/20/26/28/66 PRx




8. Level 3 Repair

8-4-22. LTE 7/38/40/41 PRx




8. Level 3 Repair

8-4-23. WCDMA B1/2/4/5/8, LTE B1/2/3/4/5/7/8/12/17/20/28/38/40/41/66 DRx



8. Level 3 Repair

8-4-24. GSM 850/900/DCS/PCS, WCDMA B1/2/3/5/8, LTE 1/2/3/4/5/8/12/17/20/26/28/66 Tx



8. Level 3 Repair

8-4-25. LTE B7/38/40/41 Tx

