

The logo consists of the lowercase letters 'mae' in white, set against a solid blue rounded square background.

ADVANCED GEOPHYSICS INSTRUMENTS
WWW.MAE-SRL.IT

USER HANDBOOK

DataLogger Live Dashboard

Complete User Guide — Monitor v2

VMR624

DL8 / DL4 / DL16

DOCUMENT TYPE

User Handbook

VERSION

Monitor v2

LANGUAGE

English

PLATFORM

Web — All Browsers

DASHBOARD URL

[maeservice.it/beta](https://www.maeservice.it/beta)

YEAR

2026

CONTENTS

Table of Contents

1	General Information	3
1.1	Introduction	3
1.2	Intended Use	3
1.3	Safety & Icons	3
2	Getting Started — Access & Login	4
2.1	System Requirements	4
2.2	Login Procedure	4
2.3	Logout	4
3	Works Page	5
3.1	Selecting a Work / Project	5
3.2	Work Status & Summary Panel	5
4	Dashboard Layout Overview	6
4.1	Top Navigation Bar	6
4.2	Left Sidebar	6
4.3	Main Content Area	7
5	Period, Channel & Interval Filters	8
6	Main Chart	9
6.1	Single Channel View	9
6.2	All Channels Overlay View	9
6.3	Interactive Features	9
7	Live Mode & Auto-Refresh	10
8	Device Management	11
8.1	Device List & Status LED	11
8.2	Device Information Card	11
9	KPI Cards & Statistics	12
10	Secondary Charts & Measurement Table	13

11	Alerts & Threshold Settings	14
12	Export & File Download	15
12.1	CSV Export	15
12.2	JSON Export	15
12.3	Print / PDF Report	15
12.4	Device File Download	16
13	Map & Device Location	17
14	Power Supply Monitor	18
15	Device Types & Channel Reference	19
15.1	VMR624 — Vibration Monitor	19
15.2	DL Series — Displacement Logger	19
16	Language & Theme Settings	20
17	Troubleshooting	21

01 CHAPTER ONE

General Information

1.1 Introduction

The **MAE DataLogger Live Dashboard** is a web-based real-time monitoring platform designed for geophysical datalogger devices manufactured by MAE s.r.l. The dashboard provides live access to measurement data transmitted by field instruments including vibration monitors (VMR624) and displacement loggers (DL series).

The system allows operators and technical personnel to view, analyse and export measurement data from any device with a modern web browser, without installing any local software. Data is retrieved securely from the MAE cloud API and displayed in an interactive, responsive interface accessible from desktop computers, tablets, and mobile devices.

LIVE DASHBOARD URL

The dashboard is accessible at: <https://www.maeservice.it/beta/>
An active account with valid credentials provided by MAE is required to access the system.

1.2 Intended Use

This software is designed to be used by qualified technical operators who have been trained by MAE or an authorised representative. The platform is intended for:

- Real-time monitoring of field measurement devices
- Visualisation and analysis of recorded geophysical data
- Configuration of alert thresholds and notification settings
- Export and archiving of measurement data in standard formats
- Remote supervision of multi-device monitoring sites

ATTENTION

Any use of the dashboard for purposes other than those described above is considered improper use. MAE s.r.l. assumes no liability for damages resulting from unauthorised or improper use of this software. The technical operator is solely responsible for the correctness and interpretation of the data produced.

1.3 Icons Used in This Handbook

Icon / Label	Meaning
NOTE	Informational note — read carefully to understand correct operation.
ATTENTION	Warning message regarding safety or correct configuration of the system.

Icon / Label	Meaning
IMPORTANT	Critical instruction — failure to follow may result in data loss or system error.
TIP	Useful hint to improve efficiency or user experience.

02

CHAPTER TWO

Getting Started — Access & Login

2.1 System Requirements

Requirement	Specification
Browser	Google Chrome 90+, Mozilla Firefox 88+, Microsoft Edge 90+, Safari 14+
Internet Connection	Required — the dashboard communicates with the MAE cloud API
Screen Resolution	Minimum 1024 × 768 px; recommended 1440 × 900 px or higher
Mobile / Tablet	Fully supported — responsive layout adapts to all screen sizes
Local Software	None required — fully browser-based application
Credentials	Username and password provided by MAE s.r.l.

2.2 Login Procedure

1 Open the Dashboard

Navigate to <https://www.maeservice.it/beta/> in your browser. You will be directed to the Works page with the login form visible.

2 Enter Credentials

Enter your **Username** in the first field. Press `Tab` or `Enter` to move to the **Password** field and enter your password.

3 Sign In

Click the **Sign In** button or press `Enter`. Your credentials are verified securely against the MAE authentication server.

4 Session Saved

On successful login, your session token is stored locally in the browser. You will remain logged in across page refreshes until you explicitly log out.

NOTE — PASSWORD SECURITY

Your credentials are transmitted securely to the MAE authentication server. Session tokens are stored in the browser and are cleared upon logout.

2.3 Logout

To log out, click the **Logout** button located in the top-right area of the navigation bar (visible as a door/exit icon). Logging out clears the session token and all stored credentials from the browser. You will be redirected to the login page.

ATTENTION — SHARED COMPUTERS

Always log out when using the dashboard on a shared or public computer. Closing the browser tab without logging out does **not** clear your session; use the Logout button explicitly.

03

CHAPTER THREE

Works Page

The **Works Page** is the entry point of the dashboard after logging in. It presents all monitoring sites (works/projects) associated with your account. A work represents a specific deployment site, such as a construction project, geological survey, or monitoring campaign.

3.1 Selecting a Work / Project

- 1

Browse Available Works

All works linked to your account are displayed as cards in a grid layout. Each card shows the work name, location, number of devices, and active/inactive status.
- 2

Search or Filter

Use the **search bar** at the top to find a work by name or location. Use the filter chips (**All**, **Active**, **Inactive**) to narrow the list by status.
- 3

Open the Dashboard

Click the **Open Dashboard** button on the desired work card. The dashboard loads with all devices associated with that work.

3.2 Work Status & Summary Panel

At the top of the Works page, a **Summary Panel** displays aggregated statistics across all your works:

Indicator	Description
Active	Number of works currently in active monitoring status
Inactive	Number of works that are inactive or suspended
Total	Total number of works in your account
Devices	Total number of devices across all works

Each work card includes an LED indicator: **green** = at least one device connected recently, **orange** = devices connected but not recently, **grey** = no devices or no recent connection.

04

CHAPTER FOUR

Dashboard Layout Overview

The main dashboard is divided into three principal areas: the **top navigation bar**, the **left sidebar**, and the **main content area**. Understanding this layout is essential for efficient operation.

4.1 Top Navigation Bar

The top bar spans the full width of the screen and contains controls that apply globally to the current session:

Control	Function
MAE Logo / Brand	Displays the application name "DataLogger — MONITOR v2" and the active work subtitle (work name, location, device count).
Period From / To	Date range selector. Defines the start and end dates for data retrieval. Changing these dates pauses Live Mode.
Apply Button	Applies the selected date range and reloads data from the API for the chosen period.
Channel Selector	Drop-down to select which measurement channel to display in the main chart. Options depend on the connected device type.
Interval Selector	Quick filter: All, Last 1h, Last 3h, Last 6h, Last 12h, Last 24h. Filters the loaded dataset without re-querying the API.
Live / Paused Pill	Status indicator. LIVE (green) = auto-refreshing every 120 s. PAUSED (orange) = manual mode, click to resume live.
Refresh Countdown	Shows the seconds remaining until the next automatic data refresh. Click to force an immediate refresh.
Language Toggle	Switch the interface language between EN (English) and IT (Italian).
Theme Toggle	Switch between Dark and Light visual themes.
Alerts Button	Opens the active alerts panel. A red badge shows the number of unacknowledged alerts.
Export Button	Opens the export modal with options for CSV, JSON, Print/PDF, and raw file download.
Logout Button	Logs out the current user and returns to the login page.

4.2 Left Sidebar

The sidebar is fixed on the left side and contains navigation links and the device list for the active work:

NAVIGATION

- Works** — Return to the Works selection page
- Alerts** — Open the alerts panel (shows badge count when active)
- Export** — Open the export modal

DEVICE LIST

- Lists all devices in the active work
- Shows connection status LED for each device
- Shows device type, position name, and serial number
- Click any device to switch to it and reload its data

4.3 Main Content Area

The main content area is divided into several zones, displayed from top to bottom:

Zone	Content
Alert Banner	Appears automatically when threshold violations are detected. Dismissible per alert.
KPI Cards	One card per measurement channel showing the latest value, unit, and status colour.
Main Chart	Interactive time-series chart for the selected channel (or all channels in overlay mode).
Secondary Mini-Charts	Compact charts for all non-primary channels, shown simultaneously for comparison.
Measurement Log Table	Tabular view of all records in the current filtered dataset.
Device Info Card	Technical details of the active device: battery, signal, GPS, last connection, IP, memory.

05

CHAPTER FIVE

Period, Channel & Interval Filters

Date Range (Period)

The **From** and **To** date fields in the top bar define the period for which measurement records are requested from the API. Data is fetched up to a maximum of **150 records** per request for the selected period.

- By default, both dates are set to **today** (or the date of the device's last diagnostic).
- Changing either date field automatically **pauses Live Mode**.
- After adjusting the dates, click **Apply** to load data for the new range.
- To return to live mode, click the **PAUSED** status pill — this resets dates to today and resumes auto-refresh.

NOTE — DATA LIMIT

The API returns a maximum of **150 records** per query. For periods with very high-frequency data, only the most recent 150 samples within the period will be displayed. Use the Export feature to retrieve full datasets.

Channel Selector

The **Channel** drop-down selects which measurement channel to display in the main chart. Available options depend on the connected device type:

- For **VMR624**: Displacement (mm), Frequency (Hz), Temperature (°C), Voltage (V)
- For **DL Series**: PT-50 fs1 (mm), ISBC-10 X, ISBC-10 Y (gr)
- The last option **"All Channels"** activates the overlay chart mode showing all channels simultaneously.

Interval Quick-Filter

The **Interval** drop-down provides a quick way to zoom into a recent time window *within the already-loaded dataset*, without re-querying the API:

Option	Effect
All	Display all records loaded for the selected date range
Last 1 hour	Show only records from the last 60 minutes
Last 3 hours	Show only records from the last 3 hours
Last 6 hours	Show only records from the last 6 hours
Last 12 hours	Show only records from the last 12 hours
Last 24 hours	Show only records from the last 24 hours

Changing the interval updates the chart and table immediately using the already-loaded data. No API call is triggered.

06 CHAPTER SIX Main Chart

The main chart is the centrepiece of the dashboard. It renders a smooth time-series plot of the selected measurement channel, providing maximum clarity at all screen sizes and zoom levels.

6.1 Single Channel View

When a single channel is selected from the Channel drop-down, the chart displays:

- A smooth **bezier curve** connecting all data points, with a gradient fill below the line
- **Y-axis labels** (left side) showing minimum, midpoint, and maximum values
- **X-axis labels** (bottom) showing evenly-spaced time markers aligned precisely with data point positions
- Subtle **horizontal grid lines** for reading values
- A **stats bar** below the chart displaying: MIN, MAX, AVG, RANGE, and SAMPLES count
- Chart title and measurement unit badge in the header

6.2 All Channels Overlay View

Select "**All Channels**" from the Channel drop-down to activate overlay mode. All measurement channels are drawn on the same chart with each channel normalised to a 0–100% scale for visual comparison:

- Each channel is drawn in its own colour with a distinct line style
- A colour-coded **legend** is displayed in the stats area below the chart, showing each channel's name, colour, and min–max range
- The Y-axis shows normalised percentages (0%, 50%, 100%)
- Hover tooltips show all channel values simultaneously

NOTE

In All Channels mode, Y-axis zoom is disabled. Switch to a single channel view to use the zoom feature.

6.3 Interactive Features

HOVER TOOLTIP

Move the mouse cursor over the chart area to see a tooltip showing the **date**, **time**, and **exact value** at the nearest data point. A vertical indicator line follows the cursor.

Y-AXIS ZOOM

Scroll up with the mouse wheel to zoom in on the Y axis (magnify the value range). **Scroll down** to zoom out. Zoom range: 0.05× to 10×. The hint text "*scroll to zoom*" is shown in the chart corner.

RESET ZOOM

Double-click anywhere on the chart to reset the Y-axis zoom to the default (1×). The hint changes to "🔄 *dblclick to reset*" when zoom is active.

STATS SUMMARY

Below the chart, five statistics are always visible for the current view: **MIN**, **MAX** (highlighted in channel colour), **AVG**, **RANGE**, and **SAMPLES** (total record count).

07

CHAPTER SEVEN

Live Mode & Auto-Refresh

The Live Mode feature enables the dashboard to automatically refresh measurement data at a fixed interval, simulating real-time monitoring of active devices.

Behaviour Overview

State	Behaviour
LIVE	Data is refreshed every 120 seconds . The countdown timer counts down from 120 and resets after each refresh. The date range is locked to today.
PAUSED	No automatic refresh. The operator controls when data is reloaded using the Apply button or by resuming Live Mode.

Automatic State Detection

When the dashboard loads or when switching between devices, the system automatically determines whether Live Mode should be active:

- If the device's **last diagnostic timestamp** is today's date → Live Mode is activated automatically
- If the last diagnostic is from a **previous date** → Live Mode is paused; the date range is set to the date of the last recorded data
- If the device has **no data** for the current period → an error message is shown and Live Mode remains off

Manual Control

- 1 Pause Live Mode**
Change the date range using the date pickers and click **Apply**. Live Mode pauses automatically when a custom date range is applied.
- 2 Resume Live Mode**
Click the **PAUSED** status pill. The dates reset to today, data is immediately refreshed, and the 120-second countdown restarts.
- 3 Force Immediate Refresh**
Click the countdown timer button at any time to trigger an immediate data refresh without waiting for the countdown to reach zero.

TIP

The auto-refresh interval is 120 seconds. If you need data more frequently, use the manual force-refresh by clicking the countdown button. For historical analysis, pause Live Mode and use the date range selector.

08

CHAPTER EIGHT

Device Management

8.1 Device List & Status LED

All devices associated with the active work are listed in the left sidebar. Each device entry shows:

- A **coloured status LED** indicating connection freshness
- The **device type** (e.g., VMR624, DL8)
- The **position/location name** (e.g., "PULVINO C13/C14")
- The **serial number**

LED Colour	Meaning	Time Since Last Connection
 Green	Online — recently connected	Within the last 15 minutes
 Orange	Warning — not connected recently	15 to 30 minutes ago
 Red	Offline — no recent connection	More than 30 minutes ago
 Grey	Unknown — no connection timestamp	No data available

Click on any device entry to **switch the active device**. The dashboard reloads all data for the selected device, applying the current date range. The previously active device entry is highlighted with a blue background.

ATTENTION — DEVICE SWITCH

When switching between devices, all previously displayed data is cleared immediately to prevent stale data from being shown. The new device's data is fetched from the API before the chart and table are updated.

8.2 Device Information Card

The Device Information Card is displayed in the main content area and shows the technical details of the currently active device. This card is updated automatically with each data refresh:

Field	Description
Serial Number	Unique hardware identifier of the device (matricola)
Type / Typology	Device model (e.g., VMR624, DL8)
Last Connection	Timestamp of the most recent server contact
Last Diagnostic	Timestamp of the most recent data transmission

Field	Description
Signal Strength	GSM signal level (0–4 bars); colour-coded badge
Memory Free	Available SD card space in GB
Battery Voltage	Current battery voltage in Volts
USB Voltage	Current USB supply voltage in Volts
AUX Voltage	Current auxiliary supply voltage in Volts
Location / Work Place	Name of the monitoring site or work location
Position / Device Place	Specific installation point of this device
IP Address	Local network IP address and port
Public IP	Public IP address and port (if available)
Coordinates	GPS latitude and longitude (decimal degrees)
Mini Map	Clickable thumbnail map showing device location (only if valid GPS coordinates are available)

DEVICE TIME WARNING

If the device's internal clock is not synchronised with the server time, a warning banner is displayed: **"Warning! Device time is incorrect!"** — This may indicate GPS/NTP sync issues on the device. Contact MAE technical support if this warning persists.

09

CHAPTER NINE

KPI Cards & Statistics

KPI Cards (Key Performance Indicator cards) are displayed in a row above the main chart. There is one card for each measurement channel of the active device. They provide an at-a-glance view of the most recent values and status for each channel.

Card Contents

Element	Description
Channel Label	Human-readable name of the measurement channel (e.g., "Displacement", "PT-50 fs1")
Current Value	The most recent recorded value for this channel, displayed in large text with unit
Trend Indicator	▲ increasing, ▼ decreasing, or ● stable — based on comparison with the previous record
Status Colour	Green = within normal range, Amber = warning threshold exceeded, Red = alert threshold exceeded
Alarm Badge	Shown if this channel has an active event/alarm from event file detection

NOTE — KPI VISIBILITY

The KPI cards are hidden when no data is available for the current date range. They reappear automatically once data is successfully loaded. When a threshold is exceeded, the corresponding KPI card border is highlighted in the alert colour.

Colour Coding

NORMAL

Value is within configured safe range. No action required.

WARNING

Value has exceeded a warning threshold. Attention recommended.

ALERT / CRITICAL

Value has exceeded the critical threshold. Immediate review required.

10

CHAPTER TEN

Secondary Charts & Measurement Table

Secondary Mini-Charts

Below the main chart, a set of compact **mini-charts** is displayed — one for each secondary channel that contains data. These charts provide a quick side-by-side visual comparison of all channels without switching the main chart view.

Each mini-chart shows:

- The channel name and an in-line **min** → **max range** value indicator
- A compact area chart with a coloured gradient fill
- The same time axis as the main chart

Mini-charts are read-only and do not support zoom or hover interaction. They update automatically with each data refresh.

Measurement Log Table

The data table displays all records in the current filtered dataset in a structured tabular format. Columns are adapted to the active device type:

Column	Description
Date	Recording date in DD/MM/YYYY format
Time	Recording time in HH:MM:SS format
Channel 1...N	One column per measurement channel with the recorded value and unit
Status	Optional status column (device-specific)

A **record count** indicator below the table header shows the total number of records currently displayed (e.g., "150 records"). A **search/filter input** allows filtering the table rows by any text value.

TIP — QUICK EXPORT

A quick **Export CSV** button is available in the table footer, providing one-click export of the currently displayed filtered dataset without opening the full Export modal.

11

CHAPTER ELEVEN

Alerts & Threshold Settings

The alert system monitors measurement values in real time and notifies the operator when configured thresholds are exceeded. Alerts are evaluated against every data refresh cycle.

Alert Types



Warning Alert — Value has crossed a warning threshold. Attention is recommended but not necessarily urgent.



Critical Alert — Value has crossed a critical threshold. Immediate inspection is required.

Alert banners appear in a coloured strip above the KPI cards. Each alert shows the channel name, current value, threshold that was exceeded, and the timestamp of the violation. Individual alerts can be dismissed by clicking the **X** button on each banner.

Configuring Thresholds

Click the **Thresholds** (settings) icon in the sidebar to open the threshold configuration panel. For each measurement channel the following parameters can be set:

Parameter	Description
Min Warning	Lower warning level — alert triggered when value falls below this point
Max Warning	Upper warning level — alert triggered when value rises above this point
Min Critical	Lower critical level — critical alert triggered when value falls below this point
Max Critical	Upper critical level — critical alert triggered when value rises above this point
Enable Alerts	Master toggle to enable or disable the alert evaluation for all channels
Sound Notifications	Toggle to enable an audible beep when a new alert is triggered

ATTENTION — THRESHOLD PERSISTENCE

Threshold values are stored in the browser's local storage. They are preserved across sessions on the same browser and device, but **are not synchronised** between different computers or browsers. If you use the dashboard from multiple devices, configure thresholds separately on each.

Event-Based Alarms (VMR624)

The VMR624 supports event file detection. When a vibration threshold is exceeded on the device, an event file is generated and uploaded to the server. The dashboard automatically detects these files: the corresponding channel's KPI card is marked with an alarm badge and the event appears in the **Alarms Panel** (accessible from the sidebar Alerts button). Clicking on an alarm entry opens a detail modal with the full event data.

12

CHAPTER TWELVE

Export & File Download

Click the **Export** button in the top navigation bar to open the Export modal. Four export methods are available. All exports use the **currently loaded and filtered dataset** unless otherwise noted.

12.1 CSV Export

Exports all records in the current filtered view as a **Comma-Separated Values** file, compatible with Microsoft Excel, Google Sheets, and any standard data analysis tool.

- **Filename:** datalogger_{deviceId}_export.csv
- **Content:** Header row with column names and units, followed by one data row per record
- **Columns:** Date, Time, and one column per measurement channel (values to 3 decimal places)
- **Encoding:** UTF-8

12.2 JSON Export

Exports the full dataset as a structured **JSON** file, suitable for API integration, backend import, or custom data processing scripts.

- **Filename:** datalogger_{deviceId}_export.json
- **Records:** Each entry contains date, time, and all channel values

12.3 Print / PDF Report

Generates a comprehensive **printable HTML report** in a new browser tab. The report can be saved as a PDF using the browser's built-in print dialog (`Ctrl + P` → Save as PDF).

The report includes the following sections:

Report Section	Content
Header	MAE logo, device serial number and type, date range, export timestamp
Device Information	9 technical fields in a 3×3 grid: serial, type, last connection, battery, USB, AUX voltages, signal, memory, location
Data Records Table	Full tabular listing of all records in the current filtered view, with date, time, and all channel values
Data Visualisation	Mini charts for each channel, plus a combined overview chart
Footer	MAE branding, generation timestamp, and website reference

12.4 Device File Download

Opens the **File Browser** modal to browse and download raw files stored on the MAE server from the device's SD card. This is useful for accessing raw measurement files for offline analysis.

In the File Browser:

- Select a **date range** and **file type** (EVT, CIR, DAY) using the filter controls
- Click **Search Files** to load the matching file list from the API
- Files are displayed in a paginated table showing: Name, Timestamp, Type, and a Download button
- Click **Download** next to any file to save it locally
- Use the ← / → pagination controls to browse files when more than 50 are available

File Type	Description
EVT	Event files — triggered recordings when a measurement threshold is exceeded on the device
CIR	Circular buffer files — continuous recordings in rotating format
DAY	Daily log files — full day recordings archived at midnight

13

CHAPTER THIRTEEN

Map & Device Location

The map feature provides a geographic visualisation of the device's current location. It is accessible by clicking the **mini map thumbnail** in the Device Information card, which opens the full Map Modal.

Map Controls

Control	Function
Zoom In / Out	Buttons to increase or decrease the map zoom level
Re-centre	Returns the map view to the active device's location
Map Style Selector	Switch between three base map tiles: Streets , Satellite , Terrain
Quick Jump / Search	Type a city or address in the search box to navigate the map to that location

Device Sidebar (in Map Modal)

The left panel of the map modal lists all devices in the active work, each showing:

- Connection status LED (same colour logic as sidebar)
- Device name, serial number, and type
- Location name and GPS coordinates

Clicking a device in the list moves the map to that device's location and updates the info display.

NOTE — GPS AVAILABILITY

The map is only displayed if the device has valid GPS coordinates. Coordinates of **0.000000°**, **0.000000°** are treated as invalid and no map is shown. If the device does not have a GPS module or has not yet acquired a fix, the map preview and modal will not be available.

14

CHAPTER FOURTEEN

Power Supply Monitor

The **Power Supply Monitor** provides a detailed view of the device's voltage supply history. Access it by clicking the power/battery icon in the Device Information card or sidebar area.

Monitored Channels

BATTERY

Internal battery voltage. Nominal range: **3.7 V – 4.2 V** (DL series) or **10.0 V – 12.5 V** (VMR624). Charge status indicator shows if the battery is currently charging.

USB SUPPLY

USB input voltage. Nominal value: **5.0 V**. Range 4.8 V – 5.0 V is considered healthy.

AUX SUPPLY

Auxiliary external power supply voltage. Nominal range: **12.0 V – 15.0 V**. Represents the external DC supply when connected.

Power Monitor Features

- **KPI bars** — Shows the current voltage value for each channel with a colour-coded status bar (green = nominal, amber = low, red = critical)
- **Combined chart** — All three voltage channels overlaid on a single time-series chart for trend comparison
- **Individual sparklines** — Compact dedicated chart per channel with min/max range annotation
- **Channel visibility toggle** — Show or hide individual channels in the combined chart
- **Charge status** — Green indicator when the battery is actively charging, orange when discharging
- **Last update timestamp** — Shows when the power data was last refreshed from the API

NOTE — DATA HISTORY

The power monitor stores the last **10 diagnostic records** when the modal is closed and the last **100 records** when the modal is open. Updates are synchronised with the main dashboard auto-refresh interval (120 seconds).

15

CHAPTER FIFTEEN

Device Types & Channel Reference

15.1 VMR624 — Vibration Monitor

VMR624 – Vibrometro

Events Supported

CH 1	Displacement	mm	Peak particle velocity / displacement measurement
CH 2	Frequency	Hz	Dominant frequency of vibration event
CH 3	Temperature	°C	Internal sensor temperature
CH 4	Voltage	V	Supply voltage at time of measurement

The VMR624 supports **event file detection**. When a vibration threshold is exceeded on the device, an EVT file is generated and uploaded to the server. The dashboard automatically detects these files and raises alarms on the relevant channels.

15.2 DL Series — Displacement Logger

DL8 / DL4 / DL16 – Displacement Logger

No Event Files

CH 1	PT-50 fs1	mm	Displacement / settlement sensor (PT-50 full scale 1)
CH 2	ISBC-10 X	—	Tilt sensor X-axis (ISBC-10)
CH 3	ISBC-10 Y	gr	Tilt sensor Y-axis (ISBC-10) in grams-force

The DL series datalogger does **not** generate event files. Alert detection is performed exclusively by the dashboard threshold configuration. Dynamic channel headers may be provided by the API for newer DL firmware versions, overriding the static configuration above.

16

CHAPTER SIXTEEN

Language & Theme Settings

Language Selection

The dashboard supports two interface languages. Use the language toggle buttons in the top navigation bar to switch:

EN — ENGLISH

Default language. All labels, buttons, error messages, and tooltips are displayed in English.

IT — ITALIAN

Full Italian translation available. Click **IT** to switch. The language selection is remembered for the current session.

The language preference is applied immediately to all visible text elements. Chart labels, KPI card titles, status messages, modal content, and error messages all switch language simultaneously.

Visual Theme

Use the **sun/moon icon** in the top bar to toggle between visual themes:

DARK MODE

Deep navy background with high-contrast coloured accents. Ideal for low-light environments and extended monitoring sessions. **Default theme.**

LIGHT MODE

Clean white background with dark text. Ideal for bright office environments, printing, and screen sharing.

The theme preference is stored in the browser and persists across sessions.

17

CHAPTER SEVENTEEN

Troubleshooting

Problem	Cause & Solution
Login fails — "Invalid credentials"	Verify username and password. Ensure Caps Lock is off. Contact MAE support if credentials were recently changed.
Dashboard redirects to Works page on load	Session has expired or no work is selected. Log in again and select a work from the Works page.
"No devices found" message	No devices are assigned to the selected work, or the API connection failed. Verify internet connectivity and contact MAE if the issue persists.
"No data for this period"	The device has no recorded data for the selected date range. Try expanding the date range or switch to a date when the device was active.
API error message in red banner	The API returned an error. Possible causes: session expired (log out and log in again), network connectivity issue (check internet), or server maintenance. Note the error code and contact MAE support if it persists.
Chart shows no data / empty	Ensure the selected date range contains data for this device. Check the interval filter — it may be set to a window too narrow for available records. Try setting Interval to "All".
Live Mode does not start automatically	The device's last diagnostic date is not today — it may be offline or not transmitting. Check device status LED in the sidebar. Live Mode can be resumed manually by clicking PAUSED.
"Warning! Device time is incorrect!"	The device's internal clock does not match the server time. GPS/NTP sync may have failed. Check the device in the field or contact MAE technical support.
Map is not shown in device info card	The device does not have valid GPS coordinates. Coordinates 0.0000°, 0.0000° are treated as invalid. Ensure the device has GPS enabled and has acquired a fix.
Export produces empty file	There is no data in the current filtered view. Ensure the chart is displaying data before exporting. Change the interval filter to "All" and re-export.
Page is slow or unresponsive	Try reducing the date range to a shorter period. Very large datasets may slow browser rendering. Ensure no other heavy browser tabs are open.

Problem	Cause & Solution
Thresholds reset after closing browser	Threshold settings are stored in browser local storage. They may be cleared if browser history/cache is deleted. Re-enter thresholds after a browser data clear.

TECHNICAL SUPPORT

For issues not resolved by the steps above, contact MAE s.r.l. technical support:
Website: www.mae-srl.it | **Dashboard:** <https://www.maeservice.it/beta/>
Please provide the device serial number, the error message displayed, and a description of the steps taken when the problem occurred.

MAE s.r.l. — Advanced Geophysics Instruments
Zona Industriale Fresilia — 86095 Frosolone (IS) — Italy
www.mae-srl.it | <https://www.maeservice.it/beta/>

This document is intended for authorised users of the MAE DataLogger Live Dashboard system.
All content is subject to change without notice. © 2026 MAE s.r.l. All rights reserved.