



- DETAIL A
- Transmission
 Oil pressure switch and pressure transmitter manifold
 Packing
 Pressure transmitter

- 5. Electrical connector

212-M-63-38

Figure 63-38. Transmission oil pressure transmitter