



- 1. Main rotor mast
- 2. Work aid plug
- 3. Bearing (roller)
- 4. Bearing outer race
- 5. Input gear quill (driven gear)
- 6. Input quill pinion
- 7. Packing
- 8. Transmission main bevel gear case
- 9. Packing
- 10. Main input quill sleeve
- 11. Spacer
- 12. Nut
- 13. Pusher set stud (T101586-5)
- 14. Curvic coupling adapter
- 15. Drain tube union

212-M-63-47

Figure 63-47. Workaid plug for installing input drive quill