



- 1. Manual automatic fuel control interconnect linkage
- 2. Datum line
- 3. Acceleration Adjuster (dome)
- 4. Automatic Fuel Control Unit (AFCU)
- 5. Manual Fuel Control Unit (MFCU)
- 6. Minimum stop screw
- 7. Stop arm
- 8 Stop

- 9. Maximum stop screw
- 10. Fuel control arm
- 11. Cotter pin
- 12 Part power trim stop
- 13. Cotter pin
- 14. Maximum stop adjustment screw
- 15. Pointer
- 16. Quadrant

212_M_76_11_c01

Figure 76-11. Manual and Automatic Fuel Control Adjustment Provisions