


CHAPTER 8 — WEIGHT AND BALANCE

CONTENTS — ILLUSTRATED PARTS BREAKDOWN

Figure		Chapter/Section	Page
Number		Number	Number
8-1	Ballast Installation	8-99-00	2









Figure 8-1. Ballast Installation (Sheet 1 of 2)





212_IPB_08_0001

Figure 8-1. Ballast Installation (Sheet 2 of 2)



	(-)	(2)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 8-1. Ballast Installation			
	212-030-245-107	BALLAST INSTL (S/N 35049 THRU SUB)	1	NP	
1	NAS679A4	. NUT (REPLACED BY MS21042L4)	4	Р	
1	MS21042L4	. NUT (REPLACES NAS679A4)	4	SP	
2	AN970-4	. WASHER	8	SP	
3	AN4-40A	. BOLT (NOTE 1)	4	SP	
4	NAS679A4	. NUT (REPLACED BY MS21042L4)	2	Р	
4	MS21042L4	. NUT (REPLACES NAS679A4)	2	SP	
5	AN970-4	. WASHER	4	SP	
6	AN4-35A	. BOLT (NOTE 1)	2	SP	
7	NAS679A4	. NUT (REPLACED BY MS21042L4)	2	Р	
7	MS21042L4	. NUT (REPLACES NAS679A4)	2	SP	
8	AN970-4	. WASHER	2	SP	
9	AN960-416	. WASHER (REPLACED BY NAS1149F0463P)	2	NP	
9	NAS1149F0463P	. WASHER (REPLACES AN960-416)	2	SP	
10	AN4-25A	. BOLT (NOTE 1)	2	SP	
11	212-030-245-007	BALLAST (NOTE 2) (REPLACED BY 212-030-245-147)	3	NP	
11	212-030-245-147	. BALLAST (NOTE 2) (REPLACES 212-030-245-007)	3	SP	
11 A	212-030-245-121	. BALLAST (NOTE 2) (S/N 35049 THRU SUB) (REPLACED BY	3	NP	
		212-030-245-151)	_	_	
11A	212-030-245-151	. BALLAST (NOTE 2) (REPLACES 212-030-245-121)	3	P	
11B	212-030-245-007	. BALLAST (NOTE 2) (S/N 30504 THRU 31311, 35001 THRU 35048)	3	NP	
		(REPLACED BY 212-030-245-147)			
11B	212-030-245-147	. BALLAST (NOTE 2) (REPLACES 212-030-245-007)	3	SP	
12	212-030-245-009	. BALLAST (NOTE 2) (REPLACED BY 212-030-245-149)	3	NP	
12	212-030-245-149	. BALLAST (NOTE 2) (REPLACES 212-030-245-009)	3	SP	
12A	212-030-245-123	. BALLAST (NOTE 2) (S/N 35049 THRU SUB) (REPLACED BY	3	NP	
		212-030-245-153)	_	_	
12A	212-030-245-153	. BALLAST (NOTE 2) (REPLACES 212-030-245-123)	3	P	
12B	212-030-245-009	. BALLAST (NOTE 2) (S/N 30504 THRU 31311, 35001 THRU 35048)	3	NP	
		(REPLACED BY 212-030-245-149)			
12B	212-030-245-149	BALLAST (NOTE 2) (REPLACES 212-030-245-009)	3	SP	
13	212-030-245-011	. BALLAST (NOTE 2)	4	SP	
13A	212-030-245-125	. BALLAST (NOTE 2) (S/N 35049 THRU SUB)	4	SP	
13B	212-030-245-011	. BALLAST (NOTE 2) (S/N 30504 THRU 31311, 35001 THRU 35048)	4	SP	
14	212-030-245-013	. BALLAST (NOTE 2)	2	SP	
14A	212-030-245-127	. BALLAST (NOTE 2) (S/N 35049 THRU SUB)	2	SP	
14B	212-030-245-013	. BALLAST (NOTE 2) (S/N 30504 THRU 31311, 35001 THRU 35048)	2	SP	
15	212-030-245-015	BALLAST (NOTE 2)	2	SP	
15A	212-030-245-129	BALLAST (NOTE 2) (S/N 35049 THRU SUB)	2	Р	
15B	212-030-245-015 212-030-177-001	BALLAST (NOTE 2) (S/N 30504 THRU 31311, 35001 THRU 35048)	2	SP	
	212-030-177-001	BALLAST INSTL (S/N 30504 THRU 30596, 30604 THRU 30610)	1	NP NP	
16		BALLAST INSTL (S/N 30597 THRU 30603, 30611 THRU 30679)	2	NP NP	
16	MS21042-5 MS21042L5	NUT (REPLACED BY MS21042L5)	2	SP	
17	AN960PD516	. NUT, SELF-LOCKING (REPLACES MS21042-5)	2	P	
17	AN960JD516	. WASHER, FLAT (REPLACES AN960PD516) (REPLACED BY	2	P	
17	A143000D310			1"	
17	NAS1149D0563J	NAS1149D0563J)	2	SP	
18	AN44-37A	. WASHER (REPLACES AN960JD516)	2	SP	
19	AN3-30A	BOLT	4	SP	
20	AN960PD10	. WASHER (REPLACED BY AN960JD10)	4	SP	
20	AN960JD10	. WASHER (REPLACED BY AN960JD10)	4	Р	
20	7.1.100002.10		T .	'	
20	NAS1149D0363J	NAS1149D0363J)	4	SP	
21	212-030-176-001	BRACKET	2	SP	
22	212-030-175-001	PAN (S/N 30504 THRU 30596, 30604 THRU 30610)	1	NP	
22	212-030-175-003	PAN (S/N 30504 THRO 30590, 30604 THRO 30610)	1	NP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U O C
		Figure 8-1. Ballast Installation (Cont'd)			
22 23 23 23	212-030-175-005 212-030-173-001 212-030-173-007 212-030-177-007 212-030-177-101 212-030-177-103 MS21042-5 MS21042L5	PAN (REPLACES 212-030-175-003)	1 1 1 1 1 1 2 2	SP	
25 25	AN960PD516 AN960JD516	. WASHER (REPLACED BY AN960JD516)	2 2	P P	
25 26 26 27 27 28 28 29 29	NAS1149D0563J AN44-31A AN44-4A AN44-37A AN44-12A AN3-31A NAS6203-10 AN960PD10 AN960JD10	NAS1149D0563J) . WASHER (REPLACES AN960JD516) . EYEBOLT (NOTE 3) . BOLT (NOTE 6) . BOLT (NOTE 6) . WASHER (REPLACED BY AN960JD10) . WASHER (REPLACES AN960PD10) (REPLACED BY NAS1149D0363J)	2 1 1 1 1 4 4 4	SP SP SP SP SP SP SP P	
29 30 31 32 33	NAS1149D0363J 212-030-176-001 212-030-176-003 212-030-175-005 212-030-173-009	. WASHER (REPLACES AN960JD10)	4 1 1 1	SP SP SP SP NP	
33 34 34 34 34 34 34 34 35	212-030-173-101 NAS6604-9 NAS6604-17 NAS6604-25 NAS6604-42 NAS6604-50 NAS6604-58 NAS6604-34 AN960PD416L	(REPLACED BY 212-030-173-101) BALLAST (NOTE 2) (REPLACES 212-030-173-009)	1 8 8 8 8 8 8 8	SP	
35	AN960JD416L	AN960JD416L)	16	Р	
35	NAS1149D0416J	AN960PD416L) (REPLACED BY NAS1149D0416J)	16	SP	
35A	AN960PD416L	AN960JD416L)	24	NP	
35A	AN960JD416L	AN960JD416L)	24	Р	
35A	NAS1149D0416J	AN960PD416L) (REPLACED BY NAS1149D0416J)	24	SP	
36 36A 37	222-031-357-101 222-031-357-101 212-030-435-001 204-040-811-001	BALLAST (NOTE 2) (S/N 35012 THRU 35068) BALLAST (NOTE 2) (S/N 35069 THRU SUB) BALLAST INSTL CLAMP ASSY (NOTE 2)	7 14 1 9	SP SP NP SP	
37A 37A 37B 37C 37C	52Z1835-048 D52Z1835-048 MS9089-24 204-040-809-001 204-040-809-003	NUT (ALTERNATE PART) NUT BOLT CLAMP (NOTE 2) (REPLACED BY 204-040-809-003) CLAMP ASSY (NOTE 2) (REPLACES 204-040-809-001) (REPLACED BY 204-040-811-001)	4 4 4 2 2	SP PSPP	



(1)	(2)	(3)	(4)	(5)	(6)
INDEX NUMBER	PART NUMBER	ITEM NAME	UNIT PER ASSY	A V A I L	U 0 C
		Figure 8-1. Ballast Installation (Cont'd)			
37C 38 38 39 40 41 42 42	204-040-811-001 MS9048-237 NAS561P8-26 204-071-566-005 204-071-566-001 204-071-566-003 31-026-8F18 31-026-8B18	CLAMP ASSY (NOTE 2) (REPLACES 204-040-809-003) PIN (REPLACED BY NAS561P8-26) PIN (REPLACES MS9048-237) WASHER (NOTE 2) BALLAST (NOTE 2) BALLAST (NOTE 2) DECAL (BALLAST INSIDE) (NOTE 7) (REPLACED BY 31-026-8B18) DECAL (BALLAST INSIDE) (NOTE 7) (REPLACES 31-026-8F18).	2 1 1 8 10 4 1	SP NP SP SP SP NP SP	
		NOTE 1: BOLT LENGTHS TO BE DETERMINED ON INSTALLATION.			
		NOTE 2: QUANTITY SHOWN IS MAXIMUM AND IS DETERMINED BY SHIP CONFIGURATION. CHANGES BY OPERATOR SHOULD BE IN ACCORDANCE WITH BHT-212-MM.			
		NOTE 3: USE EYEBOLTS AN44-4A AND AN44-12A IN LIEU OF AN44-31A AND AN44-37A RESPECTIVELY IF BALLASTS ARE NOT REQUIRED.			
		NOTE 4: USE BOLTS NAS6604 BOLTS AS REQUIRED TO MATCH STACK UP OF BALLAST WEIGHTS 222-031-357 AND PANEL 212-030-066 THICKNESSES.			
		NOTE 5: USE ONE WASHER AN960JD416L UNDER HEAD OF ALL BOLTS NAS6604 EXCEPT FOR BOLTS NA56604-34, NAS6604-42, NAS6604-50 AND NAS6604-58, WHICH REQUIRE THREE WASHERS.			
		NOTE 6: USE BOLT NAS6203-10 IN LIEU OF AN3-31A IF BALLAST IS NOT REQUIRED.			
		NOTE 7: DECAL APPLIED ONLY IF BALLAST HAS BEEN ADDED. REFER TO BHT-212-MM.			
		AVAIL CODE DEFINITION			
		P Procurable NP Non Procurable SP Normal Stock/Procurable			
		Please see Chapter 1 for additional information on availability codes as well as general use of the Illustrated Parts Breakdown Manual.			