Sattware

Variant: [No Variations]

08/03/2022 1.0.00

RELEASED DD-MMM-YYYY

Page	Index	Page	Index	Page	Index	Page	Index
•••••	•••••	•••••	•••••	•••••	•••••	•••••	•••••
1	COVER PAGE	11		21		31	
2	BLOCK DIAGRAM	12		22		32	
3	MICROCONTROLLER	13		23		33	
4	SENSORS-1	14		24		34	
5	SENSORS-2	15		25		35	
6	CONTROL UNITS	16		26		36	
7	POWER MANAGEMENT	17		27		37	
8	CONNECTORS	18		28		38	
9		19		29		39	1
10		20		30		40	

!!!CAUTION!!!

FUSE HOLDER The fuse holder was placed on the line of the positive wire from battery

Use 10AWG size cable between Battery and Power Switch

IMU SOI DERING!!!! Consult document before soldering https://www.bosch-sensortec.com/media /boschsensortec/downloads/handling_so derina mountina instructions/bst-bno05

In order to boot the ESP32, shortcut the jumper resistors JS1 and JS2

DESIGN NOTE: Example text for critical design notes

Example text for critical layout guidelines.

	Designed By: Enes Mercan	
	Title: Sattware	Variant: [No Variations]
	Page Name: Cover Page.SchDoc	Page Size: A3
Company: HurSAT Setellite Cannot open file C:\Users\Public\Documents\Altium\Projects\	Date: 08/03/2022	Revision: 1.0.00
Guvenlik Karti\Screen Shot 2021-05-17 at 14.20.06.png. File does not exist.	ApprovedBy: *	Sheet: 1 of 8













