


# STARTING



## Supplied accessories




Key for mounting and dismounting the sieve



Cleaning brush



Measuring dipper





Test strip for water hardness

## Technical data

- Type
  - Nominal voltage
  - Mains cable
  - Nominal output
  - Pump pressure
  - Preparation time
  - Coffee grounds ejection
  - Dosage of water quantity
  - Capacity
  - Steam volume
  - Dimensions (L x H x D)
  - Weight (net)
- SUP 016 RE  
see type plate on machine  
1.2 m  
see type plate on machine  
approx. 15 bar  
Espresso approx. 20 sec/cup, coffee approx. 30 sec/cup  
automatic  
electronic, continuous  
water tank: approx. 2.4 l  
dregs drawer: approx. 300 g  
continually adjustable  
approx. 33 x 45 x 40 cm  
approx. 70 x 45 x 40 cm with opened service door  
approx. 16 kg

cod. 0351.955 Rev 01 del 18/03/02



This TSM SUCCESS MANUAL® has been examined by SEV for conformity with the safety-relevant standards, and has been analysed by an application-oriented risk analysis for the completeness and correctness of the indications for a safe use of the appliance. Thereby we assume a use with which can be reckoned based on common sense.

TSM SUCCESS MANUAL® - safe to use - easy to understand due to TSM®-Total Security Management and ergonomic communication®

## TROUBLESHOOTING

- No display**  
No power to the machine

- Switch on main power switch  
- Close service door  
- Check plug, connection and fuses

### Preparation cycle does not begin

Display :	
BREW UNIT MISS.	► Insert brewing unit
BREWUNIT BLOCK.	► Clean brewing unit
DREGDRAW. MISS.	► Insert dregs drawer
GRINDER BLOCKED	► Clean grinding unit
ENERGY SAVING	► Press «ENTER»

### With «coffee powder» selected, only water comes instead of coffee

- Fill a measuring dipper with ground coffee

### Coffee is not hot enough

- Preheat the cups

- Modify temperature

- If necessary: clean brewing unit

- If necessary: descale

### No hot water/steam

Hot water/steam nozzle is blocked

### Heating time too long, not enough water

- Descale machine

### Brewing unit cannot be removed

...although the dregs drawer is removed

### Brewing unit cannot be inserted

#### Reset brewing unit



## DESCALE

 (automatic)  
*Carry out this procedure only when all parts of the machine have cooled down*

### 1 Prepare descaling

- NEVER use VINEGAR possible damage to machine
- Follow strictly the manufacturers instructions for use

1. Place large receptacle under hot water/steam nozzle
2. Fill descaling solution into the water tank according to manufacturer's instructions
1. Press programming key
2. Search for DESCALING with ▲▼
3. Start cycle with ENTER

### 2 Start descaling

Cancel with ESC

MACHINE IS DESCALING ► Wait approx. 45 min.

DESCALING FINISHED ► Close turning knob, press ENTER

FILL WATERTANK ► Rinse + fill water tank

2. Open turning knob

3. Let tank contents run out

4. Close turning knob, press ENTER

RINSING FINISHED ► Press ESC

### 3 Reset descale display

Cancel with ESC

1. Press programming key

2. Search for SIGNAL DESCAL.

with ▲▼ -> ENTER

3. Search for YES

8

## CLEANING

Use only a mild and non-scouring cleaning agent

- Remove mains from power socket before cleaning the machine

- Do not dry parts of the coffee machine in a baking or microwave oven

### Casing

Wipe with a soft, damp cloth

### Dregs drawer, drip tray and fresh water tank

Clean under running water

### Brewing unit

Clean weekly

Never clean the brewing unit in a dishwasher



1. Open service door, Remove drip tray/dregs drawer

2.1 Loosen sieve with key...

2. Press position PRESS and remove brewing unit. If necessary, unscrew upper sieve of brewing unit

3. Clean everything under running warm water and let dry. Clean service area

### Cappuccinatore

1. Take out lateral

2. Remove cover

3. Remove brewing unit cappuccinatore

4. Wash in water

5. Dry

6. Mount

### Dregdrawer full

This message appears on the display when the dregdrawer is full

or every 10-15 cups.

When the digital display reads "dregdrawer full" the machine is able to dispense only hot water and steam (not coffee).

To clear the message, make sure machine is on, remove the dregdrawer, empty it, wait for 5 seconds and then put back in place. After this the display reads:

SELECT PRODUCT

READY FOR USE

Now the machine is ready to dispense coffee again.

9



## Operating Instructions

Please read these TSM® operating instructions before initial operation. Follow the instructions carefully to insure constant optimum quality of your drinks and to avoid damages and injuries. Keep this instruction manual handy where you can readily refer to it. If you pass on your machine to others, be sure that the operating and safety instructions go with it. Your machine has been conscientiously checked for safety and proper functioning and left the factory in fault-free working order.

## FOR HOUSEHOLD USE ONLY

Read safety instructions before starting to use the machine

CE

