bq30z554-R1

Technical Reference



Literature Number: SLUUA79 October 2013



Contents

Pret	ace		. 9
1	Intro	duction	10
2	Calib	ration	11
	2.1	Overview	11
	2.2	Combining Calibrations	12
	2.3	Cell Voltage Calibration	
	2.4	BAT Voltage Calibration	
	2.5	PACK Voltage Calibration	
	2.6	Current Calibration	
		2.6.1 Offset Calibration	
		2.6.2 Board Offset Calibration	
		2.6.3 Gain Calibration	
	2.7	Temperature Calibration	
		2.7.1 Internal Temperature Sensor Calibration	
		2.7.2 TS1–TS4 Calibration	
3	Prote	ections	
3	3.1	Introduction	
	3.2	Cell Undervoltage Protection	
	3.3	Cell Undervoltage Compensated Protection	
	3.4	Cell Overvoltage Protection	
	3.5	Overcurrent in Charge Protection	
	3.6	Overcurrent in Discharge Protection	
	3.7	Hardware-Based Protection	
	5.7	3.7.1 Overload in Discharge Protection	
		3.7.2 Short Circuit in Charge Protection	
		3.7.3 Short Circuit in Discharge Protection	
	3.8	Overtemperature in Charge Protection	
	3.9	Overtemperature in Discharge Protection	
	3.10	Overtemperature FET Protection	
	3.11	SBS Host Watchdog Protection	
	3.12	Precharge Timeout Protection	
	3.13	Fast Charge Timeout Protection	
	3.14	Overcharge Protection	
	3.15	Over-ChargingVoltage() Protection	
	3.16	Over-Charging Voltage() Protection	
1			27
-	4.1	Introduction	
	4.2	Charge Temperature Ranges	
	4.3	Voltage Range	
	4.4	Charging Current	
	4.5	Charging Voltage	
	4.6	Valid Charge Termination	
	4.7	Maintenance Charge	
	4.8	Charge Disable	
		Charge Dicasio	50

2



www.ti.com

4.10 Charging Suspend 4.11 Charging/Outrent() Rate of Change 4.12 Charging Loss Compensation 5 Permanent Fail 5.1 Introduction 5.2 Black Box Recorder 5.3 Cell Undervoltage Permanent Fail 5.4 Cell Overvoltage Permanent Fail 5.5 Copper Deposition Permanent Fail 5.6 Overtemperature Cell Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.19 Ferminent Fail 5.20 Second Level Protection Pe				
4.11 ChargingCurrent() Rate of Change 4.12 Charging Current() Rate of Change 4.13 Charging Loss Compensation 5 Permanent Fail 5.1 Introduction 5.2 Black Box Recorder 5.3 Cell Undervoltage Permanent Fail 5.4 Cell Overvoltage Permanent Fail 5.5 Copper Deposition Permanent Fail 5.6 Overtemperature Cell Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance Active Permanent Fail 5.13 Ostage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Cherrical Fuse Permanent Fail 5.18 AFE Communication Permanent Fail 5.19 AFE Communication Permanent Fail 5.20		4.9	Charge Inhibit	31
4.12 ChargingCurrent() Rate of Change 4.13 Charging Loss Compensation 5 Permanent Fail 5.1 Introduction 5.2 Black Box Recorder 5.3 Cell Undervoltage Permanent Fail 5.4 Cell Overvoltage Permanent Fail 5.5 Copper Deposition Permanent Fail 5.6 Overtemperature Cell Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Intermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.10 PTC Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes <t< th=""><th></th><th>4.10</th><th>Charge Suspend</th><th>31</th></t<>		4.10	Charge Suspend	31
1.13 Charging Loss Compensation 5		4.11	ChargingVoltage() Rate of Change	31
5 Permanent Fall 5.1 Introduction 5.2 Black Box Recorder 5.3 Cell Undervoltage Permanent Fail 5.4 Cell Overvoltage Permanent Fail 5.5 Copper Deposition Permanent Fail 5.6 Overtemperature Cell Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance at Rest Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Rogister Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 pror Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.24		4.12	ChargingCurrent() Rate of Change	31
5.1 Introduction 5.2 Black Box Recorder 5.3 Cell Undervoltage Permanent Fail 5.4 Cell Overvoltage Permanent Fail 5.5 Copper Deposition Permanent Fail 5.6 Overtemperature Cell Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.24 Data Flash Permanent Fail <t< th=""><th></th><th>4.13</th><th>Charging Loss Compensation</th><th>32</th></t<>		4.13	Charging Loss Compensation	32
5.2 Black Box Recorder 5.3 Cell Undervoltage Permanent Fail 5.4 Cell Overotitage Permanent Fail 5.5 Copper Deposition Permanent Fail 5.6 Overtemperature Cell Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance Active Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail <th>5</th> <th>Perm</th> <th>anent Fail</th> <th>33</th>	5	Perm	anent Fail	33
5.3 Cell Undervoltage Permanent Fail 5.4 Cell Overvoltage Permanent Fail 5.5 Copper Deposition Permanent Fail 5.6 Overtemperature Cell Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes </th <th></th> <th>5.1</th> <th>Introduction</th> <th>33</th>		5.1	Introduction	33
5.4 Cell Overvoltage Permanent Fail 5.5 Copper Deposition Permanent Fail 5.6 Overtemperature Cell Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 Instruction Flash Checksum Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode		5.2	Black Box Recorder	33
5.5 Copper Deposition Permanent Fail 5.6 Overtemperature CeIl Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance Active Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 5.24 Data Flash Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes		5.3	Cell Undervoltage Permanent Fail	34
5.6 Overtemperature Cell Permanent Fail 5.7 Overtemperature FET Permanent Fail 5.8 GMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6.1 NORMAL Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep		5.4	Cell Overvoltage Permanent Fail	34
5.7 Overtemperature FET Permanent Fail 5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.10 AFE Communication Permanent Fail 5.21 PTC Permanent Fail 5.22 Descond Level Protection Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.2.2 ManufacturerAccess() Shutdow		5.5	Copper Deposition Permanent Fail	34
5.8 QMAX Imbalance Permanent Fail 5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 5.25 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode		5.6	Overtemperature Cell Permanent Fail	35
5.9 Cell Balancing Permanent Fail 5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Update 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description		5.7	Overtemperature FET Permanent Fail	35
5.10 Capacity Degradation Permanent Fail 5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Register Permanent Fail 5.10 Second Level Protection Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.4 QMAX 7.4 QMAX 7.5		5.8	QMAX Imbalance Permanent Fail	35
5.11 Impedance Permanent Fail 5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell		5.9	Cell Balancing Permanent Fail	35
5.12 Voltage Imbalance at Rest Permanent Fail 5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.3 Gas Gauge Modes 7.4 Impedance Track Update 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditio		5.10	Capacity Degradation Permanent Fail	36
5.13 Voltage Imbalance Active Permanent Fail 5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.2 QMAX Initial Values 7.4.2 QMAX Update Conditions		5.11	Impedance Permanent Fail	
5.14 Charge FET Permanent Fail 5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.3 Gas Gauge Modes 7.4 Impedance Track Update 7.2 Impedance Track Update 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6		5.12	Voltage Imbalance at Rest Permanent Fail	
5.15 Discharge FET Permanent Fail 5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.3 Ga Gauging 7.1 Impedance Track Update 7.2 Impedance Track Update 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Initial Values 7.4.2 QMAX Update Conditions		5.13	Voltage Imbalance Active Permanent Fail	
5.16 Thermistor Permanent Fail 5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.3 Gas Gauge Modes 7.1 Impedance Track Update 7.2 Impedance Track Update 7.4 QMAX 7.4.1 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 De		5.14	Charge FET Permanent Fail	
5.17 Chemical Fuse Permanent Fail 5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Initial Values 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description		5.15	Discharge FET Permanent Fail	
5.18 AFE Register Permanent Fail 5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.1 Impedance Track Update 7.2 Impedance Track Update 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description		5.16	Thermistor Permanent Fail	
5.19 AFE Communication Permanent Fail 5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.1 Impedance Track Update 7.2 Impedance Track Update 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description		• • • • • • • • • • • • • • • • • • • •	Chemical Fuse Permanent Fail	
5.20 Second Level Protection Permanent Fail 5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.1 Impedance Track Update 7.2 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description			AFE Register Permanent Fail	
5.21 PTC Permanent Fail 5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description				
5.22 Instruction Flash Checksum Permanent Fail 5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description				
5.23 Open Cell Voltage Connection Permanent Fail 5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		-		
5.24 Data Flash Permanent Fail 6 Power Modes 6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		-		
6			·	
6.1 NORMAL Mode 6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		_		
6.2 SLEEP Mode 6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description	6			
6.2.1 Device Sleep 6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		-		
6.2.2 ManufacturerAccess() Sleep 6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		6.2		
6.3 SHUTDOWN Mode 6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description			·	
6.3.1 Voltage-Based Shutdown 6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description			y .	
6.3.2 ManufacturerAccess() Shutdown 7 Gauging 7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		6.3		
7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description				
7.1 Impedance Track Update 7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description			v	
7.2 Impedance Track Configuration 7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description	7	Gaug	ing	43
7.3 Gas Gauge Modes 7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		7.1	Impedance Track Update	
7.4 QMAX 7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		7.2	Impedance Track Configuration	
7.4.1 QMAX Initial Values 7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		7.3	Gas Gauge Modes	
7.4.2 QMAX Update Conditions 7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		7.4	QMAX	
7.5 Cell Balancing 7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description			The Company of the Co	
7.6 TURBO Mode 8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description			·	
8 Lifetime Data Collection 8.1 Description 9 Device Security 9.1 Description		_		
8.1 Description		_		
9 Device Security	8	Lifetir	me Data Collection	51
9.1 Description		8.1	Description	51
9.1 Description	9	Devic	e Security	53
9.2 SHA-1 Description		9.1	Description	53
·		9.2	SHA-1 Description	53





	9.3	HMAC I	Description	53
	9.4		tication	
	9.5	Unseal/	Full Access	54
10	SBS	Comma	nds	55
	10.1		anufacturerAccess()	
		10.1.1	0x0000 ManufacturerData	
		10.1.2	0x0001 Device Type	
		10.1.3	0x0002 Firmware Version	
		10.1.4	0x0003 Hardware Version	
		10.1.5	0x0004 Instruction Flash Checksum	
		10.1.6	0x0005 Data Flash Checksum	
		10.1.7		
		10.1.8	0x0010 Shutdown Mode	
		10.1.9	0x0011 SLEEP Mode	
		10.1.10	0x0012 Device Reset	
		10.1.11		
		10.1.12		
		10.1.13		
		10.1.14		
		10.1.15		
		10.1.16		
		10.1.17	"	
		10.1.18	v	
		10.1.19	w	
		10.1.20	w	
		10.1.21		
		10.1.22	w	
		10.1.23	w	
		10.1.24	w	
		10.1.25	w	
		10.1.26	·	
		10.1.27	w	
		10.1.28	·	
		10.1.29	v	
		10.1.30	· ·	
		10.1.31		
		10.1.32	ManufacturerAccess() 0x0050 SafetyAlert	
		10.1.33	·	
		10.1.34	· · · · · · · · · · · · · · · · · · ·	
		10.1.35	·	
		10.1.36	·	
		10.1.37	The state of the s	
		10.1.38	· · · · · · · · · · · · · · · · · · ·	
		10.1.39	· · · · · · · · · · · · · · · · · · ·	
		10.1.40	· · · · · · · · · · · · · · · · · · ·	
		10.1.41	· · · · · · · · · · · · · · · · · · ·	
		10.1.42	_	
		10.1.42	·	
		10.1.44		
		10.1.45	·	
		10.1.46	·	
		10.1.47	"	
		10.1.48	·	
		10.1.70	manarasass, toooog oxooo Enounto Data Diotit E	50



www.ti.com

	10.1.49 ManufacturerAccess() 0x0062 Lifetime Data Block 3	
	10.1.50 ManufacturerAccess() 0x0070 ManufacturerInfo	
	10.1.51 ManufacturerAccess() 0x0071 Voltages	
	10.1.52 ManufacturerAccess() 0x0072 Temperatures	
	10.1.53 ManufacturerAccess() 0x0073 ITSTATUS1	
	10.1.54 ManufacturerAccess() 0x0074 ITSTATUS2	
	10.1.55 ManufacturerAccess() 0x270C MANUAL FET CONTROL	67
	10.1.56 ManufacturerAccess() 0xF080 Exit Calibration Output Mode	67
	10.1.57 ManufacturerAccess() 0xF081 Output CC and ADC for Calibration	68
	10.1.58 ManufacturerAccess() 0xF082 Output shorted CC AND ADC Offset for Calibration	68
	10.1.59 ManufacturerAccess() 0x01yy DF Access Row Address	69
10.2	0x01 RemainingCapacityAlarm()	69
10.3	0x02 RemainingTimeAlarm()	69
10.4	0x03 BatteryMode()	69
10.5	0x04 AtRate()	
10.6	0x05 AtRateToFull()	
10.7	0x06 AtRateToEmpty()	
10.8	0x07 AtRateOK()	
10.9	0x08 Temperatures()	
10.10	0x09 Voltage()	
10.11	0x0A Current()	
10.12	0x0B AverageCurrent()	
10.12	0x0C MaxError()	
10.13	0x0D RelativeStateOfCharge()	
10.14	0x0E AbsoluteStateOfCharge()	
10.13	0x0F RemainingCapacity()	
10.10	0x10 FullChargeCapacity()	
10.17	0x11 RunTimeToEmpty()	
10.16	0x12 AverageTimeToEmpty()	
	0x13 AverageTimeToEmpty()	
10.20		
10.21	0x14 ChargingCurrent()	
10.22	0x15 ChargingVoltage()	
10.23	0x16 BatteryStatus()	
10.24	0x17 CycleCount()	
10.25	0x18 DesignCapacity()	
	0x19 DesignVoltage()	
		75
10.28	0x1B ManufacturerDate()	
10.29	0x1C SerialNumber()	
10.30	0x20 ManufacturerName()	
10.31	0x21 DeviceName()	
10.32	7.0	
10.33	V	
10.34	0x2F Authentication() AND ManufacturerInput()	
10.35	0x3C-0x3F Cell Voltages()	
10.36	0x50 SafetyAlert()	
10.37	0x51 SafetyStatus()	
10.38	0x52 PFAlert()	81
10.39	0x53 PFStatus()	
10.40	0x54 OperationStatus()	
10.41	0x55 ChargingStatus()	
10.42		
10.43	0x57 ManufacturingStatus()	86





	10.44	0x58 Al	FERegisters()	. 87
	10.45	0x59 TI	JRBO_POWER()	. 88
	10.46	0x5A T	URBO_FINAL()	. 88
	10.47	0x5B T	URBO_PACK_R()	. 88
	10.48	0x5C T	URBO_SYS_R()	. 88
	10.49	0x5D M	IIN_SYS_V()	. 88
	10.50		URBO_CURRENT()	
	10.51	0x60 Li	fetime Data Block 1	. 89
	10.52		fetime Data Block 2	
	10.53	0x62 Li	fetime Data Block 3	. 90
	10.54		anufacturerInfo()	
	10.55	0x71 V	oltages()	. 91
	10.56		emperatures()	
	10.57	0x73 IT	Status1()	. 91
	10.58	0x74 IT	Status2()	. 92
11	Data	Flash V	alues and Device Configuration	. 94
	11.1		ormats	
		11.1.1	Unsigned Integer	
		11.1.2	Integer	
		11.1.3	Floating Point	
		_	Hex	
			String	
	11.2		ons	
	–		CUV—Cell Undervoltage	
			COV—Cell Overvoltage	
			OCC1—Overcurrent In Charge 1	
			OCC2—Overcurrent In Charge 2	
			OCC Overcurrent In Charge Recovery	
			OCD1—Overcurrent In Discharge 1	
		11.2.7	OCD2—Overcurrent In Discharge 2	
		11.2.8	OCD—Overcurrent In Discharge Recovery	
		_	OLD—Overload in Discharge	
			SCC—Short Circuit In Charge	
		11.2.11		
			SCD2—Short Circuit in Discharge 2	
			SCD—Short Circuit in Discharge	
		_	OTC—Over Temperature in Charge	_
			OTD—Over Temperature in Discharge	
			OTF—Over Temperature FET	
			HWD—Host Watchdog	
			PTO—PRECHARGE Mode Time Out	
			CTO—FAST CHARGE Mode Time Out	
			OC—Overcharge	
			CHGV—ChargingVoltage	
			CHGC—Charging Voltage CHGC—Charging Current	
	11.3		ent Fail	
	11.0		CUV—Cell Undervoltage	
			COV—Cell Overvoltage	
		11.3.2	CUDEP—Copper Deposition	
			OTCE—Over Temperature Cell	
			OTF—Over Temperature Cell	
			CB—Cell Balance	
			VIMR—Voltage Imbalance at Rest	
		11.5.7	viivin—voitage iiiibalaite at nest	100



www.ti.com

	11.3.8 VIMA—Voltage Imbalance Active	
	11.3.9 CD—Capacity Degradation	
	11.3.10 CFETF—CHG FET Failure	101
	11.3.11 DFET—DFET Failure	101
	11.3.12 THERM—NTC Thermistor Failure	101
	11.3.13 FUSE—FUSE Failure	101
	11.3.14 AFER—AFE Register	101
	11.3.15 AFEC—AFE Communication	101
	11.3.16 2LVL—2nd Level OV	102
	11.3.17 OCECO—Open Cell Connection	102
11.4	Advanced Charging Algorithm	102
	11.4.1 Temperature Ranges	
	11.4.2 Low Temp Charging	
	11.4.3 Standard Temp Charging	
	11.4.4 High Temp Charging	
	11.4.5 REC Temp Charging	
	11.4.6 PCHG	
	11.4.7 MCHG	
	11.4.8 Voltage Range	
	11.4.9 Termination Config	
	11.4.10 Cell Balancing Config	
	11.4.12 Charge Loss Compensation	
11 E	System Data	
11.5		
44.0	11.5.1 Manufacturer Data	
11.6	· · · · · · · · · · · · · · · · · · ·	
	11.6.1 Data	
	11.6.2 FD	
	11.6.3 FC	
	11.6.4 TDA	
	11.6.5 TCA	
	11.6.6 Max Error	
11.7	Lifetimes	
	11.7.1 Voltage	
	11.7.2 Current	
	11.7.3 Safety Events	
	11.7.4 Charging Events	109
	11.7.5 Gauging Events	
	11.7.6 Power Events	110
	11.7.7 Cell Balancing	110
	11.7.8 Temperature	110
	11.7.9 Time	110
11.8	Settings	110
	11.8.1 Fuse	110
	11.8.2 Manufacturing	111
	11.8.3 Protection	112
	11.8.4 Permanent Failure	114
	11.8.5 Configuration	114
	11.8.6 AFE	119
11.9	Power	119
	11.9.1 Power	119
	11.9.2 Shutdown	120
	11.9.3 Sleep	120
	·	





		11.9.4 Ship	120
		11.9.5 Power Off	120
	11.10	Gas Gauging1	120
		11.10.1 Current Thresholds	120
		11.10.2 State	120
		11.10.3 Turbo Configuration	121
	11.11	IT Config1	122
	11.12	RA Table 1	123
		11.12.1 R_a0 1	123
		11.12.2 R_a1 1	124
		11.12.3 R_a2 1	124
		11.12.4 R_a3 1	125
		11.12.5 R_a0x	125
		11.12.6 R_a1x	126
		11.12.7 R_a2x	127
		11.12.8 R_a3x 1	128
	11.13	PF Status	128
		11.13.1 Device Status Data	128
		11.13.2 Device Voltage Data	137
		11.13.3 Device Current Data	138
		11.13.4 Device Temperature Data	138
		11.13.5 Device Gauging Data	138
		11.13.6 AFE Regs	138
	11.14	Black Box1	142
		11.14.1 Safety Status	142
		11.14.2 PF Status	148
	11.15	Calibration	152
		11.15.1 Voltage	152
		11.15.2 Current	152
		11.15.3 Current Offset	153
		11.15.4 Temperature	153
		11.15.5 Internal Temp Model	153
		11.15.6 Cell Temp Model	153
		11.15.7 FET Temp Model	154
		11.15.8 Filter	154
		11.15.9 Current Deadband	
	11.16	Data Flash Values	155
Α	AFE 1	Threshold and Delay Settings 1	170
	A.1	Overload in Discharge Protection (OLD)	
	A.2		170
	A.3	Short Circuit in Discharge (SCD1 and SCD2)	171
В		ing and Writing to Data Flash	
_			
С	Samp	ble Filter Settings	174

8



Preface

Read this First

This manual discusses the modules and peripherals of the bq30z554-R1 device, and how it is used to build a complete battery pack gas gauge and protection solution.

Notational Conventions

The following notation is used if SBS commands and data flash values are mentioned within a text block:

- SBS commands: italics with parentheses and no breaking spaces, e.g., RemainingCapacity().
- Data Flash: italics, bold, and breaking spaces, e.g., Design Capacity
- Register Bits and Flags: italics and brackets, e.g., [TDA] Data
- Flash Bits: italics and bold, e.g., [LED1]
- Modes and states: ALL CAPITALS, e.g., UNSEALED

The reference format for SBS commands is: SBS:Command Name(Command No.):Manufacturer Access(MA No.)[Flag], for example:

SBS:Voltage(0x09), or SBS:ManufacturerAccess(0x00):Seal Device(0x0020)

The reference format for data flash values is: DF:Class Name:Subclass Name(Subclass ID):Value Name(Offset)[Flag], for example:

DF:1st Level Safety:Voltage(576):CUV Threshold(13), or

DF:ChargeControl:ChargingFaults(482)Charge Fault Cfg(8)[OC].



Introduction

The bq30z554-R1 device provides a feature-rich gas gauging solution for 2-series cell to 4-series cell battery-pack applications. The device has extended capabilities, including:

- SBS Data updates every 250 ms; values are filtered, not averaged
- Unseal via SHA-1 authentication for enhanced security
- Advanced Impedance Track™ Algorithm v3.75 with cell balancing during rest
- · Fast host-side calibration
- Fast QMAX learning
- AC peak power information capability (systems with TURBO mode operation)
- Manual FET Control Option
- Independent function enable/disable: FET, IT, BB, LT, PF, FUSE
- Cell and FET temperature configuration options and up to five independently selectable sources for each option
- Manufacturer access commands for test: FUSE, FET, toggle
- Extended lifetimes tracking
- · Black Box Recorder



Calibration

2.1 Overview

The bq30z554-R1 device has integrated routines that support calibration of current, voltage, and temperature readings, accessible after writing 0xF081 or 0xF082 to *ManufacturerAccess()* when the *ManufacturingStatus()[CAL]* bit is ON. While the calibration is active, the raw ADC data is available on *ManufacturerData()*. The device will stop reporting calibration data on *ManufacturerData()* if any other MAC commands are sent.

ManufacturerAccess()	Description
0x002D	Enables/Disables ManufacturingStatus()[CAL]
0xF080	Disable raw ADC data output on ManufacturerData()
0xF081	Output raw ADC data of voltage, current, and temperature on ManufacturerData()
0xF082	Output raw ADC data of voltage, current, and temperature on <i>ManufacturerData()</i> . This mode includes a shunt of the coulomb counter input.

The *ManufacturerData()* output format is: ZZYYaaAAbbBBccCCddDDeeEEffFFggGGhhHHiilIjjJJkkKKIlLL, where:

Value	Format	Description
ZZ	byte	8-bit counter, increments when raw ADC values are refreshed, typically every 250 ms
YY	byte	Output status ManufacturerAccess() = 0xF081: 1 ManufacturerAccess() = 0xF082: 2
AAaa	2's comp	ManufacturerAccess() = 0xF081: coulomb counter ManufacturerAccess() = 0xF082: internal shorted coulomb counter
BBbb	2's comp	Cell Voltage 1
CCcc	2's comp	Cell Voltage 2
DDdd	2's comp	Cell Voltage 3
EEee	2's comp	Cell Voltage 4
FFff	2's comp	Internal temperature sensor
GGgg	2's comp	Temperature Sensor 1
HHhh	2's comp	Temperature Sensor 2
Ilii	2's comp	Temperature Sensor 3
JJjj	2's comp	Temperature Sensor 4
KKkk	2's comp	PACK Voltage
LLII	2's comp	BAT Voltage



Combining Calibrations www.ti.com

2.2 Combining Calibrations

Current and voltage calibrations can be combined to shorten calibration time. For example:


Table 2-1. Combining Calibrations

Time (s) ZZ in ManufacturerData()		Action	
0	N	 Read DF values Apply 0 mA current Apply cell voltages Send 0xF082 to ManufacturerAccess() Poll ManufacturerData() for ZZ increment 	
0.25	N + 1	Poll ManufacturerData() for ZZ increment	
0.5	N + 2	Store ManufacturerData() block 1 Poll ManufacturerData() for ZZ increment	
0.75	N + 3	 Store ManufacturerData() block 2 Poll ManufacturerData() for ZZ increment 	
1	N + 4	 Store ManufacturerData() block 3 Poll ManufacturerData() for ZZ increment 	
1.25	N + 5	Store ManufacturerData() block 4 Apply Pack Voltage Send 0xF081 to ManufacturerAccess() Poll ManufacturerData() for ZZ increment	
1.5	N + 6	Poll ManufacturerData() for ZZ increment	
1.75	N + 7	Store ManufacturerData() block 5 Poll ManufacturerData() for ZZ increment	
2	N + 8	Store ManufacturerData() block 6 Poll ManufacturerData() for ZZ increment	
2.25	N + 9	Store ManufacturerData() block 7 Poll ManufacturerData() for ZZ increment	
2.5	N + 10	Store ManufacturerData() block 8 Apply calibration current Poll ManufacturerData() for ZZ increment	
2.75	N + 11	Poll ManufacturerData() for ZZ increment	
3	N + 12	 Store ManufacturerData() block 9 Poll ManufacturerData() for ZZ increment 	
3.25	N + 13	 Store ManufacturerData() block 10 Poll ManufacturerData() for ZZ increment 	
3.5	N + 14	Store ManufacturerData() block 11 Poll ManufacturerData() for ZZ increment	
3.75	N + 15	 Store ManufacturerData() block 12 Calculate CC offset using blocks 1 to 4 Calculate board offset using blocks 5 to 8 Calculate current gain using blocks 9 to 12 Calculate cell voltage gains using blocks 1 to 4 Calculate pack voltage gain using blocks 5 to 8 Write values to data flash 	



www.ti.com Cell Voltage Calibration

2.3 Cell Voltage Calibration



- 1. Apply known voltages in mV to the cell voltage inputs:
 - V_{CELLO} between VC4 pin and VSS pin
 - V_{CELL1} between VC3 pin and VC4 pin
 - V_{CELL2} between VC2 pin and VC3 pin
 - V_{CELL3} between VC1 pin and VC2 pin
- 2. If ManufacturerStatus()[CAL] = 0, send 0x002D to ManufacturerAccess() to enable the [CAL] flag.
- 3. Send 0xF081 or 0xF082 to *ManufacturerAccess()* to enable raw cell voltage output on *ManufacturerData()*.
- Poll ManufacturerData() until ZZ counter increments by 2 before reading data.
 Read the ADC conversion readings of cell voltages from ManufacturerData():
 - ADC_{CELL0} = AAaa of ManufacturerData()
 Is ADC_{CELL0} < 0x8000? If yes, use ADC_{CELL0}; otherwise, ADC_{CELL0} = -(0xFFFF AAaa + 0x0001).
 - ADC_{CELL1}= BBbb of ManufacturerData().
 Is ADC_{CELL1} < 0x8000? If yes, use ADC_{CELL1}; otherwise, ADC_{CELL1} = -(0xFFFF BBbb + 0x0001).
 - ADC_{CELL2} = CCcc of ManufacturerData()
 Is ADC_{CELL2} < 0x8000? If yes, use ADC_{CELL3}; otherwise, ADC_{CELL2} = -(0xFFFF CCcc + 0x0001).
 - ADC_{CELL3} = DDdd of ManufacturerData()
 Is ADC_{CELL3} < 0x8000? If yes, use ADC_{CELL3}; otherwise, ADC_{CELL3} = -(0xFFFF DDdd + 0x0001).
- 5. Average several readings for higher accuracy. Poll *ManufacturerData()* until ZZ increments, to indicate that updated values are available:
 - ADC_{CELLx} = [ADC_{CELLx}(reading n) + ...+ ADC_{CELLx}(reading 1)]/n
- 6. Calculate gain values:

Cell Scale
$$0 = \frac{V_{CELL0}}{ADC_{CELL0}} * 2^{16}$$

$$Cell Scale 1 = \frac{V_{CELL0} + V_{CELL1}}{ADC_{CELL0} + ADC_{CELL1}} * 2^{16}$$



BAT Voltage Calibration www.ti.com

$$Cell \ Scale \ 2 = \frac{V_{CELL0} + V_{CELL1} + V_{CELL2}}{ADC_{CELL0} + ADC_{CELL1} + ADC_{CELL2}} * 2^{16}$$

$$Cell \ Scale \ 3 = \frac{V_{CELL0} + V_{CELL1} + V_{CELL2} + V_{CELL3}}{ADC_{CELL0} + ADC_{CELL1} + ADC_{CELL2} + ADC_{CELL3}} * 2^{16}$$

- 7. Write the new Cell Scale 0, Cell Scale 1, Cell Scale 2, and Cell Scale 3 values to data flash.
- 8. Re-check the voltage reading. Repeat the steps if the readings are not accurate.
- 9. Send 0x002D to ManufacturerAccess() to clear the [CAL] flag if all calibration is complete.

2.4 **BAT Voltage Calibration**



- 1. Apply known voltages in mV to the voltage input:
 - V_{BAT} between VC4 pin and VSS pin
- 2. If ManufacturerStatus()[CAL] = 0, send 0x002D to ManufacturerAccess() to enable the [CAL] flag.
- 3. Send 0xF081 or 0xF082 to ManufacturerAccess() to enable raw cell voltage output on ManufacturerData().
- 4. Poll ManufacturerData() until ZZ counter increments by 2 before reading data.
- 5. Read ADC conversion readings of cell stack voltage from ManufacturerData():
 - ADC_{BAT} = LLII of ManufacturerData(), Is ADC_{BAT} < 0x8000? If yes, use ADC_{BAT}; otherwise, ADC_{BAT} = -(0xFFFF - LLII + 0x0001).
- 6. Average several readings for higher accuracy. Poll ManufacturerData() until ZZ increments to indicate that updated values are available:
 - $ADC_{BAT} = [ADC_{BAT}(reading n) + ... + ADC_{BAT}(reading 1)]/n$

7. Calculate gain value:
$$BAT \ Gain = \frac{V_{BAT}}{ADC_{BAT}} * 2^{16}$$

- 8. Write the new **BAT Gain** value to data flash.
- 9. Re-check the voltage reading, and repeat steps if the readings are not accurate.
- 10. Send 0x002D to ManufacturerAccess() to clear the [CAL] flag if all calibration is complete.

2.5 **PACK Voltage Calibration**



- 1. Apply known voltages in mV to the voltage input:
 - V_{PACK} between PACK pin and VSS pin
- 2. If ManufacturerStatus()[CAL] = 0, send 0x002D to ManufacturerAccess() to enable the [CAL] flag.
- 3. Send 0xF081 or 0xF082 to ManufacturerAccess() to enable raw cell voltage output on ManufacturerData().
- 4. Poll ManufacturerData() until ZZ increments by 2 before reading data.




www.ti.com Current Calibration

- 5. Read ADC conversion readings of pack voltage from ManufacturerData():
 - ADC_{PACK} = KKkk of *ManufacturerData()* Is ADC_{PACK} < 0x8000? If yes, use ADC_{PACK}, otherwise ADC_{PACK} = -(0xFFFF KKkk + 0x0001)
- 6. Average several readings for higher accuracy. Poll *ManufacturerData()* until ZZ increments to indicate that updated values are available:
 - ADC_{PACK} = [ADC_{PACK}(reading n) + ... + ADC_{PACK}(reading 1)]/n
- 7. Calculate gain value:

$$PACK \ Gain = \frac{V_{PACK}}{ADC_{PACK}} * 2^{16}$$

- 8. Write the new PACK Gain value to data flash.
- 9. Re-check voltage reading; repeat Steps 4 to 6 if the readings are not accurate.
- 10. Send 0x002D to ManufacturerAccess() to clear the [CAL] flag if all calibration is complete.

2.6 Current Calibration



2.6.1 Offset Calibration

- 1. Apply a known current of 0 mA, and ensure no current is flowing through the sense resistor connected between the SRP and SRN pins.
- 2. If ManufacturerStatus()[CAL] = 0, send 0x002D to ManufacturerAccess() to enable the [CAL] flag.
- 3. Send 0xF082 to ManufacturerAccess() to enable raw cell voltage output on ManufacturerData().
- 4. Poll ManufacturerData() until ZZ increments by 2 before reading data.
- 5. Read the ADC conversion readings of current from ManufacturerData():
 - ADC_{CC} = AAaa of ManufacturerData()
 Is ADC_{CC} < 0x8000? If yes, use ADC_{CC}; otherwise, ADC_{CC} = -(0xFFFF AAaa + 0x0001).
- 6. Average several readings for higher accuracy. Poll *ManufacturerData()* until ZZ increments to indicate that updated values are available:
 - ADC_{CC} = [ADC_{CC}(reading n) + ... + ADC_{CC}(reading 1)]/n
- 7. Read Coulomb Counter Offset Samples from data flash.
- Calculate offset value:
 - $CC ext{ offset} = ADC_{CC} \times (Coulomb ext{ Counter Offset Samples})$
- 9. Write the new CC Offset value to data flash.
- 10. Re-check the current reading. Repeat the steps if the readings are not accurate.



Current Calibration www.ti.com

11. Send 0x002D to ManufacturerAccess() to clear the [CAL] flag if all calibration is complete.

2.6.2 Board Offset Calibration

- 1. Ensure that Offset Calibration was performed first.
- 2. Apply a known current of 0 mA, and ensure no current is flowing through the sense resistor connected between the SRP and SRN pins.
- 3. If ManufacturerStatus()[CAL] = 0, send 0x002D to ManufacturerAccess() to enable the [CAL] flag.
- 4. Send 0xF081 to ManufacturerAccess() to enable raw cell voltage output on ManufacturerData().
- 5. Poll ManufacturerData() until ZZ increments by 2 before reading data.
- 6. Read the ADC conversion readings of current from ManufacturerData():
 - ADC_{CC} = AAaa of ManufacturerData()
 Is ADC_{CC} < 0x8000? If yes, use ADC_{CC}; otherwise, ADC_{CC} = -(0xFFFF AAaa + 0x0001).
- 7. Average several readings for higher accuracy. Poll *ManufacturerData()* until ZZ increments to indicate that updated values are available:
 - ADC_{cc} = [ADC_{cc}(reading n) + ... + ADC_{cc}(reading 1)]/n
- 8. Read Coulomb Counter Offset Samples from data flash.
- 9. Calculate offset value:
 - Board offset = (ADC_{CC} CC Offset) x Coulomb Counter Offset Samples
- 10. Write the new **Board Offset** value to data flash.
- 11. Re-check the current reading. Repeat the steps if the readings are not accurate.
- 12. Send 0x002D to ManufacturerAccess() to clear the [CAL] flag if all calibration is complete.

2.6.3 Gain Calibration

- 1. Ensure that Offset and Board Offset Calibrations were performed first.
- 2. Apply a known current (typically 1 A to 2 A), and ensure I_{CC} is flowing through the sense resistor connected between the SRP and SRN pins.
- 3. If ManufacturerStatus()[CAL] = 0, send 0x002D to ManufacturerAccess() to enable the [CAL] flag.
- 4. Send 0xF081 to ManufacturerAccess() to enable raw CC output on ManufacturerData().
- 5. Poll *ManufacturerData()* until ZZ increments by 2 before reading data.
- 6. Read the ADC conversion readings of current from ManufacturerData():
 - ADC_{CC} = AAaa of ManufacturerData()
 Is ADC_{CC} < 0x8000? If yes, use ADC_{CC}; otherwise, ADC_{CC} = -(0xFFFF AAaa + 0x0001).
- 7. Average several readings for higher accuracy. Poll *ManufacturerData()* until ZZ increments to indicate that updated values are available:
 - ADC_{cc} = [ADC_{cc}(reading n) + ... + ADC_{cc}(reading 1)]/n
- 8. Read Coulomb Counter Offset Samples from data flash.
- 9. Calculate gain values:


$$CC \ Gain = \frac{I_{CC}}{ADC_{CC} - \frac{Board \ Offset + CC \ Offset}{Coulomb \ Counter \ Offset \ Samples}}$$

$$Capacity \ Gain = CC \ Gain * 298261.6178$$

- 10. Write the new CC Gain and Capacity Gain values to data flash.
- 11. Re-check the current reading. Repeat the steps if the readings are not accurate.
- 12. Send 0x002D to ManufacturerAccess() to clear the [CAL] flag if all calibration is complete.



2.7 Temperature Calibration



2.7.1 Internal Temperature Sensor Calibration

- 1. Apply a known temperature in 0.1°C, and ensure that temperature Temp_{TINT} is applied to the device.
- 2. Read the TINT offset old from Internal Temp Offset.
- 3. Read the reported temperature from Temperatures():
 - TINT = AAaa of Temperatures()

Is TINT > 0? If yes, TINT = AAaa - 2732.

- 4. Calculate temperature offset: $TINT \ offset = TEMP_{TINT} TINT + TINT \ offset_{old}$
- 5. Write the new Internal Temp Offset value to data flash.
- 6. Re-check the *Temperatures()* reading. Repeat the steps if the readings are not accurate.

2.7.2 TS1-TS4 Calibration

- 1. Apply a known temperature in 0.1°C, and ensure that temperature TEMP_{TSx} is applied to the thermistor connected to the TSx pin. "TSx" refers to TS1, TS2, TS3, or TS4, whichever is applicable.
- 2. Read the TSx offset_{old} from *External x Temp Offset*, where x is 1, 2, 3, or 4.
- 3. Read the appropriate temperature from the *Temperatures()* block as TSx.
- 4. Calculate the temperature offset: $TSx \ offset = TEMP_{TSx} TSx + TSx \ offset_{old}$ where x is 1, 2, 3, or 4.
- 5. Write the new *External x Temp Offset* (where x is 1, 2, 3, or 4) value to data flash.
- 6. Re-check the *Temperatures()* reading. Repeat the steps if the readings are not accurate.



Protections

3.1 Introduction

All of the protection items can be enabled or disabled under Settings/Enabled Protections 0–15 and Settings/Enabled Protections 16–31.

3.2 Cell Undervoltage Protection

The bq30z554-R1 device can detect undervoltage in batteries and protect cells from damage by preventing further discharge.

Status	Condition	Action
Normal	All Cell voltages in Voltages() > Threshold	SafetyAlert()[CUV] = 0BatteryStatus()[TDA] = 0
Alert	Any Cell voltages in <i>Voltages()</i> ≤ <i>Threshold</i>	SafetyAlert()[CUV] = 1BatteryStatus()[TDA] = 1
Trip	Any Cell voltages in <i>Voltages()</i> continuous ≤ <i>Threshold</i> for <i>Delay</i> duration	 SafetyAlert()[CUV] = 0 SafetyStatus()[CUV] = 1 BatteryStatus()[FD] = 1 Discharging is not allowed. BatteryStatus[TDA] = 0
Recovery	SafetyStatus()[CUV] = 1 AND All Cell voltages in Voltages() > Recovery AND (CUV_RECOV_CHG = 0 OR (CUV_RECOV_CHG = 1 AND Charging detected))	 SafetyStatus()[CUV] = 0 BatteryStatus()[FD] = 0 Discharging is allowed.

3.3 Cell Undervoltage Compensated Protection

The bq30z554-R1 device can detect undervoltage in batteries and protect cells from damage by preventing further discharge. The protection is compensated by the *Current()* * CellResistance4..1.

Status	Condition	Action
Normal	All Cell voltages in Voltages() – Current() × Cell Resistance > Threshold	SafetyAlert()[CUVC] = 0BatteryStatus()[TDA] = 0
Alert Any Cell voltages in Voltages() – Current() × Cell Resistance ≤ Threshold		SafetyAlert()[CUVC] = 1BatteryStatus()[TDA] = 1
Trip	Any Cell voltages in <i>Voltages() – Current()</i> × Cell Resistance continuous ≤ Threshold for Delay duration	 SafetyAlert()[CUVC] = 0 SafetyStatus()[CUVC] = 1 BatteryStatus()[FD] = 1 BatteryStatus()[TDA] = 0 Discharging is not allowed.
Recovery	SafetyStatus()[CUVC] = 1 AND All Cell voltages in Voltages() > Recovery AND (CUV_RECOV_CHG = 0 OR (CUV_RECOV_CHG = 1 AND Charging detected))	 SafetyStatus()[CUVC] = 0 BatteryStatus()[FD] = 0 Discharging is allowed.



3.4 Cell Overvoltage Protection

The device can detect cell overvoltage in batteries and protect cells from damage by preventing further charging.

Status	Condition	Action
Normal	Temperature() ≤ T2 AND all Cell voltages in Voltages() < Threshold Low Temp	SafetyAlert()[COV] = 0
Normal	T2 < Temperature() ≤ T3 AND all Cell voltages in Voltages() < Threshold Standard Temp	SafetyAlert()[COV] = 0
Normal	T3 < Temperature() AND all Cell voltages in Voltages() < Threshold High Temp	SafetyAlert()[COV] = 0
Normal	T5 < Temperature() ≤ T6 AND all Cell voltages in Voltages() < Threshold Rec Temp	SafetyAlert()[COV] = 0
Alert	Temperature() ≤ T2 AND any Cell voltages in Voltages() ≥ Threshold Low Temp	SafetyAlert()[COV] = 1
Alert	T2 < Temperature() ≤ T3 AND any Cell voltages in Voltages() ≥ Threshold Standard Temp	SafetyAlert()[COV] = 1
Alert	T3 < Temperature() AND any Cell voltages in Voltages() ≥ Threshold High Temp	SafetyAlert()[COV] = 1
Alert	T5 < Temperature() ≤ T6 AND any Cell voltages in Voltages() ≥ Threshold Rec Temp	SafetyAlert()[COV] = 1
Trip	Temperature() ≤ T2 AND any Cell voltages in Voltages() continuous ≥ Threshold Low Temp for Delay duration	 SafetyAlert()[COV] = 0 SafetyStatus()[COV] = 1 BatteryStatus()[TCA] = 1 If charging, BatteryStatus()[OCA] = 1 Charging is not allowed.
Trip	T2 < Temperature() ≤ T3 AND any Cell voltages in Voltages() continuous ≥ Threshold Standard Temp for Delay duration	 SafetyAlert()[COV] = 0 SafetyStatus()[COV] = 1 BatteryStatus()[TCA] = 1 If charging, BatteryStatus()[OCA] = 1 Charging is not allowed.
Trip	T3 < Temperature() AND any Cell voltages in Voltages() continuous ≥ Threshold High Temp for Delay duration	 SafetyAlert()[COV] = 0 SafetyStatus()[COV] = 1 BatteryStatus()[TCA] = 1 If charging, BatteryStatus()[OCA] = 1 Charging is not allowed.
Trip	T5 < Temperatures() ≤ T6 AND any Cell voltages in Voltages() continuous ≥ Threshold Rec Temp for Delay duration	 SafetyAlert()[COV] = 0 SafetyStatus()[COV] = 1 BatteryStatus()[TCA] = 1 If charging, BatteryStatus()[OCA] = 1 Charging is not allowed.
Recovery	SafetyStatus()[COV] = 1 AND Temperatures() ≤ T2 AND all Cell voltages in Voltages() < Recovery Low Temp	 SafetyAlert()[COV] = 0 BatteryStatus()[TCA] = 0 BatteryStatus()[OCA] = 0 Charging is allowed.
Recovery	SafetyStatus()[COV] = 1 AND T2 < Temperatures() ≤ T3 AND all Cell voltages in Voltages() < Recovery Standard Temp	 SafetyAlert()[COV] = 0 BatteryStatus()[TCA] = 0 BatteryStatus()[OCA] = 0 Charging is allowed.
Recovery	SafetyStatus()[COV] = 1 AND T3 < Temperatures() AND all Cell voltages in Voltages() < Recovery High Temp	 SafetyStatus()[COV] = 0 BatteryStatus()[TCA] = 0 BatteryStatus()[OCA] = 0 Charging is allowed.



Status	Condition	Action
Recovery	SafetyStatus()[COV] = 1 AND T5 < Temperatures() ≤ T6 AND all Cell voltages in Voltages() < Recovery Rec Temp	 SafetyStatus()[COV] = 0 BatteryStatus()[TCA] = 0 BatteryStatus()[OCA] = 0 Charging is allowed.

3.5 Overcurrent in Charge Protection

The device has two independent overcurrent in charge protections that can be set to different current and delay thresholds to accommodate different charging behaviors.

Status	Condition	Action
Normal	Current() < OCC1:Threshold	SafetyAlert()[OCC1] = 0
Normal	Current() < OCC2:Threshold	SafetyAlert()[OCC2] = 0
Alert	Current() ≥ OCC1:Threshold	SafetyAlert()[OCC1] = 1
Alert	Current() ≥ OCC2:Threshold	SafetyAlert()[OCC2] = 1
Trip	Current() continuous ≥ OCC1:Threshold for OCC1:Delay duration	 SafetyAlert()[OCC1] = 0 SafetyStatus()[OCC1] = 1 BatteryStatus()[TCA] = 1 Charging is not allowed.
Trip	Current() continuous ≥ OCC2:Threshold for OCC2:Delay duration	 SafetyAlert()[OCC2] = 0 SafetyStatus()[OCC2] = 1 BatteryStatus()[TCA] = 1 Charging is not allowed.
Recovery	[SafetyStatus()[OCC1] = 1 OR SafetyStatus()[OCC2] = 1] AND recovery delay timer running > OCC:Recovery Delay Time from the time that Current() < OCC:Recovery Threshold	 SafetyStatus()[OCC1] = 0 SafetyStatus()[OCC2] = 0 BatteryStatus()[TCA] = 0 Charging is allowed.

3.6 Overcurrent in Discharge Protection

The device has two independent overcurrent in discharge protections that can be set to different current and delay thresholds to accommodate different load behaviors.

Status	Condition	Action
Normal	Current() > OCD1:Threshold	SafetyAlert()[OCD1] = 0
Normal	Current() > OCD2:Threshold	SafetyAlert()[OCD2] = 0
Alert	Current() ≤ OCD1:Threshold	SafetyAlert()[OCD1] = 1
Alert	Current() ≤ OCD2:Threshold	SafetyAlert()[OCD2] = 1
Trip	Current() continuous ≤ OCD1:Threshold for OCD1:Delay duration	 SafetyAlert()[OCD1] = 0 SafetyStatus()[OCD1] = 1 Discharging is not allowed.
Trip	Current() continuous ≤ OCD2:Threshold for OCD2:Delay duration	 SafetyAlert()[OCD2] = 0 SafetyStatus()[OCD2] = 1 Discharging is not allowed.
Recovery	[SafetyStatus()[OCD1] = 1 OR SafetyStatus()[OCD2] = 1] AND recovery delay timer running > OCD:Recovery Delay Time from the time that Current() < OCD:Recovery Threshold	 SafetyStatus()[OCD1] = 0 SafetyStatus()[OCD2] = 0 Discharging is allowed.



3.7 Hardware-Based Protection

The bq30z554-R1 device has three main hardware-based protections—OLD, SCC, and SCD—with adjustable current and delay time. The data flash protection Threshold and Delay settings are documented in Appendix A. By setting the **AFE State Control[RSNS]** flag, the threshold values will be divided in half. The Threshold settings are in mV, thus, the actual current that triggers the protection is based on the RSNS resistor used in the schematic design.

All the hardware-based protections provide a short term Trip/Alert/Recovery protection to account for a current spike as well as a Trip/Alert/Latch protection for true faulty condition. The latch feature also stops the FETs from toggling on and off continuously, preventing damage to the FETs.

In general, when a fault is detected after the Delay time, both CHG and DSG FETs will be disabled (Trip stage). An internal fault counter will be incremented (Alert stage). Since both FETs are off, the current will drop to 0 mA. After Recovery time, the CHG and DSG FETs will be turned on again (Recovery stage).

If the alert is caused by a current spike, the fault count will be decremented after Counter Dec Delay time. If this is a true faulty condition, the device will enter the Trip stage after Delay time, and repeat the Trip/Alert/Recovery cycle. The internal fault counter is incremented every time the device goes through the Trip/Alert/Recovery cycle. Once the internal fault counter hits the Latch Limit, the protection enters a Latch stage and the fault will only be cleared through the Latch Reset condition.

The Trip/Alert/Recovery/Latch stages are documented in each hardware-based protection sections below.

3.7.1 Overload in Discharge Protection

The bq30z554-R1 device has a hardware-based overload in discharge protection with adjustable current and delay.

Status	Condition	Action
Normal	Current() > (Threshold / RSNS)	• SafetyAlert()[OLD] = 0, if OLD counter = 0
Trip	Current() continuous ≤ (Threshold / RSNS) for Delay duration	 SafetyStatus()[OLD] = 1 CHG FET and DSG FET disabled Increment OLD counter
Alert	OLD counter > 0	 SafetyAlert()[OLD] = 1 Decrement OLD counter by one after each Counter Dec Delay period
Recovery	SafetyStatus()[OLD] = 1 AND SafetyStatus()[OLDL] = 0 AND Recovery duration wait time	 SafetyStatus()[OLD] = 0 CHG FET and DSG FET return to normal
Latch	OLD counter ≥ Latch Limit	 SafetyStatus()[OLD] = 0 SafetyStatus()[OLDL] = 1 Reset OLD counter Disable recovery method Enable reset method
Latch Reset (NR = 0)	SafetyStatus()[OLDL] = 1 AND System Configuration[NR] = 0 AND Low-high-low transition on PRES pin	 SafetyStatus()[OLDL] = 0 CHG FET and DSG FET return to normal Disable reset method Enable recovery method
Latch Reset (NR = 1)	SafetyStatus()[OLDL] = 1 AND System Configuration[NR] = 1 AND Reset duration wait time	 SafetyStatus()[OLDL] = 0 CHG FET and DSG FET return to normal Disable reset method Enable recovery method

Hardware-Based Protection www.ti.com

3.7.2 Short Circuit in Charge Protection

The bq30z554-R1 device has a hardware-based short circuit in charge protection with adjustable current and delay.

Status	Condition	Action
Normal	Current() < (Threshold[2:0] / RSNS)	• SafetyAlert()[SCC] = 0, if SCC counter = 0
Trip	Current() continuous ≥ (Threshold[2:0] / RSNS) for Threshold[7:4] duration	 SafetyStatus()[SCC] = 1 If charging, BatteryStatus()[TCA] = 1 CHG FET and DSG FET disabled Increment SCC counter
Alert	SCC counter > 0	 SafetyAlert()[SCC] = 1 Decrement SCC counter by one after each Counter Dec Delay period
Recovery	SafetyStatus()[SCC] = 1 AND SafetyStatus()[SCCL] = 0 AND Recovery duration wait time	 SafetyStatus()[SCC] = 0 BatteryStatus()[TCA] = 0 CHG FET and DSG FET return to normal
Latch	SCC counter ≥ Latch Limit	 SafetyStatus()[SCC] = 0 SafetyStatus()[SCCL] = 1 Reset SCC counter Disable recovery method Enable reset method
Latch Reset (NR = 0)	SafetyStatus()[SCCL] = 1 AND System Configuration[NR] = 0 AND Low-high-low transition on PRES pin	 SafetyStatus()[SCCL] = 0 BatteryStatus()[TCA] = 0 CHG FET and DSG FET return to normal Disable reset method Enable recovery method
Latch Reset (NR = 1)	SafetyStatus()[SCCL] = 1 AND System Configuration[NR] = 1 AND Reset duration wait time	 SafetyStatus()[SCCL] = 0 BatteryStatus()[TCA] = 0 CHG FET and DSG FET return to normal Disable reset method Enable recovery method

3.7.3 Short Circuit in Discharge Protection

The device has a hardware-based short circuit in discharge protection with adjustable current and delay.

Status	Condition	Action
Normal	Current() > (Threshold[2:0] / RSNS)	• SafetyAlert()[SCD] = 0, if SCD counter = 0
Trip	Current() continuous ≤ (Threshold[2:0] / RSNS) for Threshold[7:4] duration	 SafetyStatus()[SCD] = 1 CHG FET and DSG FET disabled Increment SCD counter
Alert	SCD counter > 0	 SafetyAlert()[SCD] = 1 Decrement SCD counter by one after each Counter Dec Delay period
Recovery	SafetyStatus()[SCD] = 1 AND SafetyStatus()[SCDL] = 0 AND Recovery duration wait time	 SafetyStatus()[SCD] = 0 CHG FET and DSG FET return to normal
Latch	SCD counter ≥ Latch limit	 SafetyStatus()[SCD] = 0 SafetyStatus()[SCDL] = 1 Reset SCD counter Disable recovery method Enable reset method



Status	Condition	Action
Latch Reset (NR = 0)	SafetyStatus()[SCDL] = 1 AND System Configuration[NR] = 0 AND Low-high-low transition on PRES pin	 SafetyStatus()[SCDL] = 0 CHG FET and DSG FET return to normal Disable reset method Enable recovery method
Latch Reset (NR = 1)	SafetyStatus()[SCCL] = 1 AND System Configuration[NR] = 1 AND Reset duration wait time	 SafetyStatus()[SCDL] = 0 CHG FET and DSG FET return to normal Disable reset method Enable recovery method

3.8 Overtemperature in Charge Protection

The bq30z554-R1 device has an overtemperature protection for cells in charge direction.

Status	Condition	Action
Normal	Cell Temperature in <i>Temperatures()</i> < Threshold AND charging	SafetyAlert()[OTC] = 0
Alert	Cell Temperature in <i>Temperatures()</i> ≥ Threshold AND charging	SafetyAlert()[OTC] = 1
Trip	Cell Temperature in <i>Temperatures()</i> ≥ Threshold AND charging for Delay duration	 SafetyAlert()[OTC] = 0 SafetyStatus()[OTC] = 1 BatteryStatus()[OTA] = 1 BatteryStatus()[TCA] = 1 Charging Disabled if Temperature Configuration[OTFET] = 1
Recovery	SafetyStatus()[OTC] AND Cell Temperature in Temperatures() < Recovery	 SafetyStatus()[OTC] = 0 BatteryStatus()[OTA] = 0 BatteryStatus()[TCA] = 0 Charging is allowed if Temperature Configuration[OTFET] = 1.

3.9 Overtemperature in Discharge Protection

The device has an overtemperature protection for cells in discharge.

Status	Condition	Action
Normal	Cell Temperature in <i>Temperatures()</i> < Threshold AND discharging	SafetyAlert()[OTD] = 0
Alert	Cell Temperature in <i>Temperatures()</i> ≥ Threshold AND discharging	SafetyAlert()[OTD] = 1
Trip	Cell Temperature in Temperatures() ≥ Threshold AND discharging for Delay duration	 SafetyAlert()[OTD] = 0 SafetyStatus()[OTD] = 1 BatteryStatus()[OTA] = 1 Discharging Disabled if Temperature Configuration[OTFET] = 1
Recovery	SafetyStatus()[OTD] AND Cell Temperature in Temperatures() < Recovery	 SafetyStatus()[OTD] = 0 BatteryStatus()[OTA] = 0 Discharging is allowed if Temperature Configuration[OTFET] = 1.

3.10 Overtemperature FET Protection

The device has an overtemperature protection to limit the FET temperature.



Status	Condition	Action
Normal	FET Temperature in <i>Temperatures()</i> < Threshold	• SafetyAlert()[OTF] = 0
Alert	FET Temperature in <i>Temperatures()</i> ≥ Threshold	• SafetyAlert()[OTF] = 1
Trip	FET Temperature in <i>Temperatures()</i> ≥ Threshold for Delay duration	 SafetyAlert()[OTF] = 0 SafetyStatus()[OTF] = 1 BatteryStatus()[OTA] = 1 CHG FET and DSG FET off if Temperature Configuration[OTFET] = 1
Recovery	SafetyStatus()[OTF] AND FET Temperature in Temperatures() < Recovery	 SafetyStatus()[OTD] = 0 BatteryStatus()[OTA] = 0 CHG FET and DSG FET return to normal

3.11 SBS Host Watchdog Protection

The device can check for periodic communication over SBS and prevent usage of the battery pack if no valid communication is detected.

Status	Condition	Action
Trip	No valid SBS transaction for Delay duration	SafetyStatus()[HWD] = 1Charging disabled, CHG FET off
Recovery	Valid SBS transaction detected	 SafetyStatus()[HWD] = 0 CHG FET returns to normal, charging is allowed.

3.12 Precharge Timeout Protection

The device can measure the precharge time and stop charging if it exceeds the adjustable period.

Status	Condition	Action
Enable	Current() > Charge Threshold AND ChargingStatus()[PV] = 1	 Start PTO timer SafetyAlert()[PTO] = 1 SafetyAlert()[PTOS] = 0
Suspend or Recovery	Current() < Suspend Threshold	 Stop PTO timer SafetyAlert()[PTO] = 1 SafetyAlert()[PTOS] = 1
Trip	PTO time > Delay	 Stop PTO timer SafetyAlert()[PTO] = 0 SafetyStatus()[PTO] = 1 BatteryStatus()[TCA] = 1 Charging is not allowed.
Reset	SafetyStatus()[PTO] = 1 AND System Configuration[NR] = 0 AND low-high-low transition on PRES	 Stop and reset PTO timer SafetyAlert()[PTO] = 0 SafetyAlert()[PTOS] = 0 SafetyStatus()[PTO] = 0 BatteryStatus()[TCA] = 0 Charging is allowed.
Reset	SafetyStatus()[PTO] = 1 AND Discharge by an amount of Reset	 Stop and reset PTO timer SafetyAlert()[PTO] = 0 SafetyAlert()[PTOS] = 0 SafetyStatus()[PTO] = 0 BatteryStatus()[TCA] = 0 Charging is allowed.



3.13 Fast Charge Timeout Protection

The device can measure the charge time, and stop charging if it exceeds the adjustable period.

Status	Condition	Action
Enable	Current() > Charge Threshold AND (ChargingStatus()[LV] = 1 OR ChargingStatus()[MV] = 1 OR ChargingStatus()[HV] = 1)	 Start CTO timer SafetyAlert()[CTO] = 1 SafetyAlert()[CTOS] = 0
Suspend or Recovery	Current() < Suspend Threshold	 Stop CTO timer SafetyAlert()[CTO] = 1 SafetyAlert()[CTOS] = 1
Trip	CTO time > Delay	 Stop CTO timer SafetyAlert()[CTO] = 0 SafetyStatus()[CTO] = 1 BatteryStatus()[TCA] = 1 Charging is not allowed.
Reset	SafetyStatus()[CTO] = 1 AND System Configuration[NR] = 0 AND low-high-low transition on PRES	 Stop and reset CTO timer SafetyAlert()[CTO] = 0 SafetyAlert()[CTOS] = 0 SafetyStatus()[CTO] = 0 BatteryStatus()[TCA] = 0 Charging is allowed.
Reset	SafetyStatus()[CTO] = 1 AND Discharge by an amount of Reset	 Stop and reset CTO timer SafetyAlert()[CTO] = 0 SafetyAlert()[CTOS] = 0 SafetyStatus()[CTO] = 0 BatteryStatus()[TCA] = 0 Charging is allowed.

3.14 Overcharge Protection

The device can prevent continuing charging if the pack is charged in excess over FullChargeCapacity().

Status	Condition	Action
Normal	RemainingCapacity() < FullChargeCapacity()	• SafetyAlert()[OC] = 0
Alert	RemainingCapacity() ≥ FullChargeCapacity()	SafetyAlert()[OC] =
Trip	RemainingCapacity() ≥ FullChargeCapacity() + Threshold	 SafetyAlert()[OC] = 0 SafetyStatus()[OC] = 1 BatteryStatus()[TCA] = 1 Charging is not allowed.
Recovery	SafetyStatus()[OC] = 1 System Configuration[NR] = 0 AND (Low-high-low transition on PRES pin	 SafetyStatus()[OC] = 0 BatteryStatus()[TCA] = 0 Charging is allowed.
Recovery	SafetyStatus()[OC] =1 System Configuration[NR] = 1 AND continuous discharge of Recovery OR RemainingStateOfCharge() < RSOC Recovery	 SafetyStatus()[OC] = 0 BatteryStatus()[TCA] = 0 Charging is allowed.

3.15 Over-ChargingVoltage() Protection

The device can stop charging if it measures a difference between the requested *ChargingVoltage()* and the delivered voltage from the charger.



Status	Condition	Action
Normal	PackVoltage() < ChargingVoltage() + CHGV:Threshold	SafetyAlert()[CHGV] = 0
Alert	PackVoltage() ≥ ChargingVoltage() + CHGV:Threshold	SafetyAlert()[CHGV] = 1
Trip	PackVoltage() continuous ≥ ChargingVoltage() + CHGV:Threshold for CHGV:Delay period	 SafetyAlert()[CHGV] = 0 SafetyStatus()[CHGV] = 1 BatteryStatus()[TCA] = 1 Charging is not allowed.
Recovery	SafetyStatus()[CHGV] = 1 AND PackVoltage() ≤ ChargingVoltage() + CHGV Recovery	 SafetyStatus()[CHGV] = 0 BatteryStatus()[TCA] = 0 Charging is allowed.

3.16 Over-ChargingCurrent() Protection

The device can stop charging if it measures a difference between the requested *ChargingCurrent()* and the delivered current from the charger. This protection is designed to recover by a discharge event; therefore, *CHGC Recovery* should be set to a negative value in the data flash.


Status	Condition	Action
Normal	Current() < ChargingCurrent() + CHGC:Threshold	SafetyAlert()[CHGC] = 0
Alert	Current() ≥ ChargingCurrent() + CHGC:Threshold	SafetyAlert()[CHGC] = 1
Trip	Current() continuous ≥ ChargingCurrent() + CHGC:Threshold for CHGC:Delay period	 SafetyAlert()[CHGC] = 0 SafetyStatus()[CHGC] = 1 BatteryStatus()[TCA] = 1 Charging is not allowed.
Recovery	SafetyStatus()[CHGC] = 1 AND Current() ≤ CHGC Recovery	 SafetyStatus()[CHGC] = 0 BatteryStatus()[TCA] = 0 Charging is allowed.



Advanced Charging Algorithm

4.1 Introduction

The device can change the values of *ChargingVoltage()* and *ChargingCurrent()* based on *Temperatures()* and **Cell Voltage1..4()**. Its flexible charging algorithm is JEITA compatible and can also meet ATL cell charge requirements. The *ChargingStatus()* register shows the state of the charging algorithm.



4.2 Charge Temperature Ranges

The measured temperature is segmented into several temperature ranges. The charging algorithm adjusts *ChargingCurrent()* and *ChargingVoltage()* according to the temperature range. The temperature ranges set in the data flash need to adhere to the following format:

 $T1 \le T2 \le T5 \le T6 \le T3 \le T4$

Status Condition		Action
Under Temp	T1 < Temperature() > T1 + Hysteresis Temp	ChargingStatus()[UT] = 0ChargingStatus()[LT] = 1
Low Temp	Temperature() < T1	ChargingStatus()[LT] = 0ChargingStatus()[UT] = 1



Voltage Range www.ti.com

Status	Condition	Action
Low Temp	Temperature() > T2 + Hysteresis Temp	ChargingStatus()[LT] = 0ChargingStatus()[STL] = 1
Standard Temp Low	Temperature() < T2	ChargingStatus()[STL] = 0ChargingStatus()[LT] = 1
Standard Temp Low	Temperature() > T5 + Hysteresis Temp	ChargingStatus()[STL] = 0ChargingStatus()[RT] = 1
Recommended Temp	Temperature() < T5	ChargingStatus()[RT] = 0ChargingStatus()[STL] = 1
Recommended Temp	Temperature() > T6	ChargingStatus()[RT] = 0ChargingStatus()[STH] = 1
Standard Temp High	Temperature() < T6 – Hysteresis Temp	ChargingStatus()[STH] = 0ChargingStatus()[RT] = 1
Standard Temp High	Temperature() > T3	ChargingStatus()[STH] = 0ChargingStatus()[HT] = 1
High Temp	Temperature() < T3 – Hysteresis Temp	ChargingStatus()[HT] = 0ChargingStatus()[STH] = 1
High Temp	Temperature() > T4	ChargingStatus()[HT] = 0ChargingStatus()[OT] = 1
Over Temp	Temperature() < T4 – Hysteresis Temp	ChargingStatus()[OT] = 0ChargingStatus()[HT] = 1

4.3 Voltage Range

The measured cell voltage is segmented into several voltage ranges. The charging algorithm adjusts ChargingCurrent() according to the temperature range and voltage range. The voltage ranges set in the data flash need to adhere to the following format:

Charging Voltage Low \leq Charging Voltage Med \leq Charging Voltage High \leq x Temp Charging: Voltage

Status	Condition	Action
Not Precharge	Any Cell Voltages in <i>Voltages()</i> < Charging Voltage Low	 ChargingStatus()[LV] = 0 ChargingStatus()[MV] = 0 ChargingStatus()[HV] = 0 ChargingStatus()[PV] = 1
Precharge	Precharge All Cell Voltages in Voltages() > Charging Voltage • ChargingStatus()[PV] = 0 • ChargingStatus()[LV] = 1	
Low	Any Cell Voltage in <i>Voltages()</i> > Charging Voltage Medium	ChargingStatus()[LV] = 0ChargingStatus()[MV] = 1
Medium		ChargingStatus()[MV] = 0ChargingStatus()[HV] = 1
High — Voltage Hysteresis AND no charging		ChargingStatus()[HV] = 0ChargingStatus()[MV] = 1
Medium	All Cell Voltages in <i>Voltages()</i> < Charging Voltage Medium – Voltage Hysteresis AND no charging detected	ChargingStatus()[MV] = 0ChargingStatus()[LV] = 1

4.4 Charging Current

The *ChargingCurrent()* value changes depending on the detected temperature and voltage per the charging algorithm.



Charging Voltage www.ti.com

NOTE: Table priority is top to bottom.

Temp Range	Voltage Range	Condition	Action
Any	Any	OperationStatus()[PRES] = 0 OR SafetyStatus()[COV] = 1 OR SafetyStatus()[OCC] = 1 OR SafetyStatus()[ASCC] = 1 OR SafetyStatus()[ASCCL] = 1 OR SafetyStatus()[CTO] = 1 OR SafetyStatus()[CTO] = 1 OR	ChargingCurrent() = 0
UT or OT	Any	_	ChargingCurrent() = 0
Any	PV	_	ChargingCurrent() = Pre-Charging:Current
Any	LV, MV, or HV	ChargingStatus()[MCHG] = 1	ChargingCurrent() = Maintenance Charging:Current
	LV	_	ChargingCurrent() = Low Temp Charging:Current Low
LT	MV	-	ChargingCurrent() = Low Temp Charging:Current Med
	HV	-	ChargingCurrent() = Low Temp Charging:Current High
	LV	_	ChargingCurrent() = Standard Temp Charging:Current Low
STL or STH	MV	_	ChargingCurrent() = Standard Temp Charging:Current Med
	HV	_	ChargingCurrent() = Standard Temp Charging:Current High
	LV	_	ChargingCurrent() = Rec Temp Charging:Current Low
RT	MV	-	ChargingCurrent() = Rec Temp Charging:Current Med
	HV	-	ChargingCurrent() = Rec Temp Charging:Current High
нт	LV	_	ChargingCurrent() = High Temp Charging:Current Low
	MV	_	ChargingCurrent() = High Temp Charging:Current Med
	HV	_	ChargingCurrent() = High Temp Charging:Current High

Charging Voltage 4.5

The Charging Voltage() changes depending on the detected temperature per the charge algorithm.

NOTE: Table priority is top to bottom.

Temp Range	Condition	Action
Any	OperationStatus()[PRES] = 0 OR SafetyStatus()[COV] = 1 OR SafetyStatus()[OCC] = 1 OR SafetyStatus()[ASCC] = 1 OR SafetyStatus()[ASCCL] = 1 OR SafetyStatus()[CTO] = 1 OR SafetyStatus()[PTO] = 1	ChargingVoltage() = 0
UT or OT	_	ChargingVoltage() = 0
LT	_	ChargingVoltage() = Low Temp Charging:Voltage * Number of Cells
STL or STH	_	ChargingVoltage() = Standard Temp Charging:Voltage * Number of Cells



Temp Range	Condition	Action
RT		ChargingVoltage() = Rec Temp Charging:Voltage * Number of Cells
HT	_	ChargingVoltage() = High Temp Charging:Voltage * Number of Cells

4.6 Valid Charge Termination

The charge termination condition must be met to enable valid charging termination.

Status	Condition	Action
Charging	GaugingStatus()[REST] = 0 AND GaugingStatus()[DSG] = 0	Charging Algorithm active
Valid Charge Termination	(Charging AND AverageCurrent() continuous < Charge Term Taper Current AND Maximum cell voltage in Voltages() + Charge Term Voltage > Charging Voltage()/Number of Cells AND Δcharge > .25 mAH) for two consecutive 40-s periods	 ChargingStatus()[VCT] = 1 ChargingStatus()[MCHG] = 1 ChargingVoltage() = Charging Algorithm ChargingCurrent() = Charging Algorithm BatteryStatus()[FC] = 1 and GaugingStatus()[FC] = 1 if SOCFlagConfig 0-15[FCSETVCT] = 1 BatteryStatus()[TCA] = 1 and GaugingStatus()[TCA] = 1 if SOCFlagConfig 0-15 [TCASETVCT] = 1

4.7 Maintenance Charge

Maintenance charge can be configured to provide charge current after charge termination is reached.

Status	Condition	Action	
Set	ChargingStatus()[IN] = 0 AND ChargingStatus()[SU] = 0 AND ChargingStatus()[PV] = 0 AND GaugingStatus()[TCA] = 1	 ChargingStatus()[MCHG] = 1 ChargingVoltage() = Charging Algorithm ChargingCurrent() = Charging Algorithm If Charging Configuration[CHGFET] = 1, then CHG, PCHG FET disabled and Charging Voltage() = ChargingCurrent() = 0 	
Clear	ChargingStatus()[IN] = 1 OR ChargingStatus()[SU] = 1 OR ChargingStatus()[PV] = 1 OR GaugingStatus()[TCA] = 0	 ChargingStatus()[MCHG] = 0 ChargingVoltage() = Charging Algorithm ChargingCurrent() = Charging Algorithm 	

4.8 Charge Disable

The device can disable charging if certain safety conditions are detected.

Status	Condition	Action
Normal	ALL PFStatus()[] = 0 AND SafetyStatus()[COV] = 0 AND SafetyStatus()[OCC] = 0 AND SafetyStatus()[SCC] = 0 AND SafetyStatus()[SCCL] = 0 AND SafetyStatus()[CTO] = 0 AND SafetyStatus()[PTO] = 0 AND OperationStatus()[PRES] = 1 AND GaugingStatus()[TCA] = 0 if ChargingConfiguration()[CHGFET] = 1	 ChargingVoltage() = Charging Algorithm ChargingCurrent() = Charging Algorithm
Trip	ANY PFStatus()[] = 1 OR SafetyStatus()[COV] = 1 OR SafetyStatus()[OCC] = 1 OR SafetyStatus()[SCC] = 1 OR SafetyStatus()[SCCL] = 1 OR SafetyStatus()[CTO] = 1 OR SafetyStatus()[PTO] = 1 OR OperationStatus()[PRES] = 0 OR GaugingStatus()[TCA] = 1 if ChargingConfiguration()[CHGFET] = 1	 ChargingVoltage() = 0 ChargingCurrent() = 0



Charge Inhibit www.ti.com

4.9 **Charge Inhibit**

The device can stop charging at high and low temperatures to prevent damage of the cells.

Status	Condition	Action
Normal	ChargingStatus()[LT] = 1 OR ChargingStatus()[STL] = 1 OR ChargingStatus()[RT] = 1 OR ChargingStatus()[STH] = 1	 ChargingStatus()[IN] = 0 ChargingVoltage() = charging algorithm ChargingCurrent() = charging algorithm
Trip	ChargingStatus()[UT] = 1	 ChargingStatus()[IN] = 1 ChargingVoltage() = 0 ChargingCurrent() = 0 No charging is allowed if Charging Configuration[CHGIN] = 1
Trip	Not charging AND ChargingStatus()[HT] = 1 OR ChargingStatus()[OT] = 1)	 ChargingStatus()[IN] = 1 ChargingVoltage() = 0 ChargingCurrent() = 0 No charging is allowed if Charging Configuration[CHGIN] = 1

4.10 Charge Suspend

The device can stop charging at high and low temperatures to prevent damage of the cells.

Status	Condition	Action
Normal	ChargingStatus()[LT] = 1 OR ChargingStatus()[STL] = 1 OR ChargingStatus()[RT] = 1 OR ChargingStatus()[RT] = 1 OR ChargingStatus()[HT] = 1	 ChargingStatus()[SU] = 0 ChargingVoltage() = charging algorithm ChargingCurrent() = charging algorithm
Trip	ChargingStatus()[UT] = 1 OR ChargingStatus()[OT] = 1	 ChargingStatus()[SU] = 1 ChargingVoltage() = 0 ChargingCurrent() = 0 No charging is allowed if Charging Configuration[CHGSU] = 1

4.11 ChargingVoltage() Rate of Change

The device can slope the value changes from one range to another to avoid jumping between different voltage ranges.

NOTE: The host needs to read Charging Voltage() at least once a second during charging to adjust the charger accordingly.

Status	Condition	Action
Trip	Charging Voltage() Change	 ChargingStatus()[CVR] = 1 ChargingVoltage() = OLD + n * (New – OLD)/Voltage Rate, n = 1 Voltage Rate for Voltage Rate seconds

4.12 ChargingCurrent() Rate of Change

The device can slope the value changes from one range to another to avoid jumping between different current ranges.

NOTE: The host needs to read ChargingCurrent() at least once a second during charging to adjust the charger accordingly.



Status	Condition	Action
Trip	ChargingCurrent() Change	 ChargingStatus()[CCR] = 1 ChargingCurrent() = OLD + n * (New – OLD)/Current Rate, n = 1 Current Rate for Current Rate seconds

4.13 Charging Loss Compensation

The device can modify *ChargingVoltage()* and *ChargingCurrent()* to compensate losses caused by the FETs, the fuse, and the sense resistor by measuring the cell voltages directly and adjusting *ChargingCurrent()* and *ChargingVoltage()* accordingly.

In CONSTANT CURRENT mode, the device can increase the *ChargingVoltage()* value to compensate the drop losses.

NOTE: The host must read *ChargingVoltage()* and/or *ChargingCurrent()* at least once a second during charging to adjust the charger accordingly.

Status	Condition	Action
Normal	Current() > CCC Current Threshold AND Voltage() = Charging algorithm voltage	 ChargingStatus()[CCC] = 0 ChargingVoltage() = Charging Algorithm
Active	Current() > CCC Current Threshold AND Voltage() < Charging algorithm voltage	 ChargingStatus()[CCC] = 1 ChargingVoltage() = Charging Algorithm + (PackVoltage() - Voltage())
Limit	(PackVoltage() – Voltage()) > CCC Voltage Threshold	ChargingVoltage() = Charging Algorithm + CCC Voltage Threshold



Permanent Fail

5.1 Introduction

The device can permanently disable the use of the battery pack in case of a severe failure. The following actions in sequence are taken in PERMANENT FAIL (PF) mode when the **Settings:Manufacturing**Status[PF] bit is enabled. An individual PF event can be enabled and disabled with **Settings:Enabled**PF0–15 and **Settings:Enabled PF16–31** even after **Settings:Manufacturing Status[PF]** bit is enabled.

All PF protections can be disabled globally through **Settings:Manufacturing Status[PF]** regardless of the **Enabled PF 0–15** and **Enable PF 16 –31** settings.


- 1. Precharge, charge, and discharge FETs are turned off.
- 2. The following SBS data is changed: BatteryStatus()[TCA] = 1, if not charging, BatteryStatus()[TDA] = 1, ChargingCurrent() = 0, ChargingVoltage() = 0.
- A backup of the internal AFE hardware registers are written to data flash: STATUS, STATE_CONTROL, OUTPUT_STATUS, FUNCTION_CONTROL, CELL_SEL, OCDV, OCDD, SCD1, SCD2.
- 4. The black box data of the last three *SafetyStatus()* changes leading up to PF with time difference is written into data flash.
- 5. The cause of the permanent fail is logged into PFAlert and PFStatus.
- 6. The following SBS values are preserved in the data flash for failure analysis:
 - SafetyAlert()
 - SafetyStatus()
 - PFAlert()
 - PFStatus()
 - OperationStatus()
 - ChargingStatus()
 - GaugingStatus()
 - Voltages()
 - Temperatures()
 - DOD()
- 7. Data flash writing is disabled, except subsequent PFStatus flags.
- 8. Subsequent PFs are appended to PFAlert and PFStatus in PF Status class. PF Status is also logged separately to the Black Box Recorder 1st, 2nd, and 3rd PF Status.
- 9. The FUSE pin is driven high if configured for specific failures.

5.2 Black Box Recorder

The Black Box Recorder maintains the last three updates of *SafetyStatus()* in memory. In case of permanent failure, this information is written to data flash together with the first three updates of *PFStatus()* after the PF event.

33





NOTE: This information is useful in failure analysis, and can provide a full recording of the events and conditions leading up to the permanent failure.

If there were less than three safety events before PF, then some information will be left blank.

5.3 Cell Undervoltage Permanent Fail

The device can permanently disable the battery in case of a severely low cell voltage level.

Status	Condition	Action
Normal	All Cell voltages in Voltages() > Threshold	PFAlert()[CUV] = 0BatteryStatus()[TDA] = 0
Alert	Any Cell voltages in <i>Voltages()</i> ≤ Threshold	PFAlert()[CUV] = 1BatteryStatus()[TDA] = 1
Trip	Any Cell voltages in <i>Voltages()</i> continuous ≤ Threshold for Delay duration AND Enabled PF 0–15[CUV] = 1	 PFAlert()[CUV] = 0 PFStatus()[CUV] = 1 BatteryStatus()[FD] = 1 BatteryStatus()[TDA] = 1

5.4 Cell Overvoltage Permanent Fail

The device can permanently disable the battery in case of severe overvoltage of a cell.

Status	Condition	Action
Normal	All Cell voltages in Voltages() < Threshold	• PFAlert()[COV] = 0
Alert	Any Cell voltages in <i>Voltages()</i> ≥ Threshold	• PFAlert()[COV] = 1
Trip	Any Cell voltages in <i>Voltages()</i> continuous ≥ Threshold for Delay duration AND <i>Enabled PF 0–15[COV]</i> = 1	 PFAlert()[COV] = 0 PFStatus()[COV] = 1 If charging, BatteryStatus()[OCA] = 1

5.5 Copper Deposition Permanent Fail

The device can permanently disable the battery in case of a severely low cell voltage level. The copper deposition checks cell voltages upon wake up from SHUTDOWN mode while keeping the charge, discharge, and precharge FETs off until the check is complete.



Status	Condition	Action
Normal	All Cell voltages in Voltages() > Threshold	PFAlert()[CUDEP] = 0BatteryStatus()[TDA] = 0
Alert	Any Cell voltages in <i>Voltages()</i> ≤ Threshold	PFAlert()[CUDEP] = 1BatteryStatus()[TDA] = 1
Trip	Any Cell voltages in <i>Voltages()</i> continuous ≤ Threshold for Delay duration AND Enabled PF 0–15[CUDEP] = 1	 PFAlert()[CUDEP] = 0 PFStatus()[CUDEP] = 1 BatteryStatus()[FD] = 1 BatteryStatus()[TDA] = 1

5.6 Overtemperature Cell Permanent Fail

The device can permanently disable the battery pack in case of severe overtemperature of the cells.

Status	Condition	Action
Normal	Cell Temperature in <i>Temperatures()</i> < Threshold	• PFAlert()[OTCE] = 0
Alert	Cell Temperature in <i>Temperatures()</i> ≥ Threshold	• PFAlert()[OTCE] = 1
Trip	Cell Temperature in <i>Temperatures()</i> continuous ≥ Threshold for Delay duration AND <i>Enabled PF 0–15[OTCE]</i> = 1	 PFAlert()[OTCE] = 0 PFStatus()[OTCE] = 1

5.7 Overtemperature FET Permanent Fail

The device can permanently disable the battery pack in case of severe overtemperature on the power FET.

Status	Condition	Action
Normal	FET Temperature in <i>Temperatures()</i> < Threshold	• PFAlert()[OTF] = 0
Alert	FET Temperature in <i>Temperatures()</i> ≥ Threshold	 PFAlert()[OTF] = 1
Trip	FET Temperature in <i>Temperatures()</i> continuous ≥ Threshold for Delay duration AND Enabled PF 0–15[OTF] = 1	 PFAlert()[OTF] = 0 PFStatus()[OTF] = 1 BatteryStatus()[OTA] = 1

5.8 QMAX Imbalance Permanent Fail

The device can permanently disable the battery pack in case the capacity of one of the cells is much lower than the others.

Status	Condition	Action
Normal	Δ(QMAX Cell 03) < Threshold	• PFAlert()[QIM] = 0
Alert	Δ(QMAX Cell 03) ≥ Threshold	• PFAlert()[QIM] = 1
Trip	Δ(<i>QMAX Cell 03</i>) continuous ≥ Threshold for number of Delay ⁽¹⁾ updates AND Enabled PF 0–15[QIM] = 1	 PFAlert()[QIM] = 0 PFStatus()[QIM] = 1

⁽¹⁾ The delay for this check is counted each time QMAX is updated.

5.9 Cell Balancing Permanent Fail

The device can permanently disable the battery pack in case one of the cells in the series is cell balanced much more than the others.



Status	Condition	Action
Normal	Δ(Time Cell 03) < Delta Threshold	• PFAlert()[CB] = 0
Alert	Δ(Time Cell 03) ≥ Delta Threshold	• PFAlert()[CB] = 1
Trip	Δ(Time Cell 03) continuous ≥ Delta Threshold for Delay ⁽¹⁾ cycles AND Enabled PF 0–15[CB] = 1	 PFAlert()[CB] = 0 PFStatus()[CB] = 1
Trip	Max (Time Cell 03) ≥ Max Threshold AND Enabled PF 0-15[CB] = 1	 PFAlert()[CB] = 0 PFStatus()[CB] = 1

⁽¹⁾ The delay for this check is counted every time the *CycleCount()* is incremented.

5.10 Capacity Degradation Permanent Fail

The device can permanently disable the battery pack in case the capacity of the cell stack is degraded below a threshold.

Status	Condition	Action
Normal	All(QMAX14) > Threshold	• PFAlert()[CD] = 0
Alert	Any(QMAX14) ≤ Threshold	• PFAlert()[CD] = 1
Trip	Any(QMAX14) continuous ≤ Threshold for Delay ⁽¹⁾ cycles AND Enabled PF 0–15[CD] = 1	 PFAlert()[CD] = 0 PFStatus()[CD] = 1

⁽¹⁾ The delay for this check is counted every time the *CycleCount()* is incremented.

5.11 Impedance Permanent Fail

The device can permanently disable the battery pack in case the impedance of one of the cells is much higher than the others.

NOTE: Reference Grid is configurable from 0 (resistance at fully charged cell) to 14 (resistance at fully discharged cell). The Design Resistance will be automatically calculated and updated during learning cycle and is part of the golden image.

This check is only performed when the gauge updates the *Ra* data for the Reference Grid.

Status	Condition	Action
Normal	(Cell03 R_a at Reference Grid) < (Delta Threshold * Design Resistance)	• PFAlert()[IMP] = 0
Alert	∆(Cell03 R_a at Reference Grid) ≥ (Delta Threshold * Design Resistance)	• PFAlert()[IMP] = 1
Trip	∆(Cell03 R_a at Reference Grid) ≥ (Delta Threshold * Design Resistance) for Ra Update Counts AND Enabled PF 0–15[IMP] = 1	 PFAlert()[IMP] = 0 PFStatus()[IMP] = 1
Trip	∆(Cell03 R_a at Reference Grid) ≥ (Max Threshold * Design Resistance) AND Enabled PF 0–15[IMP] = 1	 PFAlert()[IMP] = 0 PFStatus()[IMP] = 1

5.12 Voltage Imbalance at Rest Permanent Fail

The device can permanently disable the battery pack in case of a voltage difference between the cells in a stack while at rest.

Status	Condition	Action
Normal	 All Cell voltages in Voltages() < Check Voltage Current() > Check Current Δ(Cell voltages in Voltages()) < Delta Threshold 	• PFAlert()[VIMR] = 0



Status	Condition	Action
Alert	Any Cell voltages in <i>Voltages()</i> ≥ Check Voltage AND <i>Current()</i> continuous < Check Current for Duration AND Δ(Cell voltages in <i>Voltages()</i>) ≥ Delta Threshold	• PFAlert()[VIMR] = 1
Trip	[Any Cell voltages in <i>Voltages()</i> ≥ Check Voltage AND <i>Current()</i> continuous < Check Current for Duration AND Δ(Cell voltages in <i>Voltages()</i>) ≥ Delta Threshold] for Delta Delay duration AND Enabled PF 0–15[VIMR] = 1	PFAlert()[VIMR] = 0PFStatus()[VIMR] = 1

5.13 Voltage Imbalance Active Permanent Fail

The device can permanently disable the battery pack in case of a voltage difference between the cells in a stack while active.

Status	Condition	Action
Normal	 All Cell voltages in Voltages() < Check Voltage Current() < Check Current Δ(Cell voltages in Voltages()) < Delta Threshold 	• PFAlert()[VIMA] = 0
Alert	Any Cell voltages in <i>Voltages()</i> ≥ Check Voltage AND <i>Current()</i> continuous > Check Current for Duration AND Δ(Cell voltages in <i>Voltages()</i>) ≥ Delta Threshold	• PFAlert()[VIMA] = 1
Trip	[Any Cell voltages in <i>Voltages()</i> ≥ Check Voltage AND <i>Current()</i> continuous > Check Current for Duration AND Δ(Cell voltages in Voltages()) continuous ≥ Delta Threshold] for Delay duration AND Enabled PF 0–15[VIMA] = 1	 PFAlert()[VIMA] = 0 PFStatus()[VIMA] = 1

5.14 Charge FET Permanent Fail

The device can permanently disable the battery pack in case the charge FET is not working properly.

Status	Condition	Action
Normal	CHG FET off AND Current() < OFF Threshold	PFAlert()[CFETF] = 0
Alert	CHG FET off AND Current() ≥ OFF Threshold	PFAlert()[CFETF] = 1
Trip	CHG FET off AND Current() continuously ≥ OFF Threshold for OFF Delay duration AND Enabled PF 16–32[CFETF] = 1	 PFAlert()[CFETF] = 0 PFStatus()[CFETF] = 1

5.15 Discharge FET Permanent Fail

The device can permanently disable the battery pack in case the discharge FET is not working properly.

Status	Condition	Action
Normal	DSG FET off AND Current() > OFF Threshold	• PFAlert()[DFET] = 0
Alert	DSG FET off AND Current() ≤ OFF Threshold	• PFAlert()[DFET] = 1
Trip	DSG FET off AND Current() continuously ≤ OFF Threshold for OFF Delay duration AND Enabled PF 16–32[DFET] = 1	 PFAlert()[DFET] = 0 PFStatus()[DFET] = 1

5.16 Thermistor Permanent Fail

The device can permanently disable the battery pack when it detects an open (internally pulled up) or short (grounded) failure in the thermistor circuit. When a fault is detected, no PF Alert flag will be set. Instead, the *PFStatus*()[THERM] flag will be set to 1 after the fault presents for ADC Delay duration.



5.17 Chemical Fuse Permanent Fail

The device can detect a non-working fuse. The device cannot disable the battery pack permanently but can record this event for analysis.

Status	Condition	Action
Normal	FUSE pin = high AND Current() < Threshold	• PFAlert()[FUSE] = 0
Alert	FUSE pin = high AND Current() ≥ Threshold	PFAlert()[FUSE] = 1
Trip	FUSE pin = high AND Current() continuous ≥ Threshold for Delay duration AND Enabled PF 16–32[FUSE] = 1	 PFAlert()[FUSE] = 0 PFStatus()[FUSE] = 1

5.18 AFE Register Permanent Fail

The device compares the AFE hardware register periodically with a RAM backup. If the comparison fails too many times, the device disables the pack permanently.

Status	Condition	Action
Normal	AFE register fail counter = 0	 PFAlert()[AFER] = 0 Compare AFE register and RAM backup every Compare Period
Alert	AFE register fail counter > 0	 PFAlert()[AFER] = 1 Decrement AFE register fail counter by one after each Delay Period Compare AFE register and RAM backup every Compare Period
Trip	AFE register fail counter ≥ Threshold AND Enabled PF 16–32[AFER] = 1	 PFAlert()[AFER] = 0 PFStatus()[AFER] = 1

5.19 AFE Communication Permanent Fail

The device monitors the internal communication to the AFE hardware. If the read or write fails exceed a limit within a timeframe, the device disables the pack permanently.

Status	Condition	Action
Normal	AFE read/write fail counter = 0	PFAlert()[AFEC] = 0
Alert	AFE read/write fail counter > 0	 PFAlert()[AFEC] = 1 Decrement AFE read/write fail counter by one after each Delay period
Trip	Read and Write Fail counter ≥ Threshold AND Enabled PF 16–32[AFEC] = 1	 PFAlert()[AFEC] = 0 PFStatus()[AFEC] = 1

5.20 Second Level Protection Permanent Fail

The device can detect a external trigger of the chemical fuse by an external protection circuit such as a 2nd-level protector by monitoring the FUSE pin state.

If the device detects a FUSE pin high state, the CHG and DSG FET are turned off.

Status	Condition	Action
Normal	Reset AFE and FUSE pin = low AND no FUSE trigger by firmware	 PFAlert()[2LVL] = 0 Reset internal PF 2LVL counter
Alert	FUSE pin = high AND no FUSE trigger by firmware	 PFAlert()[2LVL] = 1 Increment internal PF 2LVL counter Clear AFE alerts



www.ti.com PTC Permanent Fail

Status	Condition	Action
Trip	Internal PF 2LVL counter > Delay AND Enabled PF 16–32[2LVL] = 1	 PFAlert()[2LVL] = 0 PFStatus()[2LVL] = 1

5.21 PTC Permanent Fail

The device can detect an overtemperature using a positive temperature coefficient (PTC) resistor connected to the PTC pin. This protection also works in SHUTDOWN mode.

If the device detects a PTC pin high state, the CHG and DSG FET are turned off. The pack is disabled permanently. State can only be reset by a full power cycle of the device.

If PTC permanent fail is not used, the PTC pin should be connected to VSS with a 10-k Ω resistor.

Status	Condition	Action
Normal	Reset AFE and PTC pin = low AND no FUSE trigger by firmware	• PFStatus()[PTC] = 0
Trip	PTC pin = high	 PFStatus()[PTC] = 1 FUSE = high

5.22 Instruction Flash Checksum Permanent Fail

The device can permanently disable the battery in case it detects a difference between the stored IF checksum and the calculated IF checksum right after a device reset.

Status	Condition	Action
Normal	Stored and calculated IF checksum match	• PFAlert()[IFC] = 0
Trip	Stored and calculated IF checksum after reset does not match	 PFAlert()[IFC] = 0 PFStatus()[IFC] = 1

5.23 Open Cell Voltage Connection Permanent Fail

The device can permanently disable the battery in case it detects a difference between the BAT pin voltage and the sum of the individual cell voltages.

Status	Condition	Action
Normal	Sum(Cell voltages in <i>Voltage()</i> – BAT voltage in <i>Voltages()</i> < Threshold AND <i>Enabled PF</i> 16–32[OCECO] =1	• PFAlert()[OCECO] = 0
Alert	Sum(Cell voltages in <i>Voltages()</i>) – BAT voltage in <i>Voltages()</i> ≥ Threshold	• PFAlert()[OCECO] = 1
Trip	Sum(Cell voltages in <i>Voltages()</i>) – BAT voltage in <i>Voltages()</i> continuous ≥ Threshold for Delay Period	 PFAlert()[OCECO] = 0 PFStatus()[OCECO] = 1

5.24 Data Flash Permanent Fail

The device can permanently disable the battery in case a data flash write fails.

NOTE: A DF write failure will cause the gauge to disable further DF writes.



Data Flash Permanent Fail www.ti.com

Status	Condition	Action
Normal	Data flash write ok	 PFAlert()[DFW] = 0
Trip	Data flash write not successful	 PFAlert()[DFW] = 0 PFStatus()[DFW] = 1



Power Modes

To enhance battery life, the bq30z554-R1 supports different power modes to save power and minimize power consumption during operation.

6.1 NORMAL Mode

In NORMAL mode, the device takes voltage, current, and temperature readings every 250 ms, performs protection and gauging calculations, and updates SBS data. Between these periods of activity, the device is in a reduced power state.

6.2 SLEEP Mode

6.2.1 Device Sleep

When the sleep conditions are met, the device goes to SLEEP mode with periodic wake-ups to reduce power consumption. The device returns to NORMAL mode if SBS communication or current is detected.

Status	Condition	Action
Activate	SMBus low for SBS Low Time ⁽¹⁾ AND DA Config[SLEEP] = 1 ⁽¹⁾ AND Current() ≤ Sleep Current AND Voltage Time > 0 AND (OperationStatus()[PRES] = 0 OR DA Config[NR] = 1) AND OperationStatus()[SDM] = 0 AND No PFAlert() bits set AND No PFStatus() bits set AND No SafetyAlert() bits set AND No [OLD], [OLDL], [SCC], [SCCL], [SCD], [SCDL] set in SafetyStatus() (1)	 Turn off DSG FET, PHCG FET Turn off CHG FET if System Configuration[SLEEPCHG] = 0 Device goes to sleep Device wakes up every Sleep Voltage Time period to measure voltage and temperature Device wakes up every Sleep Current Time period to measure current
Exit	SMBus connected ⁽¹⁾ OR SMBus command received ⁽²⁾ OR DA Config[SLEEP] = 1 ⁽¹⁾ OR Current() > Sleep Current OR Wake comparator activates OR Voltage Time = 0 OR (OperationStatus()[PRES] = 1 AND DA Config[NR] = 0) OR OperationStatus()[SDM] = 1 OR PFAlert() bits set OR PFStatus() bits set OR SafetyAlert() bits set OR [OLD], [OLDL], [SCC], [SCCL], [SCD], [SCDL] set in SafetyStatus() (2)	Return to NORMAL mode

DA Config[SLEEP] and SMBus low are not checked if the ManufacturerAccess() SLEEP mode command is used to enter SLEEP mode.

6.2.1.1 Wake Function

The device can exit SLEEP mode, if enabled, by the presence of a voltage across SRP and SRN. The level of the current signal needed is programmed in Power: Wake Current Reg.

Wake on SMBus command is only possible when the gas gauge is put to sleep using the *ManufacturerAccess()* SLEEP mode command. Otherwise, the gas gauge will wake on an SMBus connection (clock or data high).



SHUTDOWN Mode www.ti.com

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Low Byte	RSVD	RSVD	RSVD	RSVD	RSVD	IWAKE	RSNS1	RSNS0

Reserved (Bits 7-3): Reserved, do not use.

IWAKE (Bit 2):

0 = 0.5A (Or if RSNS0=RSNS1=0 then this function is disabled.)

1 = 1.0A (Or if RSNS0=RSNS1=0 then this function is disabled.)

RSNS1	RSNS0	Resistance
0	0	Disabled (default)
0	1	2.5 mΩ
1	0	5 mΩ
1	1	10 mΩ

6.2.2 ManufacturerAccess() Sleep

The SLEEP MAC command will override the requirement for bus low to enter sleep. In this case, the part clock and data high condition are ignored for sleep exit, though sleep will also exit if there is any further SMBus communication. The device can be sent to sleep with *ManufacturerAccess()* if specific conditions are met.

6.3 SHUTDOWN Mode

6.3.1 Voltage-Based Shutdown

The device can be configured to shutdown at a programmable stack voltage threshold to minimize power consumption and avoid draining the battery. This function also works in PERMANENT FAILURE mode to prevent polymer cell swelling.

Status	Condition	Action
Enable	Min(Cell Voltage in <i>Voltages()</i>) < Shutdown Voltage	OperationStatus()[SDV]= 1
Activate	Min(Cell Voltage in <i>Voltages()</i>) continuous < Shutdown Voltage for Shutdown Time	The device disables everything and turns off.
Exit	Voltage at PACK pin > V _{STARTUP}	 OperationStatus()[SDV]= 0 Return to NORMAL mode

6.3.2 ManufacturerAccess() Shutdown

In SHUTDOWN mode, the device shuts down to minimize power consumption, and the FETs are turned off. The device will return to NORMAL mode when voltage at PACK pin > $V_{STARTUP}$. The device can be sent to this mode with the *ManufacturerAccess() Shutdown* command. Charger voltage must not be present for the device to enter SHIP SHUTDOWN mode.



Gauging

7.1 Impedance Track Update

The bq30z554-R1 features the most advanced Impedance Track gauging algorithm v3.75, and is capable of supporting a maximum battery pack capacity of 32 Ah. The algorithm estimates run time and capacity by measuring individual cell voltages, pack voltage, temperature, and current.

To determine the battery state of charge, the gas gauge analyzes individual cell voltages when a time exceeding 35 minutes has passed since the last charge or discharge activity of the battery. The device measures charge and discharge activity by monitoring the voltage across a small-value series sense resistor (10 m Ω typ.) between the cell stack negative terminal and the negative terminal of the battery pack. The battery state of charge is subsequently adjusted during load or charger application using the integrated charge passed through the battery.

The Impedance Track algorithm v3.75 features the following (for more details on the latest features, see Section 11.8):

- Cell balancing during relax (CBR)
- Ability to learn QMAX without a rest period following the end of discharge during the learn cycle (FAST_QMAX_LRN)
- Compatible with LiFePO4 chemistries (LFP_RELAX)
- Greatly improved low temperature accuracy
- Greatly improved RSOC convergence to 0% at EDV (RSOC CONV)
- Detailed status information is available via SBS for convenient debug and evaluation (no GG logging necessary)
 - DOD0
 - Qpassed
 - Grid numbers
 - Ra calculations
 - Balance timers
- Option to apply low pass filter smoothing to RemCap and FCC (SMOOTH)
- Option to prevent RSOC jumps during discharge (RSOC HOLD)

7.2 Impedance Track Configuration

Load Mode — During normal operation, the battery-impedance profile compensation of the Impedance Track algorithm can provide more accurate full-charge and remaining state-of-charge information if the typical load type is known. The two selectable options are constant current (**Load Mode** = 0) and constant power (**Load Mode** = 1).

Load Select — In order to compensate for the I × R drop near the end of discharge, the bq30z554-R1 must be configured for whatever current (or power) will flow in the future. While it cannot be exactly known, the bq30z554-R1 can use load history such as the average current of the present discharge to make a sufficiently accurate prediction.

The bq30z554-R1 can be configured to use several methods of this prediction by setting the **Load Select** value. Because this estimate has only a second-order effect on remaining capacity accuracy, different measurement-based methods (methods 0–3 and method 7) result in only minor differences in accuracy. However, methods 4–6, where an estimate is arbitrarily assigned by the user, can result in significant error if a fixed estimate is far from the actual load.



Gas Gauge Modes www.ti.com

For highly variable loads, selection 7 will give the most conservative estimate and is preferable.

Constant Current (Load Mode = 0)

0 = Avg I Last Run

1 = Present average discharge current

2 = Current

3 = AverageCurrent

4 = Design Capacity / 5

5 = AtRate (mA)

6 = User Rate-mA

7 = **Max Avg I Last Run** (default)

Constant Power (Load Mode = 1)

Avg P Last Run

Present average discharge power

Current x Voltage

AverageCurrent × average Voltage

Design Energy / 5 AtRate (10 mW) **User Rate-mW**

Max Avg P Last Run

Pulsed Load Compensation and Termination Voltage — In order to take into account pulsed loads while calculating remaining capacity until *Term Voltage* threshold is reached, the bq30z554-R1 monitors not only average load but also short load spikes. The maximum voltage deviation during a load spike is continuously updated during discharge and stored in *Delta Voltage*.

Reserve Battery Capacity — The bq30z554-R1 allows an amount of capacity to be reserved in either mAh (Reserve Cap-mAh, Load Mode = 0) or 10 mWh (Reserve Cap-mWh, Load Mode = 1) units between the point where the RemainingCapacity function reports zero capacity and the absolute minimum pack voltage, Term Voltage. This enables a system to report zero energy, but still have enough reserve energy to perform a controlled shutdown or to provide an extended sleep period for the host system.

Also, if the **[RESCAP]** bit is set to 0, the reserve capacity is compensated at a no-load condition. However, if the **[RESCAP]** bit is set to 1, then the reserve capacity is compensated at the present discharge rate as selected by **Load Select**.

7.3 Gas Gauge Modes

Resistance updates take place only in DISCHARGE mode, while OCV and QMAX updates only take place in RELAXATION mode. Entry and exit of each mode is controlled by data flash parameters in the subclass *Gas Gauging: Current Thresholds* section. In RELAXATION mode or DISCHARGE mode, the DSG flag in *BatteryStatus* is set.



www.ti.com Gas Gauge Modes




Figure 7-1. Gas Gauge Operating Modes



QMAX www.ti.com

CHARGE mode is exited and RELAXATION mode is entered when *Current* goes below *Quit Current* for a period of *Chg Relax Time*. DISCHARGE mode is entered when *Current* goes below *(-)DSG Current Threshold*. DISCHARGE mode is exited and RELAXATION mode is entered when *Current* goes above *(-)Quit Current* threshold for a period of *DSG Relax Time*. CHARGE mode is entered when *Current* goes above *Chg Current Threshold*.




Figure 7-2. Gas Gauge Operating Mode Example

7.4 QMAX

The total battery capacity is found by comparing states of charge before and after applying the load with the amount of charge passed. When an applications load is applied, the impedance of each cell is measured by comparing the open circuit voltage (OCV) obtained from a predefined function for present state of charge with the measured voltage under load.

Measurements of OCV and charge integration determine chemical state of charge and Chemical Capacity (QMAX).

The bq30z554-R1 acquires and updates the battery-impedance profile during normal battery usage. It uses this profile, along with state-of-charge and the *QMAX* values, to determine *FullChargeCapacity* and *RelativeStateOfCharge* specifically for the present load and temperature. *FullChargeCapacity* reports a capacity or energy available from a fully charged battery reduced by *Reserve Cap-mAh* or *Reserve Cap-mWh* under the present load and present temperature until *Voltage* reaches the *Term Voltage*.

7.4.1 QMAX Initial Values

The initial **QMAX Pack**, **QMAX Cell 0**, **QMAX Cell 1**, **QMAX Cell 2**, and **QMAX Cell 3** values should be taken from the cell manufacturers' data sheet multiplied by the number of parallel cells, and are also used for the **DesignCapacity** function value in the **Design Capacity** data flash value.

See the *Theory and Implementation of Impedance Track Battery Fuel-Gauging Algorithm in bq20zxx Product Family* application report (SLUA364B) for further details.



www.ti.com Cell Balancing

7.4.2 QMAX Update Conditions

The bq30z554-R1 updates the no-load full capacity (QMAX) when two open circuit voltage (OCV) readings are taken. These OCV readings are taken when the battery is in a relaxed state before and after charge or discharge activity. A relaxed state is achieved if the battery voltage has a dV/dt of < 4 μ V/s. Typically it takes 2 hours in a charged state and 5 hours in a discharged state to ensure that the dV/dt condition is satisfied. If 5 hours is exceeded, a reading is taken even if the dV/dt condition was not satisfied. A QMAX update is disqualified under the following conditions:

Temperature — If *Temperature* is outside of the range 10°C to 40°C.

Delta Capacity — If the capacity change between suitable battery rest periods is less than 37%.

Voltage — If *CellVoltage4..1* is in the range of 3737 mV to 3800 mV for the default LION chemistry. (See the *Support of Multiple Li-Ion Chemistries With Impedance Track Gas Gauges* application note (SLUA372) for the voltage ranges of other chemistries.)

Offset Error — If offset error accumulated during time passed from previous OCV reading exceeds 1% of Design Capacity, update is disqualified. Offset error current is calculated as **CC Deadband** / sense resistor value.

7.5 Cell Balancing

The gas gauge can determine the chemical state of charge of each cell using the Impedance Track algorithm. The cell balancing algorithm used in the device decreases the differences in imbalanced cells in a fully charged state gradually, which prevents fully charged cells from becoming overcharged, causing excessive degradation. This increases overall pack energy by preventing premature charge termination.

The algorithm determines the amount of charge needed to fully charge each cell. There is a bypass FET in parallel with each cell connected to the gas gauge. The FET is enabled for each cell with a charge greater than the lowest charged cell to reduce charge current through those cells. Each FET is enabled for a precalculated time as calculated by the cell balancing algorithm. When any bypass FET is turned on, then the [CB] charging status flag is set; otherwise, the [CB] flag is cleared.

Cell balancing is active after a QMAX update has occurred with the FC bit set and OCV taken. This state can be determined by the Update Status being set to 0x0E.

The gas gauge supports both active cell balancing during charge and cell balancing at rest. If **Settings:System Configuration [CB]** = 0, cell balancing active and at rest are disabled and all bypass FETs stay OFF. The cell balancing at rest can be disabled individually by writing **Settings: System Configuration [CBR]** = 0.

The cell balancing bypass time per mAh required for each cell is based on data flash setting. The bypass time needed for each cell is calculated as:

Balance Time per mAh cell 0 = 3600 mAs/(V_{CELL}/RVCx + R_{cb}) * DUTY/1000

Where: V_{CELL} = average cell voltage (e.g., 3.7 V for most chemistry)

RVCx = resistor value in series to VCx input (e.g., 100Ω , based on the reference schematic)

 R_{cb} = cell balancing FET R_{dson} , which is 150 Ω

DUTY = cell balancing duty cycle, which is 66% typ

Balance Time per mAh cell 1-3 = 3600 mAs/(V_{CELL}/(2*RVCx + Rcb) * DUTY)/1000

Where:

V_{CFII} = average cell voltage (e.g., 3.7 V for most chemistry)

RVCx = resistor value in series to VCx input (e.g., 100Ω , based on the reference schematic)

 R_{cb} = cell balancing FET R_{dson} , which is 150 Ω

DUTY = cell balancing duty cycle, which is 66% typ



TURBO Mode www.ti.com

The cell balancing at rest can be configured by configuring the data flash *Min Start Balance Delta*, *Relax Balance Interval*, and *Min RSOC for Balancing*. For the data flash setting description, see Section 11.4.10. The gas gauge balances cells by bypassing the energy. It is recommended to perform cell balancing at rest when there is capacity in the battery pack.

7.6 TURBO Mode

By computing and reporting in TURBO mode, the device predicts the maximum power pulse the system can deliver for approximately 10 ms. The information is a read on the SBS command 0x59, TURBO POWER. This will be a negative value in cW and is updated every 1 s.

The following SBS commands are used for this operation:

TURBO_POWER (0x59): read word

Reports maximal peak power value TURBO_POWER.

Units: cW

The gauge will compute a new TURBO_POWER every second.

Value is negative.

TURBO POWER is initialized to present value of TURBO POWER on reset or on power-up.

TURBO_FINAL (0x5A): read/write word

Sets DF.Min Turbo Power, which represents minimal TURBO-mode power level during active operation (e.g., non-SLEEP) after all higher TURBO-mode levels are disabled (expected at the end of discharge).

Units: cW

Negative value is expected.

TURBO PACK R (0x5B): read/write word

Sets the battery pack serial resistance that includes FETs, traces, sense resistors, etc. inside the battery pack TURBO PACK R.

Units: mΩ

TURBO PACK R is the actual data flash value DF.Pack Resistance.

Pack Resistance: Initial value of Pack Resistance. This can be measured once the circuit board on the Pack side is developed, and an accurate method of measurement is completed to program into this register.

This is a DF value used with the TURBO mode feature.

TURBO SYS R (0x5C): read/write word

Sets the system serial resistance along the path from battery to system power converter input that includes FETs, traces, sense resistors, etc., TURBO_SYS_R.

Units: mΩ

TURBO_SYS_R is the actual data flash value DF.Pack Resistance.

System Resistance: Initial value of System Resistance. This can be measured once the circuit board on the system side is developed, and an accurate method of measurement is completed to program into this register.

This is a DF value used with the TURBO mode feature.

MIN SYS V (0x5D): read/write word

Sets the Minimal Voltage at system power converter input at which the system will still operate.

Units: mV



www.ti.com TURBO Mode

MIN_SYS_V is initialized to the data flash value of DF.Terminate Voltage. Write to this command will overwrite the DF value. Intended use is to write it once on first use to adjust for possible changes in system design from the time the battery pack was designed.

TURBO_CURRENT (0x5E): read word

The gauge computes a maximal discharge current supported by the cell in mA for a 10-ms pulse. This value is updated every 1 s for the system to read.

Additionally, the following DF registers are programmed to set up the appropriate system level requirements:

Units: $m\Omega$ Units: $m\Omega$

High Frequency Resistance:

NOTE: The High Frequency measurement is required for TURBO mode and for the parameter in the data flash register called High Frequency Resistance under Turbo Configuration (see Section 11.10.3).

- If the ID was released for this cell, obtain Rhf from the chemistry ID selection table. Divide the value by the number of parallel cells used.
- If the chem. ID selection procedure is set up by the customer, the following procedure is required:
 - Perform the selection test using relax-discharge-relax.
 - Select the chem. ID using the mathcad tool.
 - Perform at 4C, 10-ms pulse discharge test, and collect 1 ms or higher sampled data with oscilloscope (see Figure 7-3).




Figure 7-3. Rhf Resistance Reference Waveform

• Use the following formula to find the high-frequency resistance:

$$\label{eq:loss_equation} \begin{aligned} &1000 \times \frac{\text{V_before} - \text{V_end_of_pulse}}{\text{I_before} - \text{I_pulse}} - \text{Rsys} - \text{Rpack} \\ &\text{High_Frequency_Resistance} \ = \frac{\text{I_before} - \text{I_pulse}}{\text{N_serial}} \end{aligned}$$



TURBO Mode www.ti.com

Setup Procedure:

- Discharge Current at C/4 rate
- Pulse duration 10 ms with 4C Discharge
- Pulse frequency 1 s
- · Sampling rate: 1 ms or higher
- Voltage measurement performed at Load inputs (same point used earlier to find system resistance)
- If an oscilloscope is not available to collect data, there is a 10-ms capable load, or the test is not working:
 - Send the cell to TI to determine the OCV/relaxation test with HF sampling.
 - Results will be used to obtain both chem. ID selection and Rhf value.

NOTE: See the *bq30z554 TURBO Mode Application Report* (SLUA663) for further details.



Lifetime Data Collection

8.1 Description

The device has extensive capabilities to log events over the life of the battery, which is useful for analysis. The data is collected in RAM and only written in DF under the following conditions to avoid wear out of flash:

- Every 10 hours if RAM content is different from flash
- In permanent fail, before data flash updates are disabled
- · A reset counter increments
- · Before scheduled shutdown
- · Before low voltage shutdown

The lifetime data stops collecting under the following conditions:

- After permanent fail
- Lifetime data collection is disabled

Total firmware runtime starts when lifetime data is enabled.

- Voltage
 - Max/Min Cell Voltage Each Cell
 - Max Delta Voltage
- Current
 - Max Charge/Discharge Current
 - Max Average Discharge Current
 - Max Average Discharge Power
- Safety Events (12 most common are tracked)
 - Number of Safety Events
 - Cycle Count at Last Safety Event(s)
- Charging Events
 - Number of Valid Charge Terminations
 - Cycle Count at Last Charge Termination
- Gauging Events
 - Number of QMAX updates
 - Cycle Count at Last QMAX update
 - Number of RA updates
 - Cycle Count at Last RA update
- Power Events: Number of Resets
- Cell Balancing
 - Cell Balancing Time each Cell
- Temperature
 - Max/Min Cell Temp
 - Delta Cell Temp
 - Max/Min Int Temp Sensor



Description www.ti.com

- Max FET Temp
- Time
 - Total runtime
 - Time spent different temperature ranges



Device Security

9.1 Description

The device uses a SHA-1 one-way hash function for device authentication by the host system. UNSEAL or FULL ACCESS modes are also protected using SHA-1 authentication.

9.2 SHA-1 Description

The SHA-1 is known as a one-way hash function, meaning there is no known mathematical method of computing the input given, only the output. The specification of the SHA-1, as defined by FIPS 180–2, states that the input consists of 512-bit blocks with a total input length less than 264 bits. Inputs that do not conform to integer multiples of 512-bit blocks are padded before any block is input to the hash function. The SHA-1 algorithm outputs 160 bits, commonly referred to as the digest.

(As of April 23, 2004 the latest revision is FIPS 180–2). SHA-1 or secure hash algorithm is used to compute a condensed representation of a message or data also known as hash. For messages $< 2^{64}$ the SHA-1 produces an 160-bit output called digest.

The device generates an SHA-1 input block of 288 bits (total input = 160 bit message + 128 bit key). To complete the 512 bit block size requirement of the SHA-1, the device pads the key and message with a 1, followed by 159 0s, followed by the 64 bit value for 288 (000...00100100000), which conforms to the pad requirements specified by FIPS 180–2.

Detailed information about the SHA-1 algorithm can be found:

- 1. http://www.itl.nist.gov/fipspubs/fip180-1.htm
- 2. http://csrc.nist.gov/publications/fips
- 3. www.faqs.org/rfcs/rfc3174.html

9.3 HMAC Description

The SHA-1 engine is used to calculate a modified HMAC value. Using a public message and a secret key, the HMAC output is considered to be a secure fingerprint that authenticates the device used to generate the HMAC.

To compute the HMAC, let H designate the SHA-1 hash function, M designate the message transmitted to the device, and KD designate the unique 128-bit unseal/full access/authentication key of the device. HMAC(M) is defined as:

H[KD || H(KD || M)], where || symbolizes an append operation

The message, M, is appended to the unseal/full access/authentication key, KD, and padded to become the input to the SHA-1 hash. The output of this first calculation is then appended to the unseal/full access/authentication key, KD, padded again, and cycled through the SHA-1 hash a second time. The output is the HMAC digest value.

9.4 Authentication

- 1. Generate 160-bit message M using a random number generator that meets approved random number generators described in FIPS PUB 140–2.
- 2. Generate SHA-1 input block B1 of 512 bytes (total input =128-bit authentication key KD + 160 bit message M + 1 + 159 0s + 100100000).
- 3. Generate SHA-1 hash HMAC1 using B1.
- 4. Generate SHA-1 input block B2 of 512 bytes (total input =128-bit authentication key KD + 160 bit hash



Unseal/Full Access www.ti.com

- HMAC1 + 1 + 159 0s + 100100000).
- 5. Generate SHA-1 hash HMAC2 using B2.
- 6. With no active *ManufacturerInput()* data waiting, write 160-bit message M to *ManufacturerInput()* in the format 0xAABBCCDDEEFFGGHHIJJKKLLMMNNOOPPQQRRSSTT, where AA is LSB.
- 7. Wait 250 ms, then read ManufacturerInput() for HMAC3.
- 8. Compare host HMAC2 with device HMAC3, it matches, both host and device have the same key KD and device is authenticated.

9.5 Unseal/Full Access

- 1. Send Unseal (0x0031) or Full Access (0x0032) command to ManufacturerAccess().
- 2. Read 160-bit message M from *ManufacturerInput()* in the format 0xAABBCCDDEEFFGGHHIJJKKLLMMNNOOPPQQRRSSTT, where AA is LSB.
- 3. Generate SHA-1 input block B1 of 512 bytes (total input =128-bit unseal/full access key KD + 160 bit message M + 1 + 159 0s + 100100000).
- 4. Generate SHA-1 hash HMAC1 using B1.
- 5. Generate SHA-1 input block B2 of 512 bytes (total input =128-bit unseal/full access key KD + 160 bit hash HMAC1 + 1 + 159 0s + 100100000).
- 6. Generate SHA-1 hash HMAC2 using B2.
- 7. Write 160-bit hash HMAC2 to *ManufacturerInput()* in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNNOOPPQQRRSSTT, where AA is LSB.
- 8. Device compares hash HMAC2 with internal calculated hash HMAC3. If it matches, device allows UNSEALED/FULL ACCESS mode indicated with the *OperationStatus()[SEC1],[SEC0]* flags.



SBS Commands

10.1 0x00 ManufacturerAccess()

The ManufacturerAccess() command has several functions depending on the data written to this command.

10.1.1 0x0000 ManufacturerData

This command returns *ManufacturerData()* information.

Status	Condition	Action
Activate	0x0000 to ManufacturerAccess()	Output ManufacturerData() on ManufacturerData()

10.1.2 0x0001 Device Type

The device can be checked for the IC part number.

Status	Condition	Action
Enable	0x0001 to ManufacturerAccess()	 Returns the IC part number on subsequent read on ManufacturerData() in the following format: aaAA, where: aaAA: device type

10.1.3 0x0002 Firmware Version

The device can be checked for the firmware version of the IC.

Status	Condition	Action
Enable	0x0002 to ManufacturerAccess()	 Returns the firmware revision on ManufacturerData() in the following format: ddDDvvVVbbBBttzzZZRREE, where: ddDD: Device Number vvVV: Version bbBB: build number tt: Firmware type zzZZ: Impedance Track Version RR: reserved EE: reserved
Enable	Write following sequence within 4 seconds; also works in SEALED mode: 1. Block write to 0x22 with block size 62 2. Block write to 0x20 with block size 62 3. Block write to 0x22 with block size 62	 Returns the firmware revision on ManufacturerData() in the following format: ddDDvvVVbbBBttzzZZRREE, where: ddDD: Device Number vvVV: Version bbBB: build number tt: Firmware type zzZZ: Impedance Track Version RR: reserved EE: reserved



10.1.4 0x0003 Hardware Version

The device can be checked for the hardware version of the IC.

Status	Condition	Action
Enable	0x0003 to ManufacturerAccess()	Returns the hardware revision on subsequent read on ManufacturerData()

10.1.5 0x0004 Instruction Flash Checksum

The device can return the instruction flash checksum.

Status	Condition	Action
Enable	0x0004 to ManufacturerAccess()	Returns the IF checksum on subsequent read on ManufacturerData() after a wait time of 250 ms

10.1.6 0x0005 Data Flash Checksum

The device can return the data flash checksum.

Status	Condition	Action
Enable	0x0005 to ManufacturerAccess()	Returns the DF checksum on subsequent read on ManufacturerData() after a wait time of 250 ms. Only static DF items are included in the checksum. No items modified by the device or items that are different device to device are included.

10.1.7 0x0006 Chemical ID

This command returns the chemical ID of the OCV tables used in the gauging algorithm.

Status	Condition	Action
Enable	0x0006 to ManufacturerAccess()	 Returns the chemical ID on subsequent read on ManufacturerData()

10.1.8 0x0010 Shutdown Mode

The device can be sent to SHUTDOWN mode before shipping to reduce power consumption to a minimum. The device will wake up when a voltage is applied to PACK.

Status	Condition	Action
Normal	OperationStatus()[SH] = 0	
Enable	0x0010 to ManufacturerAccess; when sealed, two times in a row	OperationStatus()[SD] = 1
Trip	[NR] = 1 AND Current() = 0 AND Voltage on PACK = 0	FETs are turned off after Power:Shutdown time. Device will enter SHUTDOWN mode after another passage of Power:Shutdown time. (i.e. 2x of the Shutdown time after the command is set and 1x of the Shutdown time after the FETs are off.)
Trip	Delay after command is sent > Power:Shutdown Time	No charging or discharging is allowed; device is shut down.

10.1.9 0x0011 SLEEP Mode

The device can be sent to sleep with ManufacturerAccess() if the sleep conditions are met.



Status	Condition	Action
Enable	0x0011 to ManufacturerAccess()	OperationStatus()[SLEEPM] = 1
Activate	Settings:System Configuration[NR] = 0 AND OperationStatus()[PRES] = 0 AND Current() < Power:Sleep Current	 Turn off CHG FET, DSG FET, PCHG FET Device goes to sleep Device wakes up every Power: Sleep Voltage Time period to measure voltage and temperature Device wakes up every Power: Sleep Current Time period to measure current
Activate	Settings:System Configuration:System[NR] = 1 AND Current() < Power:Sleep Current	 Turn off DSG FET, PCHG FET Turn off CHG FET if Settings:System Configuration[SLEEPCHG] = 0 Device goes to sleep Device wakes up every Power:Sleep Voltage Time period to measure voltage and temperature Device wakes up every Power:Sleep Current Time period to measure current
Exit	Settings:System Configuration[NR] = 0 AND OperationStatus()[PRES] = 1	 OperationStatus()[SLEEPM] = 0 Return to NORMAL mode
Exit	Current() > Power:Sleep Current	 OperationStatus()[SLEEPM] = 0 Return to NORMAL mode
Exit	Wake Comparator trips	 OperationStatus()[SLEEPM] = 0 Return to NORMAL mode
Exit	SafetyAlert() flag or PFAlert() flag set	 OperationStatus()[SLEEPM] = 0 Return to NORMAL mode

10.1.10 0x0012 Device Reset

This command resets the device.

Status	Condition	Action
Enable	0x0012 to ManufacturerAccess()	Reset the device

This command activates/deactivates FUSE pin for ease of manufacturing testing.

Status	Condition	Action
Disable	OperationStatus()[FUSE] = 1 AND 0x001D to ManufacturerAccess()	 OperationStatus()[FUSE] = 0 FUSE pin drive low
Enable	OperationStatus()[FUSE] = 0 AND 0x001D to ManufacturerAccess()	 OperationStatus()[FUSE] = 1 FUSE pin drive high

10.1.12 0x001E PRE-CHG FET

This command turns on/off Pre-CHG (PCHG) FET drive function to ease testing during manufacturing.

Status	Condition	Action
Disable	ManufacturingStatus()[FET][PCHG] = 0,1 AND 0x001E to ManufacturerAccess()	 ManufacturingStatus()[FET][PCHG] = 0,0 precharge function defined with PCHG1,PCHG0 turns off
Enable	ManufacturingStatus()[FET][PCHG] = 0,0 AND 0x001E to ManufacturerAccess()	 ManufacturingStatus()[FET][PCHG] = 0,1 precharge function defined with PCHG1,PCHG0 turns on



10.1.13 0x001F CHG FET

This command turns on/off CHG FET drive function to ease testing during manufacturing.

Status	Condition	Action
Disable	ManufacturingStatus()[FET][CHG] = 0,1 AND 0x001F to ManufacturerAccess()	 ManufacturingStatus()[FET][CHG] = 0,0 CHG FET turns off
Enable	ManufacturingStatus()[FET][CHG] = 0,0 AND 0x001F to ManufacturerAccess()	 ManufacturingStatus()[FET][CHG] = 0,1 CHG FET turns on

10.1.14 0x0020 DSG FET

This command turns on/off DSG FET drive function to ease testing during manufacturing.

Status	Condition	Action
Disable	ManufacturingStatus()[FET][DSG] = 0,1 AND 0x0020 to ManufacturerAccess()	 ManufacturingStatus()[FET][DSG] = 0,0 DSG FET turns off
Enable	ManufacturingStatus()[FET][DSG] = 0,0 AND 0x0020 to ManufacturerAccess()	 ManufacturingStatus()[FET][DSG] = 0,1 DSG FET turns on

10.1.15 0x0021 Gauging

This command enables/disables the gauging function to ease testing during manufacturing.

Status	Condition	Action
Disable	ManufacturingStatus()[Gauge] = 1 AND 0x0021 to ManufacturerAccess()	 ManufacturingStatus()[Gauge] = 0 Disable gauging feature
Enable	ManufacturingStatus()[Gauge] = 0 AND 0x0021 to ManufacturerAccess()	 ManufacturingStatus()[Gauge] = 1 Enable gauging feature

10.1.16 ManufacturerAccess() 0x0022 FET Control

This command enables/disables control of the CHG, DSG, and PCHG FET by the firmware.

Status	Condition	Action
Disable	ManufacturingStatus()[FET] = 1 AND 0x0022 to ManufacturerAccess()	 ManufacturingStatus()[FET] = 0 CHG, DSG and PCHG FET are disabled and remain OFF.
Enable	ManufacturingStatus()[FET] = 0 AND 0x0022 to ManufacturerAccess()	 ManufacturingStatus()[FET] = 1 CHG, DSG and PCHG FET are controlled by the firmware.

10.1.16.1 ManufacturerAccess() Manual FET Control

The *ManufacturerAccess()* SBS command can enter and execute Manual FET Control, which enables outputs from the bq30z554-R1 device go into a state to turn off the external PCHG, CHG, and DSG FETs, which are associated with power delivery and protection in the system. This allows the safe removal of the internal battery, and auto-recovery once a battery is re-inserted. This is very similar to MAC 0x22 command, but is available when sealed.

To enter and execute Manual FET Control with the *ManufacturerAccess()* SBS command, do the following:



NOTE: The following two commands and data information must be sent in consecutive order for correct execution of this feature, and must be written within a specified time limit (typically less than 4seconds).

- (a) Write SBS command 0x00. Send Data code 0x270C. This arms the feature for FET control of PCHG, CHG, and DSG.
- (b) Write SBS command 0x00. Send Data code 0x043D. This disables the FET outputs PCHG, CHG, and DSG.


The assigned Data Flash register, *Manual FET Control Delay*, sets a delay time before the FETs are turned OFF (user-programmable).

To exit Manual FET Control, one of the following must occur:

- (a) The gas gauge detects a battery insertion (by detecting the edge trigger on the PRES pin).
- (b) Sending an SBS command as follows: Write 0x00 and data code 0x23A7.
- (c) Pressing the **Shutdown** button to enable the FETs to turn back ON.

NOTE: MFC Delay Time is in seconds (max value = 255 seconds, default = 60 seconds). Once the MFC command is issued, the gas gauge waits for MFC Delay Time before it turns off the FETs. If this value is set to 0, then the action is immediate (no delay).

The following graphic shows how to enable the FET turn OFF.



The data read back from the gas gauge notifies the system of the status of the enabling process.

Table 10-1. Enabling with the following Settings: MFC Delay Time = 0 s

Time(s)	Action	
0	System writes SMB: Cmd = 0x00, Data = 0x270C	
1		
2		
3(11)	System writes SMB: Cmd = 0x00, Data = 0x043D. The gas gauge turns off both FETs AND the <i>OperationStatus</i> register Bit 29 [OFF] is set.	

⁽¹⁾ Shows that the gas gauge turns off the FETs in much less than 1 second.



Table 10-2. Enabling with the following Settings: MFC Delay Time = 10 s

Time(s)	Action	
0	System writes SMB: Cmd = 0x00, Data = 0x270C	
1		
2		
3	System writes SMB: Cmd = 0x00, Data = 0x043D	
4		
5	System reads cmd 0x54, The gas gauge returns Block data = OperationStatus (Bit 29 OFF = 0)	
6	System reads cmd 0	
7		
8		
12		
13	The gas gauge turns off both FETs (a 10-s delay time was reached since the MFC command was issued).	
14	System Reads cmd 0x54, the gas gauge returns Block data = OperationStatus (Bit 29 [EMSHUT] = 1, FETs has been turned off).	

To exit Manual FET Control Mode, use one of following procedures (required):

- 1. When [NR] = 0, normal FET control is restored when SYS PRES transitions into the CONNECTED state.
- 2. When [NR] = 1 AND [OFF] = 1, normal FET control can be restored by pressing the **Shutdown** button. This allows disabling the FETs via the SMBus, and turns them back on via the **Shutdown** button. Or the user can disable the FETs via the Shutdown button and turn them back on via the SMBus. The features will work together as an OR function to enable/disable the FETs.
- 3. Sending an SBS command as follows: Write 0x00 and data code 0x23A7.

NOTE: In the event the CHG FET is turned OFF due to fully charged capacity, the user can press the Shutdown button OR a MAC command can initiate a manual shutdown. The PCHG, CHG, and DSG FETs are turned OFF; however, once any of the criteria to exit the Manual FET Control mode has begun OR if the emergency Shutdown button is pressed to exit, shutdown is initiated and the CHG and DSG FETs are turned ON. After a delay, the gas gauge reverts back to normal conditions so that it may turn OFF the CHG FET if the appropriate conditions are satisfied: for example, a fully charged pack with the AC adapter connected OR a COV condition or similar conditions that ensured that the CHG FET was OFF prior to when the emergency shutdown or Manual FET Control was invoked.

10.1.17 ManufacturerAccess() 0x0023 Lifetime Data Collection

This command enables/disables Lifetime data collection for ease of manufacturing.

Status	Condition	Action
Disable	ManufacturingStatus()[LF] = 1 AND 0x0023 to ManufacturerAccess()	 ManufacturingStatus()[LF] = 0 Lifetime Data collection feature disabled
Enable	ManufacturingStatus()[LF] = 0 AND 0x0023 to ManufacturerAccess()	 ManufacturingStatus()[LF] = 1 Lifetime Data collection feature enabled

10.1.18 ManufacturerAccess() 0x0024 Permanent Failure

This command enables/disables Permanent Failure for ease of manufacturing.



Status	Condition	Action
Disable	ManufacturingStatus()[PF] = 1 AND 0x0024 to ManufacturerAccess()	 ManufacturingStatus()[PF] = 0 Permanent Failure feature disabled
Enable	ManufacturingStatus()[PF] = 0 AND 0x0024 to ManufacturerAccess()	 ManufacturingStatus()[PF] = 1 Permanent Failure feature enabled

10.1.19 ManufacturerAccess() 0x0025 Black Box Recorder

This command enables/disables Black Box Recorder function for ease of manufacturing.

Status	Condition	Action
Disable	ManufacturingStatus()[BBR] = 1 AND 0x0025 to ManufacturerAccess()	 ManufacturingStatus()[BBR] = 0 Black Box Recorder feature is disabled.
Enable	ManufacturingStatus()[BBR] = 0 AND 0x0025 to ManufacturerAccess()	 ManufacturingStatus()[BBR] = 1 Black Box Recorder feature is enabled.

10.1.20 ManufacturerAccess() 0x0026 Fuse

This command enables/disables firmware fuse toggle function for ease of manufacturing.

Status	Condition	Action
Disable	ManufacturingStatus()[FUSE] = 1 AND 0x0026 to ManufacturerAccess()	 ManufacturingStatus()[FUSE] = 0 FUSE pin action is disabled.
Enable	ManufacturingStatus()[FUSE] = 0 AND 0x0026 to ManufacturerAccess()	 ManufacturingStatus()[FUSE] = 1 FUSE pin action is enabled.

10.1.21 ManufacturerAccess() 0x0028 Lifetime Data Reset

This command resets Lifetime data in the data flash for ease of manufacturing.

Status	Condition	Action
Reset	0x0028 to ManufacturerAccess()	Clear Lifetime Data in DF

10.1.22 ManufacturerAccess() 0x0029 Permanent Fail Data Reset

This command resets PF data in the data flash for ease of manufacturing.

Status	Condition	Action
Reset	0x0029 to ManufacturerAccess()	Clear PF Data in DF

10.1.23 ManufacturerAccess() 0x002A Black Box Recorder Reset

This command resets the Black Box Recorder data in the data flash for ease of manufacturing.

Status	Condition	Action
Reset	0x002A to ManufacturerAccess()	Clear Black Box Recorder data in DF

10.1.24 ManufacturerAccess() 0x002D CAL Mode

This command enables output of the raw ADC and CC data on ManufacturerData().



Status	Condition	Action
Disable	ManufacturingStatus()[CAL] = 1 AND 0x002D to ManufacturerAccess()	 ManufacturingStatus()[CAL] = 0 Disable output of ADC and CC raw data on ManufacturingData()
Enable	ManufacturingStatus()[CAL] = 0 AND 0x002D to ManufacturerAccess()	 ManufacturingStatus()[CAL] = 1 Enable output of ADC and CC raw data on ManufacturingData(), controllable with 0xF081 and 0xF082 on ManufacturerAccess()

10.1.25 ManufacturerAccess() 0x0030 Seal Device

This command seals the device for the field, disabling certain SBS commands and access to DF.

Status	Condition	Action
Sealed	OperationStatus()[SEC1,SEC0] = 0,1 or 1,0 AND 0x0030 to ManufacturerAccess()	 OperationStatus()[SEC1,SEC0] = 1,1 Certain SBS Commands not available; see SBS table for details.

10.1.26 ManufacturerAccess() 0x0031 UnSeal Device

This command unseals the device after valid SHA-1 authentication.

Status	Condition	Action
Initiate	OperationStatus()[SEC1,SEC0] = 1,1 AND 0x0031 to ManufacturerAccess()	OperationStatus()[AUTH] = 1 160-bit random number message available at ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNNOOPPQ QRRSSTTT, where AA is LSB.
Unseal	Correct 160-bit HMAC digest computed with random number + Unseal Key written to ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNN OOPP, where AA is LSB.	OperationStatus()[SEC1,SEC0] = 0,1 OperationStatus()[AUTH] = 0 device unsealed after 250 ms, for available SBS commands in UNSEAL mode see SBS table.
Invalid	Incorrect 160-bit hash written to ManufacturerInput()	 Wait time 250 ms OperationStatus()[SEC1,SEC0] = 0,0 OperationStatus()[AUTH] = 0

10.1.27 ManufacturerAccess() 0x0032 Full Access Device

This command enables Full Access to the device after valid SHA-1 authentication.

Status	Condition	Action
Initiate	OperationStatus()[SEC1,SEC0] = 1,1 or 1,0 AND 0x0032 to ManufacturerAccess()	OperationStatus()[AUTH] = 1 160-bit random number message available at ManufacturerInput() n the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNNOOPPQ QRRSSTTT, where AA is LSB.
Full Access	Correct 160-bit HMAC digest computed with random number + Full Access Key written to ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNN OOPP, where AA is LSB.	 OperationStatus()[SEC1,SEC0] = 1,1 OperationStatus()[AUTH] = 0 device enables full access after 250 ms, for available SBS commands in FULL ACCESS mode see SBS table.
Invalid	Incorrect 160-bit hash written to ManufacturerInput()	 Wait time 250 ms OperationStatus()[SEC1,SEC0] = 0,0 OperationStatus()[AUTH] = 0



10.1.28 ManufacturerAccess() 0x0033 ROM Mode

This command enables the ROM mode for IF update.

Status	Condition	Action
ROM Mode	OperationStatus()[SEC1,SEC0] = 1,0 AND 0x0033 to ManufacturerAccess()	Device goes to ROM mode ready for update, use 0x08 to ManufacturerAccess() to return.

10.1.29 ManufacturerAccess() 0x0035 Unseal Key

This command enters a new Unseal key into the device.

Status	Condition	Action
initiate	OperationStatus()[SEC1,SEC0] = 1,0 AND 0x0035 to ManufacturerAccess()	 OperationStatus()[AUTH] = 1 160-bit random number message available at ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNNOOPPQ QRRSSTTT, where AA is LSB.
Enter Key	Correct 128-bit Key written to ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNN OOPP, where AA is LSB.	Wait time 250 ms OperationStatus()[AUTH] = 0 device returns 160-bit digest at ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIJJKKLLMMNNOOPPQ QRRSSTTT, where AA is LSB. Digest was calculated using the random number + key. compare with own calculations check validity of key.

10.1.30 ManufacturerAccess() 0x0036 Full Access Key

This command enters a new Full Access key into the device.

Status	Condition	Action
initiate	OperationStatus()[SEC1,SEC0] = 1,0 AND 0x0036 to ManufacturerAccess()	 OperationStatus()[AUTH] = 1 160-bit random number available at ManufacturerInput()
Enter Key	Correct 128-bit Key written to ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNN OOPP, where AA is LSB.	Wait time 250 ms OperationStatus()[AUTH] = 0 device returns 160-bit digest at ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNNOOPPQ QRRSSTTT, where AA is LSB. Digest was calculated using the random number + key. compare with own calculations check validity of key.

10.1.31 ManufacturerAccess() 0x0037 Authentication Key

This command enters a new authentication key into the device.

Status	Condition	Action
Initiate	OperationStatus()[SEC1,SEC0] = 1,0 AND 0x0037 to ManufacturerAccess()	 OperationStatus()[AUTH] = 1 160-bit random number available at ManufacturerInput()



Status	Condition	Action
Enter Key	Correct 128-bit Key written to ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNN OOPP, where AA is LSB.	Wait time 250 ms OperationStatus()[AUTH] = 0 device returns 160-bit HMAC digest at ManufacturerInput() in the format 0xAABBCCDDEEFFGGHIIJJKKLLMMNNOOPPQ QRRSSTTT, where AA is LSB. The HMAC digest was calculated using the random number + key. Compare with own calculations check validity of key.

10.1.32 ManufacturerAccess() 0x0050 SafetyAlert

This command returns the SafetyAlert() flags on ManufacturerData().

Status	Condition	Action
Activate	0x0050 to ManufacturerAccess()	Output SafetyAlert() flags on ManufacturerData()

10.1.33 ManufacturerAccess() 0x0051 SafetyStatus

This command returns the SafetyStatus() flags on ManufacturerData().

Status	Condition	Action
Activate	0x0051 to ManufacturerAccess()	Output SafetyStatus() flags on ManufacturerData()

10.1.34 ManufacturerAccess() 0x0052 PFAlert

This command returns the PFAlert() flags on ManufacturerData().

Status	Condition	Action
Activate	0x0052 to ManufacturerAccess()	Output PFAlert() flags on ManufacturerData()

10.1.35 ManufacturerAccess() 0x0053 PFStatus

This command returns the PFStatus() flags on ManufacturerData().

Status	Condition	Action
Activate	0x0053 to ManufacturerAccess()	Output PFStatus() flags on ManufacturerData()

10.1.36 ManufacturerAccess() 0x0054 OperationStatus

This command returns the OperationStatus() flags on ManufacturerData().

Status	Condition	Action
Activate	0x0054 to ManufacturerAccess()	Output OperationStatus() flags on ManufacturerData()

10.1.37 ManufacturerAccess() 0x0055 ChargingStatus

This command returns the ChargingStatus() flags on ManufacturerData().



Status	Condition	Action
Activate	0x0055 to ManufacturerAccess()	Output ChargingStatus() flags on ManufacturerData()

10.1.38 ManufacturerAccess() 0x0056 GaugingStatus

This command returns the GaugingStatus() flags on ManufacturerData().

Status	Condition	Action
Activate	0x0056 to ManufacturerAccess()	Output GaugingStatus() flags on ManufacturerData()

10.1.39 ManufacturerAccess() 0x0057 ManufacturingStatus

This command returns the ManufacturingStatus() flags on ManufacturerData().

Status	Condition	Action
Activate	0x0057 to ManufacturerAccess()	Output ManufacturingStatus() flags on ManufacturerData()

10.1.40 ManufacturerAccess() 0x0058 AFE Register

This command returns the AFERegister() values on ManufacturerData().

Status	Condition	Action
Activate	0x0058 to ManufacturerAccess()	Output AFERegister() values on ManufacturerData()

10.1.41 ManufacturerAccess() 0x0059 TURBO_POWER

This command returns the TURBO_POWERRegister() values on ManufacturerData().

Status	Condition	Action
Activate	0x0059 to ManufacturerAccess()	Output TURBO_POWERRegister() values on ManufacturerData()

10.1.42 ManufacturerAccess() 0x005A TURBO_FINAL

This command returns the TURBO FINALRegister() values on ManufacturerData().

Status	Condition	Action
Activate	0x005A to ManufacturerAccess()	Represents minimal Turbo-mode power level during active <i>OperationRegister()</i> . A Write to this command overwrites the DF value <i>ManufacturerData()</i>

10.1.43 ManufacturerAccess() 0x005B TURBO_PACK_R

This command returns the TURBO_PACK_RRegister() values on ManufacturerData().

Status	Condition	Action
Activate	0x005B to ManufacturerAccess()	Sets the battery pack serial ResistanceRegister(). A Write to this command overwrites the DF value ManufacturerData()



10.1.44 ManufacturerAccess() 0x005C TURBO_SYS_R

This command returns the TURBO_SYS_RRegister() values on ManufacturerData().

Status	Condition	Action
Activate	0x005C to ManufacturerAccess()	Sets the system serial ResistanceRegister(). A Write to this command overwrites the DF value ManufacturerData()

10.1.45 ManufacturerAccess() 0x005D MIN_SYS_V

This command returns the MMIN_SYS_VRegister() values on ManufacturerData().

Status	Condition	Action
Activate	0x005D to ManufacturerAccess()	Sets the Minimal Voltage at the System Power Converter Input for OperationRegister(). A Write to this command overwrites the DF value ManufacturerData()

10.1.46 ManufacturerAccess() 0x005E TURBO_CURRENT

This command returns the MIN_SYS_RRegister() values on ManufacturerData().

Status	Condition	Action
Activate	0x005E to ManufacturerAccess()	Output TURBO_CURRENTRegister() values on ManufacturerData()

10.1.47 ManufacturerAccess() 0x0060 Lifetime Data Block 1

This command returns the Lifetime data on ManufacturerData().

Status	Condition	Action
Activate	0x0060 to ManufacturerAccess()	Output 32 bytes of lifetime data values on ManufacturerData()

10.1.48 ManufacturerAccess() 0x0061 Lifetime Data Block 2

This command returns the Lifetime data on ManufacturerData().

Status	Condition	Action
Activate	0x0061 to ManufacturerAccess()	Output 27 bytes of lifetime data values on ManufacturerData()

10.1.49 ManufacturerAccess() 0x0062 Lifetime Data Block 3

This command returns the Lifetime data on ManufacturerData().

Status	Condition	Action
Activate	0x0062 to ManufacturerAccess()	Output 12 bytes of lifetime data values on ManufacturerData()

10.1.50 ManufacturerAccess() 0x0070 ManufacturerInfo

This command returns ManufacturerInfo on ManufacturerData().



Status	Condition	Action
Activate	0x0070 to ManufacturerAccess()	Output 32 bytes of ManufacturerInfo on ManufacturerData()

10.1.51 ManufacturerAccess() 0x0071 Voltages

This command returns the CellVoltages, PackVoltage, and BatVoltage on ManufacturerData().

Status	Condition	Action
Activate	0x0071 to ManufacturerAccess()	Output 12 bytes of voltage data values on ManufacturerData()

10.1.52 ManufacturerAccess() 0x0072 Temperatures

This command returns the internal temp sensor, TS1, TS2, TS3, TS4, CellTemp, and FETTemp on *ManufacturerData()*.

Status	Condition	Action
Activate	0x0072 to ManufacturerAccess()	Output 14 bytes of temperature data values on ManufacturerData()

10.1.53 ManufacturerAccess() 0x0073 ITSTATUS1

This command instructs the device to return Impedance Track related gauging information on *ManufacturerData()*.

Status	Condition	Action
Activate	0x0073 to ManufacturerAccess()	Output 30 bytes of IT data values on ManufacturerData()

10.1.54 ManufacturerAccess() 0x0074 ITSTATUS2

This command instructs the device to return Impedance Track related gauging information on *ManufacturerData()*.

Status	Condition	Action
Activate	0x0074 to ManufacturerAccess()	 Output 10 bytes of IT data values on ManufacturerData()

10.1.55 ManufacturerAccess() 0x270C MANUAL FET CONTROL

This command instructs the device to initiate Manual FET Control ManufacturerData().

Status	Condition	Action
Activate	0x270C to ManufacturerAccess()	 Initiates Manual FET Control ManufacturerData()

10.1.56 ManufacturerAccess() 0xF080 Exit Calibration Output Mode

This command returns the data acquisition to NORMAL mode.



Status	Condition	Action
Activate	ManufacturerData()[CAL] = 1 AND 0xF080 to ManufacturerAccess()	Stops output of ADC or CC data on ManufacturerData() and return to NORMAL DATA ACQUISITION mode

10.1.57 ManufacturerAccess() 0xF081 Output CC and ADC for Calibration

This command lets the device output the raw values of coulomb counter, CellVoltage1, CellVoltage2, CellVoltage3, CellVoltage4, TS1, TS2, TS3, TS4, Tint, PACK, and BAT as block on *ManufacturerData()* with updates every 250 ms for calibration purposes.

The format of each value is 2's complement, MSB first.

Status	Condition	Action
Disable	ManufacturingStatus()[CAL] = 1 AND 0xF080 to ManufacturerAccess()	 ManufacturingStatus()[CAL] = 0 Stops output of ADC and CC data on ManufacturerData() and return to NORMAL DATA ACQUISITION mode
		ManufacturingStatus()[CAL] = 1 Outputs the raw CC and AD values on ManufacturerData() in the format of ZZYYaaAAbbBBccCCddDDeeEEffFFggGGhhHHiilljjJJk kKKIILL, where: ZZ: rolling 8-bit counter, increments when values
		are refreshed. - YY: status, 1 when MAC() = 0xF081, 2 when
		MAC()=0xF082 - AAaa: coulomb counter
		BBaa: CellVoltage1
Enable	0xF081 to ManufacturerAccess()	CCaa: CellVoltage2
		DDaa: CellVoltage3
		EEee: CellVoltage4
		FFff: Tint
		- GGgg: TS1
		- HHhh: TS2
		- Ilii TS3
		- JJjj: TS4
		- KKkk: PackVoltage
		LLII: BatVoltage

10.1.58 ManufacturerAccess() 0xF082 Output shorted CC AND ADC Offset for Calibration

This command enables the device to output the raw CC value on ManufacturerData().

The format of each value is 2's complement, MSB first.

Status	Condition	Action
Disable	ManufacturingStatus()[CAL] = 1 AND 0xF080 to ManufacturerAccess()	 ManufacturingStatus()[CAL] = 0 Stops output of ADC and CC data on ManufacturerData() and return to NORMAL DATA ACQUISITION mode



Status	Condition	Action
Enable	0xF082 to ManufacturerAccess()	ManufacturingStatus()[CAL] = 1 Outputs the raw CC and AD values on ManufacturerData() in the format of ZZYYaaAAbbBBccCCddDDeeEEffFFggGGhhHHiilljjJJk kKKllLL, where: ZZ: rolling 8-bit counter, increments when values are refreshed. YY: status, 1 when MAC() = 0xF081, 2 when MAC()=0xF082 AAaa: coulomb counter BBaa: CellVoltage1 CCaa: CellVoltage2 DDaa: CellVoltage3 EEee: CellVoltage4 FFff: Tint GGgg: TS1 HHhh: TS2 Ilii TS3 JJjj: TS4 KKkk: PackVoltage LLII: BatVoltage

10.1.59 ManufacturerAccess() 0x01yy DF Access Row Address

This command sets the DF row with address yy on *ManufacturerInfo()* for immediate read/write on *ManufacturingInfo()*.

Status	Condition	Action					
Activate	0x01yy to ManufacturerAccess()	Prepare DF 32-byte row with address yy on ManufacturerInfo() for block read or write.					

10.2 0x01 RemainingCapacityAlarm()

This read/write word function sets a low capacity alarm threshold.

SBS Cmd	Name	Access		Proto-	Type	Min	Max	Unit	Note
		SE	US	FA	col	Type		WIGA	Onit
	RemainingCapacity Alarm()	naConocity.					65535	mAh	BatteryMode()[CAPM] = 0
0x01		R/W		Word	U2	0		10 mWh	BatteryMode()[CAPM] = 1

10.3 0x02 RemainingTimeAlarm()

SBS	Name		Access		Protocol	Type	Min	Max	Unit	Note
Cmd		SE	US	FA	Protocol	Туре	IVIIII	IVIAX		
0x02	RemainingTime Alarm()		R/W		Word	U2	0	65535	min	

10.4 0x03 BatteryMode()



0x04 AtRate() www.ti.com

SBS	Name		Access		Proto-	Turne	Min	Max	Note
Cmd	Name	SE	US	FA	col	Туре	Min	IVIAX	Note
0x03	BatteryMode()		R/W		Word	H2	0x0000	0xFFFF	Bit 0: ICC—Internal Charge Controller (R) 0 = Function not supported Bit 1: PBC—Primary Battery Support (R) 1 = Primary or Secondary Battery Support Bit 2: Reserved Bit 3: Reserved Bit 4: Reserved Bit 5: Reserved Bit 5: Reserved Bit 7: CF—Condition Flag 0 = Battery OK 1 = Conditioning cycle requested Bit 8: CCE—Charge Controller Enabled (R/W) 0 = Internal charge controller disabled
0x03	BatteryMode()		R/W		Word	H2	0x0000	0xFFFF	Bit 9: PB—Primary Battery (R/W) 0 = Battery operating in its secondary role (default) 1 = Battery operating in its primary role Bit 10: Reserved Bit 11: Reserved Bit 12: Reserved Bit 13: AM—Alarm Mode (R/W) 0 = Enable Alarm Warning broadcasts to host and smart battery charger 1 = Disable Alarm Warning broadcasts to host and smart battery charger Bit 14: CHGM—Charger Mode (R/W) 0 = Enable Charging Voltage() and Charging Current() broadcasts to host and smart battery charger 1 = Disable Charging Voltage() and Charging Current() broadcasts to host and smart battery charger 1 = Disable Charging Voltage() and Charging Current() broadcasts to host and smart battery charger Bit 15: CAPM—Capacity Mode (R/W) 0 = Report in mA or mAh (default) 1 = Report in 10 mW or 10 mWh

10.5 0x04 AtRate()

This read/write word function sets the value used in calculating AtRateTimeToFull() and AtRateTimeToEmpty().

SBS	Name	Access		Proto-	Proto-		Min Max	Unit	Note	
Cmd		SE	US	FA	col	Type	IVIIII	IVIAX	Offic	Note
0x04	AtRate()	R/W	D/M/		Word	12	-32768	32767	mA	BatteryMode()[CAPM] = 0
0.04	Ainale()	R/VV			vvolu	12	-32/00	32/0/	10 mW	BatteryMode()[CAPM]= 1

10.6 0x05 AtRateToFull()

This word read function returns the remaining time to fully charge the battery stack.



www.ti.com Ox06 AtRateToEmpty()

SBS	Name	Access			Protocol	Type	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAX	Onit	Note
0x05	AtRateToFull()		R		Word	U2	0	65534	min	65535 indicates not being charged

10.7 0x06 AtRateToEmpty()

This word read function returns the remaining time to fully discharge the battery stack.

SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAX	Onit	Note
0x06	AtRateToEmpty()		R		Word	U2	0	65534	min	65535 indicates not being charged

10.8 0x07 AtRateOK()

SBS	Name	Access			Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAX	Oiiit	Note
0x07	AtRateOK()		R		Word					0 = not ok

10.9 0x08 Temperatures()

SBS	Name	Access			Protocol	Type	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAX	Onic	Note
0x08	Temperatures()		R		Word	U2	0	65535	0.1°K	

10.10 0x09 Voltage()

SBS	Name		Access	i	Protocol	Туре	Min	Min Max		Note
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAX	Unit	Note
0x09	Voltage()	·	R	•	Word	U2	0	65535	mV	

10.11 0x0A Current()

SBS	Name	Access		Protocol	Type	Min	Max	Unit	Note	
Cmd	Name	SE	US	US FA Protocol Type		туре	IVIIII	IVIAX	Onit	Note
0x0A	Current()		R		Word	12	-32767	32768	mA	

10.12 0x0B AverageCurrent()

SBS	Name		Acces	s	Protocol Type Min		Min	Max	Unit	Note
Cmd	Name	SE	US	FA	11010001	Type	IVIIII	IVIAA	Oilit	Note
0x0B	Current()		R		Word	12	-32767	32768	mA	

This read word function returns an unsigned integer value of the expected margin of error, in %, in the state-of-charge calculation with a range of 1 to 100%.



SBS	Name	Access		Protocol	Type	Min	Max	Unit	Note	
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAX	Oilit	Note
0x0C	MaxError()	R		Word	U2	0	100	%		

Status	Condition	Action
	Full device reset	MaxError() = 100%
	RA-table only updated	MaxError() = 5%
	QMAX only updated	MaxError() = 3%
	RA-table and QMAX updated	MaxError() = 1%
	Each CycleCount() increment after last valid QMAX update	MaxError() increment by 0.05%
	Configuration:Max Error Time Cycle Equivalent period passed since last valid QMAX update	MaxError() increment by 0.05%

10.14 0x0D RelativeStateOfCharge()

This read word function returns the predicted remaining battery capacity as a percentage of *FullChargeCapacity()*.

SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	11010001	Турс		lilux	O.I.I.	Note
0x0D	RelativeStateOfCharge()		R		Word	U2	0	100	%	

10.15 0x0E AbsoluteStateOfCharge()

SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	туре	IVIIII	IVIAA	Oille	Note
0x0E	AbsoluteStateOfCharge()		R		Word	U2	0	100	%	

10.16 0x0F RemainingCapacity()

SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	Туре	IVIIII	IVIAX	Oilit	Note
0x0F	RemainingCapacity()	R	R	R/W	Word	U2	0	65535	mAh	BatteryMode()[CAPM] = 0
0.001	()				vvoid	02		00000	10 mWh	BatteryMode()[CAPM] = 1

10.17 0x10 FullChargeCapacity()

	SBS Cmd	Name	Access			Protocol	Туре	Min	Max	Unit	Note
			SE	US	FA	FIOLOGOI	Type	IVIIII	IVIAA	Oille	Note
•	0x10	FullChargeCapacity()	R	R	R/W	Word	U2	0	65535	mAh	BatteryMode()[CAPM] = 0
						vvoid				10 mWh	BatteryMode()[CAPM] = 1

10.18 0x11 RunTimeToEmpty()

SBS Cmd	Name	Access			Protocol	Туре	Min	Max	Unit	Note
		SE	US	FA	FIOLOCOI	Туре		IVIAA	Oiiii	Note
0x11	RunTimeToEmpty()	R	R	R	Word	U2	0	65534	min	65535 = Not being discharged



10.19 0x12 AverageTimeToEmpty()

	SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
	Cmd	Name	SE	US	FA	FIOLOCOI	Туре	IVIIII	IWIAX	Oilit	Note
Ī	0x12	AverageTimeToEmpty()	R	R	R	Word	U2	0	65534	min	65535 = Not being discharged

10.20 0x13 AverageTimeToFull()

SBS	Name		Access		Protocol	Type	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	Туре	IVIIII	Wax	Oilit	More
0x13	AverageTimeToFull()	R	R	R	Word	U2	0	65534	min	65535 = Not being discharged

10.21 0x14 ChargingCurrent()

SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	туре	IVIIII	IVIAA	Oille	More
0x14	ChargingCurrent()	R	R	R	Word	U2	0	65534	mA	65535 = request maximum current

10.22 0x15 ChargingVoltage()

SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	туре	WIIII	IVIAA	Oille	More
0x15	ChargingVoltage()	R	R	R	Word	U2	0	65534	mV	65535 = request maximum voltage

10.23 0x16 BatteryStatus()

SBS	Nama		Access		Beetseel	T	M:		Note
Cmd	Name	SE	US	FA	Protocol	Type	Min	Max	Note
0x16	BatteryStatus()	R	R	R	Word	H2			Bit 3:0: EC3,EC2,EC1,EC0 Error Code 0x0 = OK 0x1 = Busy 0x2 = Reserved Command 0x3 = Unsupported Command 0x4 = AccessDenied 0x5 = Overflow/Underflow 0x6 = BadSize 0x7 = UnknownError Bit 4: FD—Fully Discharged 0 = Battery fully depleted Bit 5: FC—Fully Charged 0 = Battery fully charged 01 = Battery fully charged 01 = Battery fully charged 01 = Battery is charging 0 = Battery is charging 1 = Battery is discharging Bit 7: INIT—Initialization 0 = Inactive 1 = Active



Ox17 CycleCount() www.ti.com

SBS	Name		Access		Protocol	Tuno	Min	Max	Note
Cmd	Name	SE	US	FA	Protocoi	Туре	IVIIII	IVIAX	Note
0x16	BatteryStatus()	R	R	R	Word	H2			Bit 9: RCA—Remaining Capacity Alarm 0 = Inactive 1 = Active Bit 10: Reserved Undefined Bit 11: TDA—Terminate Discharge Alarm 0 = Inactive 1 = Active Bit 12: OTA—Overtemperature Alarm 0 = Inactive 1 = Active Bit 13: Reserved Undefined Bit 14: TCA—Terminate Charge Alarm 0 = Inactive 1 = Active Bit 15: OCA—Overcharged Alarm 0 = Inactive 1 = Active Bit 15: OCA—Overcharged Alarm 0 = Inactive 1 = Active

10.24 0x17 CycleCount()

SBS	Name		Access	1	Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	11010001	туре	IVIIII	Wax	Oilit	Note
0x17	CycleCount()	R	R	R	Word	U2	0	65534	cycles	65535 = 65535 or more cycles

10.25 0x18 DesignCapacity()

SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	туре	IVIIII	IVIAX	Onit	Note
0x18	DesignConsoity()	R	R	R	Word	U2	0	65535	mAh	BatteryMode()[CAPM] = 0
UX16	DesignCapacity()	K	K	K	vvoid	02	U	63333	10 mWh	BatteryMode()[CAPM] = 1

10.26 0x19 DesignVoltage()

SBS	Name		Access	3	Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	11010001	турс		IVIAX	Onic	Note
0x19	DesignVoltage()	R	R	R	Word	U2	0	65535	mV	



10.27 0x1A SpecificationInfo()

SBS	Name		Access		Protocol	Tumo	Min	Max	Note
Cmd	Name	SE	US	FA	Protocol	Туре	Min	IVIAX	Note
0x1A	SpecificationInfo()	R	R	R	Word	H2	0x0000	0xFFFF	Bit 0,1,2,3: Revision Revision 0,0,0,1 = Version 1.0 and 1.1 (default) Bit 4,5,6,7: Version Version 0,0,0,1 = Version 1.0 0,0,1,1 = Version 1.1 0,0,1,1 = Version 1.1 with optional PEC support Bit 8,9,10,11: VScale Voltage Scale Factor 0,0,0,0 = reported voltages scaled by 10E0 0,0,0,1 = reported voltages scaled by 10E1 0,0,1,0 = reported voltages scaled by 10E2
0x1A	SpecificationInfo()	R	R	R	Word	H2	0x0000	0xFFFF	0,0,1,1 = reported voltages scaled by 10E3 Bit 12,13,14,15: Current 0,0,0,0 = reported currents and capacities scaled by 10E0 except ChargingVoltage() and ChargingCurrent() 0,0,0,1 = reported currents and capacities scaled by 10E1 except ChargingVoltage() and ChargingCurrent() 0,0,1,0 = reported currents and capacities scaled by 10E2 except ChargingVoltage() and ChargingCurrent() 0,0,1,1 = reported currents and capacities scaled by 10E3 except ChargingVoltage() and ChargingVoltage() and ChargingVoltage() and ChargingVoltage() and ChargingCurrent()

10.28 0x1B ManufacturerDate()

SBS	Name		Access		Protocol	Type	Min	Max	Note
Cmd	Name	SE	US	FA	1 1010001	Туре	IVIIII	IVIAA	Note
0x1B	ManufacturerDate()	R	R	R	Word				ManufacturerDate() value in the following format:Day + Month*32 + (Year–1980)*256

10.29 0x1C SerialNumber()

SBS	Name		Access	3	Protocol	Type	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAA	Oilit	Note
0x1C	SerialNumber()	R	R	R	Word					

10.30 0x20 ManufacturerName()

SBS	Name	Access		Protocol	Туре	Min	Max	Unit	Note	
Cmd	Name	SE	US	FA	11010001	Турс	Willi	IVIAA	Oille	Note
0x20	ManufacturerName()	R	R	R	Block	S21				



0x21 DeviceName() www.ti.com

10.31 0x21 DeviceName()

SBS	Name		Access	3	Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	11010001	туре	Willi	WIGA	Oiiii	Note
0x21	DeviceName()	R	R	R	Block	S21				

10.32 0x22 DeviceChemistry()

SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAA	Oille	Note
0x22	DeviceChemistry()	R	R	R	Block	S4				

10.33 0x23 ManufacturerData()

	SBS	Name		Access		Protocol	Туре	Min	Max	Unit	Note
	Cmd	Name	SE	US	FA	11010001	Туре	IVIIII	IVICA	Onne	Note
Ī	0x23	ManufacturerData()	R	R	R	Block					

10.34 0x2F Authentication() AND ManufacturerInput()

This read/write block function provides SHA-1 authentication in DEFAULT mode. It is also used to enable data flash read/writes and provide authentication input for SEALED, UNSEALED, FULL ACCESS modes.

SBS	Name		Access		Protocol	Type	Min	Max	Unit	Note	
Cmd	Name	SE	US	FA	FIOLOCOI	Туре	IVIIII	IVIAX	Oilit	Note	
0x2F	ManufacturerInput()	R/W	R/W	R/W	Block						

Status	Condition	Action
Authentication	No active <i>ManufacturerInput()</i> data waiting AND write 160-bit challenge to ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNNO OPPQQRRSSTT, where AA is LSB.	OperationStatus()[AUTH] = 1 Wait 250 ms OperationStatus()[AUTH] = 0 Device returns 160-bit digest at ManufacturerInput() in the format 0xAABBCCDDEEFFGGHHIIJJKKLLMMNNOOPP QQRRSSTTT, where AA is LSB, using the challenge + authentication key. Compare with own calculations to confirm validity of key.
ManufacturerInfo	Valid word sent to ManufacturerAccess()	Output block based on <i>ManufacturerAccess()</i> input for one time readout. Note: 0xF081 and 0xF082 on <i>ManufacturerAccess()</i> will be available for multi-read out until cleared with 0xF080.

10.35 0x3C-0x3F Cell Voltages()

SBS Cmd	Name		Access		Protocol	Туре	Min	Max	Default	Unit	Note
		SE	US	FA							
0x3C	Cell 3 voltage	R	R	R	Word	12	0	32767		mV	
0x3D	Cell 2 voltage	R	R	R	Word	12	0	32767		mV	
0x3E	Cell 1 voltage	R	R	R	Word	12	0	32767		mV	
0x3F	Cell 0 voltage	R	R	R	Word	12	0	32767		mV	



0x50 SafetyAlert() www.ti.com

10.36 0x50 SafetyAlert()

SBS	Name		Access		Proto-	Tune	Min	Max	Note
Cmd	Name	SE	US	FA	col	Type	IVIII	IVIAX	Note
0x50	SafetyAlert()	N/A	R	R	Block				Bit 0: CUV—Cell Undervoltage 0 = Inactive 1 = Detected Bit 1: COV—Cell Overvoltage 0 = Inactive 1 = Detected Bit 2: OCC1—Overcurrent in Charge 1st Tier 0 = Inactive 1 = Detected Bit 3: OCC2—Overcurrent in Charge 2nd Tier 0 = Inactive 1 = Detected Bit 4: OCD1—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 6: OLD—Overload in discharge 0 = Inactive 1 = Detected Bit 7: Reserved Bit 8: SCC—Short circuit in charge 0 = Inactive 1 = Detected Bit 10: SCD—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: Reserved Bit 12: OTC—Overtemperature in charge 0 = Inactive 1 = Detected Bit 13: OTD—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 14: CUVC—I*R compensated CUV 0 = Inactive 1 = Detected Bit 15: Reserved



0x50 SafetyAlert() www.ti.com

SBS	Name	Access		Proto-	Turna	Min	Max	Note	
Cmd	Name	SE	US	FA	col	Type	IVIIII	IVIAX	Note
0x50	SafetyAlert()	N/A	R	R	Block				Bit 16: OTF—FET overtemperature 0 = Inactive 1 = Detected Bit 17: HWD—SBS Host watchdog timeout 0 = Inactive 1 = Detected Bit 18: PTO—Precharging timeout 0 = Inactive 1 = Detected Bit 19: PTOS—Precharging timeout suspend 0 = Inactive 1 = Detected Bit 20: CTO—Charging timeout suspend 0 = Inactive 1 = Detected Bit 21: CTOS—Charging timeout suspend 0 = Inactive 1 = Detected Bit 22: CTO—Charging timeout suspend 0 = Inactive 1 = Detected Bit 22: OC—Overcharge 0 = Inactive 1 = Detected Bit 23: CHGC—Charging Current higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 25: Reserved Bit 26: Reserved Bit 27: Reserved Bit 27: Reserved Bit 28: Reserved Bit 30: Reserved Bit 31: Reserved



0x51 SafetyStatus() www.ti.com

10.37 0x51 SafetyStatus()

SBS	Name		Access		Proto-	T	Min	Max	Note
Cmd	Name	SE	US	FA	col	Type	IVIII	IVIAX	Note
0x51 Safe	tyStatus()	N/A	R	R	Block				Bit 0: CUV—Cell UnderVoltage 0 = Inactive 1 = Detected Bit 1: COV—Cell Overvoltage 0 = Inactive 1 = Detected Bit 2: OCC1—Overcurrent in Charge 1st Tier 0 = Inactive 1 = Detected Bit 3: OCC2—Overcurrent in Charge 2nd Tier 0 = Inactive 1 = Detected Bit 4: OCD1—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 6: OLD—Overload in discharge 0 = Inactive 1 = Detected Bit 7: OLDL—Overload in discharge latch 0 = Inactive 1 = Detected Bit 8: SCC—Short circuit in charge 0 = Inactive 1 = Detected Bit 9: SCCL—Short circuit in charge latch 0 = Inactive 1 = Detected Bit 10: SCD—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge latch 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge latch 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge latch 0 = Inactive 1 = Detected



Ox51 SafetyStatus() www.ti.com

SBS	Nome		Access		Proto-	Time	Min	Max	Note
Cmd	Name	SE	US	FA	col	Type	WIIN	IVIAX	Note
0x51	SafetyStatus()	N/A	R	R	Block				Bit 12: OTC—Overtemperature in charge 0 = Inactive 1 = Detected Bit 13: OTD—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 14: CUVC—I*R compensated CUV 0 = Inactive 1 = Detected Bit 15: Reserved Bit 15: Reserved Bit 16: OTF—FET overtemperature 0 = Inactive 1 = Detected Bit 17: HWD—SBS Host watchdog timeout 0 = Inactive 1 = Detected Bit 18: PTO—Precharging timeout 0 = Inactive 1 = Detected Bit 19: Reserved Bit 20: CTO—Charging timeout 0 = Inactive 1 = Detected Bit 21: Reserved Bit 22: OC—Overcharge 0 = Inactive 1 = Detected Bit 23: CHGC—Charging Current higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 25: Reserved Bit 26: Reserved Bit 27: Reserved Bit 27: Reserved Bit 29: Reserved Bit 29: Reserved Bit 29: Reserved Bit 29: Reserved Bit 30: Reserved Bit 31: Reserved



0x52 PFAlert() www.ti.com

10.38 0x52 PFAlert()


SBS	N		Access		Proto-				N
Cmd	Name	SE	US	FA	col	Туре	Min	Max	Note
0x52	PFAlert()	N/A	R	R	Block				Bit 0: CUV—Cell undervoltage 0 = Inactive 1 = Detected Bit 1: COV—Cell overvoltage 0 = Inactive 1 = Detected Bit 2: CUDEP—Copper deposition 0 = Inactive 1 = Detected Bit 3: Reserved Bit 4: OTCE—Overtemperature 0 = Inactive 1 = Detected Bit 5: Reserved Bit 6: OTF—Overtemperature FET 0 = Inactive 1 = Detected Bit 7: QIM—QMAX Imbalance 0 = Inactive 1 = Detected Bit 8: CB—Cell balancing 0 = Inactive 1 = Detected Bit 9: IMP—Cell impedance 0 = Inactive 1 = Detected Bit 10: CD—Capacity Deterioration 0 = Inactive 1 = Detected Bit 11: VIMR—Voltage imbalance at Rest 0 = Inactive 1 = Detected Bit 12: VIMA—Voltage imbalance at Rest 0 = Inactive 1 = Detected Bit 13: Reserved Bit 15: Reserved
0x52	PFAlert()	N/A	R	R	Block				Bit 16: CFETF—Charge FET 0 = Inactive 1 = Detected Bit 17: DFET—Discharge FET 0 = Inactive 1 = Detected Bit 18: THERM—Thermistor 0 = Inactive 1 = Detected Bit 19: FUSE—Fuse 0 = Inactive 1 = Detected Bit 20: AFER—AFE Register 0 = n/a 1 = Detected Bit 21: AFEC—AFE Communication 0 = Inactive 1 = Detected Bit 22: 2LVL—FUSE input indicating fuse trigger by external 2nd level protection 0 = Inactive 1 = Detected Bit 23: Reserved Bit 24: Reserved Bit 25: OCECO—Open VCx 0 = n/a 1 = Detected Bit 26: Reserved Bit 27: Reserved Bit 27: Reserved Bit 28: Reserved Bit 29: Reserved Bit 29: Reserved Bit 30: Reserved Bit 30: Reserved Bit 31: Reserved



0x53 PFStatus() www.ti.com

10.39 0x53 PFStatus()

SBS			Access		Proto-				
Cmd	Name	SE	US	FA	col	Type	Min	Max	Note
0x53	PFStatus()	N/A	R	R	Block				Bit 0: CUV—Cell undervoltage 0 = Inactive 1 = Active Bit 1: COV—Cell overvoltage 0 = Inactive 1 = Active Bit 2: Reserved Bit 3: Reserved Bit 4: OTCE—Overtemperature 0 = Inactive 1 = Active Bit 5: Reserved Bit 5: Reserved Bit 6: OTF—Overtemperature FET 0 = Inactive 1 = Active Bit 7: QIM—QMAX Imbalance 0 = Inactive 1 = Active Bit 8: CB—Cell balancing 0 = Inactive 1 = Active Bit 9: IMP—Cell impedance 0 = Inactive 1 = Active Bit 10: CD—Capacity Deterioration 0 = Inactive 1 = Active Bit 11: VIMR—Voltage imbalance at Rest 0 = Inactive 1 = Active Bit 12: VIMA—Voltage imbalance at Rest 0 = Inactive 1 = Active Bit 13: Reserved Bit 14: Reserved Bit 15: Reserved Bit 15: Reserved
0x53	PFStatus()	N/A	R	R	Block				Bit 16: CFETF—Charge FET 0 = Inactive 1 = Active Bit 17: DFET—Discharge FET 0 = Inactive 1 = Active Bit 18: THERM—Thermistor 0 = Inactive 1 = Active Bit 19: FUSE—Fuse 0 = Inactive 1 = Active Bit 20: AFER—AFE Register 0 = n/a 1 = Active Bit 21: AFEC—AFE Communication 0 = Inactive 1 = Active Bit 22: 2LVL FUSE input indicating fuse trigger by external 2nd level protection 0 = Inactive 1 = Active Bit 23:PTC—PTC by AFE 0 = Inactive 1 = Active Bit 24: IFC—Instruction Flash Checksum 0 = n/a 1 = IF checksum failure Bit 25: OCECO—Open VCx 0 = n/a 1 = Active Bit 26: DFW—DF write failure 0 = n/a 1 = Active Bit 29: Reserved Bit 29: Reserved Bit 39: Reserved Bit 30: Reserved Bit 31: Reserved





www.ti.com

10.40 0x54 OperationStatus()

SBS	Nama		Access		Proto-	T	N4:		Note
Cmd	Name	SE	US	FA	col	Type	Min	Max	Note
0x54	Operation Status()	N/A	R	R	Block				Bit 0: PRES—PRES input state 0 = PRES pin high 1 = PRES pin low detected Bit 1: DSG—DSG FET Status 0 = Disabled 1 = Enabled Bit 2: CHG—CHG FET Status 0 = Disabled 1 = Enabled Bit 3: PCHG—PCHG FET Status 0 = Disabled 1 = Enabled Bit 4: GPOD—GPOD FET Status 0 = Disabled 1 = Enabled Bit 5: FUSE—FUSE input 0 = FUSE pin low 1 = FUSE pin high detected Bit 6: CB—Cell Balancing 0 = Inactive 1 = Active Bit 7: RSVD 0 = Inactive 1 = Active Bit 9:8: SEC1,SEC0—Security Mode0 0 = Reserved 1, 0 = Full Access 0, 1 = Unsealed 1,1 = Sealed
0x54	Operation Status()	N/A	R	R	Block				Bit 10: CAL—Cal Raw ADC/CC output active 0 = Inactive 1 = Active Bit 11: SS—SafetyStatus 0 = Inactive 1 = Active Bit 12: PF—Permanent Failure 0 = Inactive 1 = Active Bit 13: XDSG—Discharging Disabled 0 = Inactive 1 = Active Bit 14: XCHG—Charging Disabled 0 = Inactive 1 = Active Bit 15: SLEEP—Sleep condition met 0 = Disabled 1 = Enabled Bit 16: SDM—Shutdown activated by ManufacturerAccess() 0 = Inactive 1 = Active Bit 17: Reserved Bit 18: AUTH—Authentication ongoing 0 = Inactive 1 = Active



0x54 OperationStatus() www.ti.com

SBS	Name		Access		Proto-	Type	Min	Max	Note
Cmd	Name	SE	US	FA	col	Туре	IVIIII	IVIAX	Note
0x54	Operation Status()	N/A	R	R	Block				Bit 19: AWD—AFE Watchdog failure 0 = Inactive 1 = Active Bit 20: FVS—Fast Voltage Sampling 0 = Inactive 1 = Active Bit 21: CALO—Raw ADC/CC offset output 0 = Inactive 1 = Active Bit 22: SDV—Shutdown activated by voltage 0 = Inactive 1 = Active Bit 23: SLEEPM—SLEEP mode active by ManufacturerAccess() 0 = Inactive 1 = Active Bit 24: INIT—Initialization after full reset, cleared when SBS data calculated and available 0 = Inactive 1 = Active Bit 25: SMBLCAL—CC auto offset calibration ongoing after SBS line goes low 0 = Inactive 1 = Active Bit 26: SLEEPQMAX—QMAX update in SLEEP mode 0 = Inactive 1 = Active Bit 27: SLEEPC—Checking current in SLEEP mode 0 = Inactive 1 = Active Bit 27: SLEEPC—Checking current in SLEEP mode 0 = Inactive 1 = Active Bit 28: XLSBS Fast Mode 0 = Inactive 1 = Active Bit 29: Reserved Bit 30: Reserved Bit 30: Reserved Bit 31: Reserved



www.ti.com Ox55 ChargingStatus()

10.41 0x55 ChargingStatus()

SBS	Nome		Access		Proto-	Time	Min	Mex	Nata
Cmd	Name	SE	US	FA	col	Type	Min	Max	Note
0x55	Charging Status()		R	R	Block				Bit 0: UT—Under Temperature Range 0 = Inactive 1 = Active Bit 1: LT—Low Temperature Range 0 = Inactive 1 = Active Bit 2: STL—Standard Temperature Low Range 0 = Inactive 1 = Active Bit 3: RT—Recommended Temperature Range 0 = Inactive 1 = Active Bit 4: ST—Standard Temperature High Range 0 = Inactive 1 = Active Bit 5: HT—High Temperature Range 0 = Inactive 1 = Active Bit 6: OT—Over Temperature Range 0 = Inactive 1 = Active Bit 7: PV—Precharge Voltage Range 0 = Inactive 1 = Active Bit 8: LV—Low Voltage Range 0 = Inactive 1 = Active Bit 9: MV—Mid Voltage Range 0 = Inactive 1 = Active Bit 10: HV—High Voltage Range 0 = Inactive 1 = Active Bit 11: IN—Charge Inhibit 0 = Inactive 1 = Active Bit 11: CCR—ChargingCurrent() Rate 0 = Inactive 1 = Active Bit 13: CCR—ChargingVoltage() Rate 0 = Inactive 1 = Active Bit 14: CVR—ChargingVoltage() Rate 0 = Inactive 1 = Active Bit 15: CCC—ChargingCurrent() Compensation 0 = Inactive 1 = Active Bit 15: CCC—ChargingCurrent() Compensation 0 = Inactive 1 = Active Bit 15: CCC—ChargingCurrent() Compensation 0 = Inactive 1 = Active



0x56 GaugingStatus() www.ti.com

10.42 0x56 GaugingStatus()

SBS			Access		Proto-	_			
Cmd	Name	SE	US	FA	col	Type	Min	Max	Note
0x56	Gauging Status()		R	R	Block				Bit 0: RESTDODO, OCV and QMAX Updated 0 = Not updated 1 = Updated Bit 1: DSG—Discharge detected 0 = Charging 1 = Discharging Bit 2: RU—Resistance update 0 = Disabled 1 = Enabled Bit 3: VOK Cell Voltage OK for QMAX update 0 = Inactive 1 = Active Bit 4: QEN—QMAX updates 0 = Disabled 1 = Enabled Bit 5: FD—Fully Discharged detected by gauge algorithm 0 = Disabled 1 = Enabled Bit 6: FC—Fully Charged detected by gauge algorithm 0 = Disabled 1 = Enabled Bit 7: NSFM—NEGATIVE SCALE FACTOR mode 0 = Disabled 1 = Enabled Bit 8: VDQ—Discharge qualified for learning 0 = Disabled 1 = Enabled Bit 9: QMAX—QMAX updated. This flag toggles every time QMAX is updated. Bit 10: RX—Resistance update. This flag toggles every time Resistance is updated. Bit 11: LDMD—LOAD mode 0 = CONSTANT CURRENT mode 1 = CONSTANT POWER mode Bit 12: OCVFR—OCV in flat region 0 = OCV outside flat region 1 = OCV in flat region Bit 13: TDA—Terminate Discharge Alarm set by gauging algorithm 0 = Disabled 1 = Enabled Bit 14: TCA—Terminate Charge Alarm set by gauging algorithm 0 = Disabled 1 = Enabled Bit 15: LPF Relax—LiPh Relax Mode, only active with Chem ID 0x400 0 = Disabled 1 = Enabled

10.43 0x57 ManufacturingStatus()

The enable bits FET_EN, LF_EN, PF_EN, BBR_EN, and FUSE_EN can be set in the golden image file if the packmaker does not want to send the individual enable commands. The only function that cannot be enabled by setting DF Setting Manufacturing Status is IT Enable. The IT Enable command is needed to take the DOD0 value for fast QMAX, etc.



www.ti.com Ox58 AFERegisters()

SBS	Nama		Access		Proto- col Type	N4:		Default	Note	
Cmd	Name	SE	US	FA	col	туре	Min	Max	Detault	Note
0x57	Manufacturing Status()		R	R	Block				0x8000	Bit 0: PCHG—PCHG Function, only available with FET = 0 0 = Disabled 1 = Enabled Bit 1: CHG—CHG FET, only available with FET = 0 0 = Disabled 1 = Enabled Bit 2: DSG—DSG FET, only available with FET = 0 0 = Disabled 1 = Enabled Bit 2: DSG—DSG FET, only available with FET = 0 0 = Disabled 1 = Enabled Bit 3: GAUGE—Gauging 0 = Disabled 1 = Enabled (default) Bit 4: FET—FET action 0 = Disabled 1 = Enabled (default) Bit 5: LF—Lifetime data collection 0 = Disabled 1 = Enabled (default) Bit 6: PF—Permanent Fail 0 = Disabled 1 = Enabled (default) Bit 7: BBR—Black Box Recorder 0 = Disabled 1 = Enabled (default) Bit 8: FUSE—FUSE action 0 = Disabled 1 = Enabled (default) Bit 8: FUSE—FUSE action 0 = Disabled 1 = Enabled (default) Bit 1: Reserved Bit 11: Reserved Bit 11: Reserved Bit 13: Reserved Bit 14: Reserved Bit 15: CAL ADC or CC output on ManufacturerData() 0 = Disabled 1 = Enabled (default)

10.44 0x58 AFERegisters()

SBS	Name		Access	i	Proto-	Type	Min	Max	Note
Cmd	Name	SE	US	FA	col	Type	IVIIII	IVIAX	Note
0x58	AFERegisters()		R	R	Block				Outputs AFE register values on ManufacturerData() in the following format: AABBCCDDEEFFGGHHIIJJKK where: • AA: STATUS register • BB: STATE_CONTROL register • CC: OUTPUT_CONTROL register • DD: OUTPUT_STATUS register • EE: FUNCTION_CONTROL register • FF: CELL_SEL register • GG: OCDV register • HH: OCDD register • II: SCC register • JJ: SCD1 register • KK: SCD2 register



0x59 TURBO_POWER() www.ti.com

10.45 0x59 TURBO_POWER()

SBS	Name	Access			Protocol	Tuno	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	Protocol	Type	IVIIII	IVIAX	Onit	Note
0x59	TURBO_POWER()	R	R	R/W	Word				cW	Computes and provides Max Power information based on the battery pack configuration

10.46 0x5A TURBO_FINAL()

SBS	Name	Access			Protocol	Туре	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	PIOLOCOI	Type	IVIIII	IVIAX	Onit	Note
0x5A	TURBO_FINAL()	R	R/W	R/W	Word				cW	Turbo Power that represents the minimal TURBO-mode power level during active operation (e.g., nonsleep) after all higher TURBO-mode levels are disabled (expected at the end of discharge).

SBS	Name	Access			Protocol	Type	Min	Max	Unit	Note	
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAX	Onn	Note	
0x5B	TURBO_PACK_R()	R	R/W	R/W	Word				mΩ	Battery pack serial resistance	

10.48 0x5C TURBO_SYS_R()

SBS			Access	1	Protocol	Туре	Min	Max	Unit	Note	
Cmd	Name	SE	US	FA	FIOLOCOI	Type	IVIIII	IVIAA	Oille	14016	
0x5C	TURBO_SYS_R()	R	R/W	R/W	Word				mΩ	System serial resistance	

10.49 0x5D MIN_SYS_V()

SBS	Name	Access			Protocol	Type	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	Protocol	Туре	IVIIII	IVIAX	Onn	Note
0x5D	MIN_SYS_V()	R	R/W	R/W	Word				mV	Minimal Voltage at system power converter input at which system will still operate

10.50 0x5E TURBO_CURRENT()

SBS	Name		Access	S	Drotocol	Type	Min	Max	Unit	Note
Cmd	Name	SE	US	FA	PIOLOCOI	Protocol Type		IVIAX	Onit	Note
0x5E	MAX-CURRENT()	R	R	R/W	Word				mA	Computes a maximal discharge current supported by the cell design.



10.51 0x60 Lifetime Data Block 1

SBS			Access		Proto-			Notes	
Cmd	Name	SE	US	FA	col	Type	Min	Max	Note
0x60	Lifetime Data Block 1		R	R	Block				Outputs lifetimes values on ManufacturerData() in the following format: AABBCCDDEEFFGGHHIIJJKKLLMMNNOOP PQQRRSSTTUUVVWWXXVVZZ1122334455 66 where: in the following format: AA: Max Cell Voltage 1 BB: Max Cell Voltage 2 CC: Max Cell Voltage 3 DD: Max Cell Voltage 4 EE: Min Cell Voltage 1 FF: Min Cell Voltage 2 GG: Min Cell Voltage 3 HH: Min Cell Voltage 3 HH: Min Cell Voltage 4 II: Max Delta Cell Voltage JJ: Max Charge Current KK: Max Discharge Current KK: Max Average Discharge Current MM: Max Average Discharge Current MM: Max Average Discharge Power NN: No of COV Events OO: Last COV Event PP: No of CUV Event RR: No of OCD1 Events SS: Last OCD1 Event TT: No of OCD2 Events UU: Last OCD2 Event VV: No of OCC1 Events WW: Last OCC1 Event XX: No of OCC2 Event YY: Last OCC2 Event XX: No of OCC2 Events YY: Last OCC2 Event TT: Last OLD Event TT: Last OLD Event TT: Last OLD Event TT: Last OCD Events TT: Last OCD Events TT: Last OCD Events TT: Last OLD Event TT: Last OLD Event TT: Last OCD Events TT: Last OCD Events TT: Last OCD Events TT: Last OLD Event TT: Last OLD Event TT: Last OCD Events

10.52 0x61 Lifetime Data Block 2



0x62 Lifetime Data Block 3 www.ti.com

SBS			Access		Proto-				5.6.1	
Cmd	Name	SE	US	FA	col	Type	Min	Max	Default	Note
0x61	Lifetime Data Block 2		R	R	Block					Outputs lifetimes values on ManufacturerData() in the following format: AABBCCDDEEFFGGHHIIJJKKL LMMNNOOPPQQRRSSTTUUVV WWXXVVZZ11 where: AA: Last OTC Event BB: No of OTD Events CC: Last OTD Event DD: No of OTF Events EE: Last OTF Event FF: No Valid Charge Terminations GG: Last Valid Charge Termination HH: No of QMAX Updates II: Last QMAX Update JJ: No of RA Updates KK: Last RA Update LL: No of RA Disables MM:Last RA Disable NN: No of Shutdowns OO: No of Partial Resets PP: No of Full Resets QQ: No of WDT Resets RR: CB Time Cell 1 SS: CB Time Cell 2 TT: CB Time Cell 3 UU: CB Time Cell 4 VV: Max Temp Cell XX: Max Delta Cell Temp YY:Max Temp Int Sensor ZZ:Min Temp Int Sensor

10.53 0x62 Lifetime Data Block 3

SBS	Name		Access		Proto-	Туре	Min	Max	Default	Note		
Cmd	Name	SE	US	FA	col	Type	IVIIII	IVIAX	Delault	Note		
										Outputs lifetimes values on ManufacturerData()		
										in the following format: aaAAbbBBccCCddDDeeEEffFF gGGhhHH where: AAaa Tatal firmunas Bun Time		
										 AAaa: Total firmware Run Time 		
0x62	Lifetime Data		R	R	Block					BBbb: Time Spent in UT		
	Block 3									CCcc: Time Spent in LT		
										DDdd: Time Spent in STL *EEee: Time Spent in RT		
										FFff: Time Spent in STH		
										 GGgg: Time Spent in HT 		
										HHhh: Time Spent in OT		



www.ti.com Ox70 ManufacturerInfo()

10.54 0x70 ManufacturerInfo()

SBS	Name		Access		Dretecal	Turns	Min Max		Note	
Cmd	Cmd	SE	US	FA	Protocol	Type	Willi	IVIAX	Note	
0x70	ManufacturerInf o()	R	R/W	R/W	Block				Instructs the device to return 32 bytes of ManufacturerInfo(). Output 32 bytes of ManufacturerInfo on ManufacturerData() in the following format: AABBCCDDEEFFGGHHIIJJKKLLMMNN OOPPQQRRSSTTUUVVWWXXVVZZ11223344 5566	

10.55 0x71 Voltages()

SBS	Name		Access		Protocol	Туре	Min	Max	Note
Cmd	Name	SE	US	FA	Protocoi	Type	IVIIII	IVIAX	Note
									Outputs 12 bytes of voltage data values on ManufacturerData() in the following format: aaAAbbBBccCCddDDeeEEffFF where:
				AAaa: Cell Voltage					
0x71	Voltages()	n/a	R	R	Block				BBbb: Cell Voltage 1
OXI I	vollagoo()	11/4			Blook				CCcc: Cell Voltage 2
									DDdd: Cell Voltage 3
						EEee: BAT Voltage			
									FFff: PACK Voltage

10.56 0x72 Temperatures()

SBS	Name		Access		Protocol	Тур	Min	Max	Note
Cmd	Name	SE	US	FA	Protocol	e	IVIII	Wax	Note
0x72	Temperatures()	n/a	R	R	Block				 Outputs 14 bytes of temperature data values on ManufacturerData() in the following format: aaAAbbBBccCCddDDeeEEffFF where: AAaa: Int Temperature BBbb: TS1 Temperature CCcc: TS2 Temperature DDdd: TS3 Temperature EEee: TS4 Temperature FFff: Cell Temperature GGgg: FET Temperature

10.57 0x73 ITStatus1()

This read block function returns gauging algorithm related parameters.



0x74 ITStatus2() www.ti.com

SBS	Name		Access		Proto-	Type	Min	Max	Note
Cmd	Name	SE	US	FA	col	Туре	IVIIII	IVIAX	Note
0x73	ITStatus1()	n/a	R	FA R	Block				Outputs 30 bytes of IT data values on Manufacturer/Data() in the following format: aaAAbbBBccCCddDeeEEffFFGGggHHhhllii JJjjkkKKIILLmmMMnnNNooOO where: • AAaa: DOD0 Cell 0 • BBbb: DOD0 Cell 1 • CCcc: DOD0 Cell 2 • DDdd: DOD0 Cell 3 • EEee: Passed Charge since last DOD0 Update • FFff: QMAX Cell 0 • GGgg: QMAX Cell 1 • HHhh: QMAX Cell 2 • Ilii: QMAX Cell 3 • JJjjKKkk: State Time
									LLII: DOD EOC Cell 0
									MMmm: DOD EOC Cell 1
									NNnn: DOD EOC Cell 2
									OOoo: DOD EOC Cell 3

Attribute	Description	Format
DOD0_0	Depth of discharge cell 0	12
DOD0_1	Depth of discharge cell 1	12
DOD0_2	Depth of discharge cell 2	12
DOD0_3	Depth of discharge cell 3	12
ChargeDOD0Update	Passed charge since last DOD0 update	12
QMAX0	QMAX of cell 0	12
QMAX1	QMAX of cell 1	12
QMAX2	QMAX of cell 2	12
QMAX3	QMAX of cell 3	I2
StateTime	Time past since last state change (DSG,CHG,RST)	U4
DODEOC0	Depth of discharge cell at End of Charge cell 0	U2
DODEOC1	Depth of discharge cell at End of Charge cell 1	U2
DODEOC2	Depth of discharge cell at End of Charge cell 2	U2
DODEOC3	Depth of discharge cell at End of Charge cell 3	U2

10.58 0x74 ITStatus2()

This read block function returns gauging algorithm related parameters.



0x74 ITStatus2() www.ti.com

SBS	Name		Access		Proto-	Min	Max	Note	
Cmd	Name	SE	US	FA	col	туре	IVIIII	IVIAX	Note
Cma		SE	US	FA	col				Outputs 30 bytes of IT data values on ManufacturerData() in the following format: AABBCCDDEEFFggGGhhHHiilljjJJkkKKIILLmmMMnnNNooOoppPqqQQrrRR where: • AA: Pack Grid point • BB: Learned Status • CC: Grid Cell 0 • DD: Grid Cell 1 • EE: Grid Cell 2 • FF: Grid Cell 3
0x74	ITStatus2()		R	R	Block				GGgg: CompRes Cell 0 HHhh: CompRes Cell 1 Ilii: CompRes Cell 2 JJjj: CompRes Cell 3 Kkkk: CB Time Cell 0 LLII: CB Time Cell 1 MMmm: CB Time Cell 2 NNnn: CB Time Cell 3 OOoo: RaScale0 PPpp: RaScale1 QQqq: RaScale2 RRrr: RaScale3

Attribute	Description	Format		
PackGrid	Active pack grid point (minimum of CellGrid0 to CellGrid3)	U1		
LStatus	Learned status of resistance table	Bit 1,0: CF—QMAX status 0,0 = Battery OK 0,1 = QMAX is first updated in learning cycle 1,0 = QMAX and resistance table updated in learning cycle Bit 2: ITEN—IT enable 0 = IT disabled 1 = IT Enabled Bit 3: ITEN—QMAX update in Field 0 = QMAX never updated in field 1 = QMAX updated in field		
CellGrid0	Active grid point cell 0	U1		
CellGrid1	Active grid point cell 1	U1		
CellGrid2	Active grid point cell 2	U1		
CellGrid3	Active grid point cell 3	U1		
CompRes0	Last calculated temperature compensated resistance cell 0	U2		
CompRes1	Last calculated temperature compensated resistance cell 1	U2		
CompRes2	Last calculated temperature compensated resistance cell 2	U2		
CompRes3	Last calculated temperature compensated resistance cell 3	U2		
CBTime0	Calculated cell balancing time cell 0	U2		
CBTime1	Calculated cell balancing time cell 1	U2		
CBTime2	Calculated cell balancing time cell 2	U2		
CBTime3	Calculated cell balancing time cell 3	U2		
RaScale0	Ra Table scaling factor cell 0	U2		
RaScale1	Ra Table scaling factor cell 1	U2		
RaScale2	Ra Table scaling factor cell 2	U2		
RaScale3	Ra Table scaling factor cell 3	U2		



Data Flash Values and Device Configuration

11.1 Data Formats

11.1.1 Unsigned Integer

Unsigned integers are stored without changes as 1-byte, 2-byte, or 4-byte values.

11.1.2 Integer

Integer values are stored in 2's-complement format in 1-byte, 2-byte, or 4-byte values.

11.1.3 Floating Point

Floating point is stored using 4-byte format, where the MSB is the exponent, byte 3 to 0 is the mantissa in unsigned integer format, with the MSB in byte 3 as sign bit.

Where:

Exp: Exponent

Mantissa: 23 bit mantissa with 24 bit as sign bit.

11.1.4 Hex

Bit register definitions are stored in unsigned integer format.

11.1.5 String

String values are stored with length byte first, followed by a number of data bytes defined with the length byte.

11.2 Protections

11.2.1 CUV—Cell Undervoltage

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	CUV	Threshold	12	0	32767	2800	mV	Cell undervoltage trip threshold
Protections	CUV	Delay	U1	0	255	2	s	Cell undervoltage trip delay
Protections	CUV	Recovery	12	0	32767	3000	mV	Cell undervoltage recovery threshold



www.ti.com Protections

11.2.2 COV—Cell Overvoltage

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Protections	COV	Threshold Low Temp	12	0	32767	4250	mV	Cell overvoltage low temperature range trip threshold
Protections	COV	Threshold Standard Temp	12	0	32767	4250	mV	Cell overvoltage standard temperature range trip threshold
Protections	COV	Threshold High Temp	12	0	32767	4250	mV	Cell overvoltage high temperature range trip threshold
Protections	COV	Threshold Rec Temp	12	0	32767	4250	mV	Cell overvoltage recommended temperature range trip threshold
Protections	COV	Delay	U1	0	255	2	s	Cell overvoltage trip delay
Protections	COV	Recovery Low Temp	12	0	32767	4150	mV	Cell overvoltage low temperature range recovery threshold
Protections	COV	Recovery Standard Temp	12	0	32767	4150	mV	Cell overvoltage standard temperature recovery range threshold
Protections	COV	Recovery High Temp	12	0	32767	4150	mV	Cell overvoltage high temperature range recovery threshold
Protections	COV	Recovery Rec Temp	12	0	32767	4150	mV	Cell overvoltage recommended temperature range recovery threshold

11.2.3 OCC1—Overcurrent In Charge 1

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Protections	OCC1	Threshold	12	-32768	32767	6000	mA	Overcurrent in Charge 1 trip threshold
Protections	OCC1	Delay	U1	0	255	6	S	Overcurrent in Charge 1 trip delay

11.2.4 OCC2—Overcurrent In Charge 2

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protection	ns OCC2	Threshold	12	-32768	32767	8000	mA	Overcurrent in Charge 2 trip threshold
Protection	ns OCC2	Delay	U1	0	255	3	S	Overcurrent in Charge 2 trip delay

11.2.5 OCC Overcurrent In Charge Recovery

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	occ	Recovery Threshold	12	-32768	32767	-50	mA	Overcurrent in Charge 1 and 2 recovery threshold
Protections	осс	Recovery Delay	U1	0	255	5	S	Overcurrent in Charge 1 and 2 recovery delay



Protections www.ti.com

11.2.6 OCD1—Overcurrent In Discharge 1

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	OCD1	Threshold	12	-32768	32767	-6000	mA	Overcurrent in Discharge 1 trip threshold
Protections	OCD1	Delay	U1	0	255	6	s	Overcurrent in Discharge 1 trip delay

11.2.7 OCD2—Overcurrent In Discharge 2

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	OCD2	Threshold	12	-32768	32767	-8000	mA	Overcurrent in Discharge 2 trip threshold
Protections	OCD2	Delay	U1	0	255	3	S	Overcurrent in Discharge 2 trip delay

11.2.8 OCD—Overcurrent In Discharge Recovery

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	OCD	Recovery	12	-32768	32767	50	mA	Overcurrent in Discharge 1 and 2 recovery threshold
Protections	OCD	Recovery Delay	U1	0	255	5	s	Overcurrent in Discharge 1 and 2 recovery delay

11.2.9 OLD—Overload in Discharge

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	OLD	Threshold	H1	0x00	0x0F	0x09	10 mV	Bit 3:0: Overload Trip Threshold between SRP and SRN Threshold can be set from 50 mV to 200 mV with 10 mV step. If Settings:AFE State Control[RSNS] = 1, threshold value will be divided in half. See Appendix A for details.
Protections	OLD	Delay	H1	0x00	0x0F	0x0F	2 ms	Bit 3:0: Overload Trip Delay Delay can be set from 1 ms to 31 s with 2-ms steps. See Appendix A for details.
Protections	OLD	Latch Limit	U1	0	255	0	counts	Overload latch counter trip threshold
Protections	OLD	Counter Dec Delay	U1	0	255	10	S	Overload latch counter decrement delay
Protections	OLD	Recovery	U1	0	255	5	S	Overload recovery time
Protections	OLD	Reset	U1	0	255	15	S	Overload latch reset time

11.2.10 SCC—Short Circuit In Charge

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Protections	SCC	Threshold	H1	0x00	0xFF	0x77		Bit 2:0: Short Circuit in Charge Threshold—Threshold can be set from 100 mV to 300 mV in 50-mV steps. If Settings:AFE State Control[RSNS] = 1, Threshold value will be divided in half. Bit 3: Reserved Bit 7:4: Short Circuit in Charge Delay Time—Delay can be set from 0 μs to 915 μs in 61-μs steps. See Appendix A for details.



Protections www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	SCC	Latch Limit	U1	0	255	0		Short Circuit in Charge Latch counter trip threshold
Protections	SCC	Counter Dec Delay	U1	0	255	10	s	Short Circuit in Charge counter decrement delay
Protections	SCC	Recovery	U1	0	255	5	S	Short Circuit in Charge recovery time
Protections	SCC	Reset	U1	0	255	15	S	Short Circuit in Charge latch reset time

11.2.11 SCD1—Short Circuit In Discharge 1

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	SDC1	Threshold	Н1	0x00	0xFF	0x77		Bit 2:0: Short Circuit in Discharge1 Threshold—Threshold can be set from 100 mV to 300 mV in 50 mV step. If Settings:AFE State Control[RSNS] = 1, Threshold value will be divided in half. Bit 3: Reserved Bit 7:4: Short Circuit in Discharge1 Delay Time—Delay can be set from 0 µs to 915 µs in 61-µs step. If Settings:AFE State Control[SCDDx2] = 1, Delay Time value will be doubled. See Appendix A for details.

11.2.12 SCD2—Short Circuit in Discharge 2

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Protections	SDC2	Threshold	H1	0x00	0xFF	0xE7		Bit 2:0: Short Circuit in Discharge2 Threshold—Threshold can be set from 100 mV to 300 mV in 50 mV step. If Settings:AFE State Control[RSNS] = 1, Threshold value will be divided in half. Bit 3: Reserved Bit 7:4: Short Circuit in Discharge2 Delay Time—Delay can be set from 0 µs to 458 µs in 30 µs step. If Settings:AFE State Control[SCDDx2] = 1, Delay Time value will be doubled. See Appendix A for details.

11.2.13 SCD—Short Circuit in Discharge

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	SCD	Latch Limit	U1	0	255	0		Short Circuit in Discharge Latch counter trip threshold
Protections	SCD	Counter Dec Delay	U1	0	255	10	S	Short Circuit in Discharge counter decrement delay
Protections	SCD	Recovery	U1	0	255	5	S	Short Circuit in Discharge recovery time
Protections	SCD	Reset	U1	0	255	15	S	Short Circuit in Discharge latch reset time

11.2.14 OTC—Over Temperature in Charge

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Protections	отс	Threshold	12	-400	1500	550	0.1°C	Over Temperature in Charge trip threshold
Protections	отс	Delay	U1	0	255	2	S	Over Temperature in Charge Cell trip delay
Protections	отс	Recovery	12	-400	1500	500	0.1°C	Over Temperature in Charge Cell recovery threshold



Protections www.ti.com

11.2.15 OTD—Over Temperature in Discharge

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	OTD	Threshold	12	-400	1500	600	0.1°C	Over Temperature in Discharge trip threshold
Protections	OTD	Delay	U1	0	255	2	s	Over Temperature in Discharge trip delay
Protections	OTD	Recovery	12	-400	1500	550	0.1°C	Over Temperature in Discharge recovery threshold

11.2.16 OTF—Over Temperature FET

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	OTF	Threshold	12	-400	1500	800	0.1°C	Over Temperature FET trip threshold
Protections	OTF	Delay	U1	0	255	2	s	Over Temperature FET trip delay
Protections	OTF	Recovery	12	-400	1500	650	0.1°C	Over Temperature FET recovery threshold

11.2.17 HWD—Host Watchdog

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	HWD	Delay	U1	0	255	10	S	SBS Host watchdog trip delay

11.2.18 PTO—PRECHARGE Mode Time Out

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	РТО	Charge Threshold	12	-32768	32767	2000	mA	Precharge Timeout Current Threshold
Protections	PTO	Suspend Threshold	12	-32768	32767	1800	mA	Precharge Timeout Suspend Threshold
Protections	PTO	Delay	U2	0	65535	1800	s	Precharge Timeout trip delay
Protections	РТО	Reset	12	-32768	32767	2	mA	Precharge Timeout Reset Threshold

11.2.19 CTO—FAST CHARGE Mode Time Out

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	СТО	Charge Threshold	12	-32768	32767	2500	mA	Fast-Charge Timeout Current Threshold
Protections	СТО	Suspend Threshold	12	-32768	32767	2000	mA	Fast-Charge Timeout Suspend Threshold
Protections	СТО	Delay	U2	0	65535	54000	s	Fast-Charge Timeout trip delay
Protections	СТО	Reset	12	-32768	32767	2	mA	Fast-Charge Timeout Reset Threshold

11.2.20 OC—Overcharge

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	OC	Threshold	12	-32768	32767	300	mAh	Overcharge trip threshold
Protections	OC	Recovery	12	-32768	32767	2	mAh	Overcharge recovery threshold
Protections	ОС	RSOC Recovery	U1	0	100	90	%	Overcharge RemainingStateOfCharge() recovery threshold



Permanent Fail www.ti.com

11.2.21 CHGV—ChargingVoltage

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	CHGV	Threshold	12	-32768	32767	500	mV	ChargingVoltage() delta trip threshold
Protections	CHGV	Delay	U1	0	255	30	s	ChargingVoltage() delta trip delay
Protections	CHGV	Recovery	12	-32768	32767	-500	mV	ChargingVoltage() delta recovery threshold

11.2.22 CHGC—ChargingCurrent

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Protections	CHGC	Threshold	12	-32768	32767	500	mA	ChargingCurrent() delta trip threshold
Protections	CHGC	Delay	U1	0	255	2	S	ChargingCurrent() delta trip delay
Protections	CHGC	Recovery	12	-32768	32767	100	mA	ChargingCurrent() delta recovery threshold

11.3 Permanent Fail

11.3.1 CUV—Cell Undervoltage

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	CUV	Threshold	12	0	32767	2500	mV	Cell Undervoltage trip threshold
Permanent Fail	CUV	Delay	U1	0	255	2	s	Cell Undervoltage trip delay

11.3.2 COV—Cell Overvoltage

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	COV	Threshold	12	0	32767	4400	mV	Cell Overvoltage trip threshold
Permanent Fail	COV	Delay	U1	0	255	2	s	Cell Overvoltage trip delay

11.3.3 CUDEP—Copper Deposition

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Permanent Fail	CUDEP	Threshold	12	0	32767	2500	mV	Copper Deposition trip threshold
Permanent Fail	CUDEP	Delay	U1	0	255	2	s	Copper Deposition trip delay

11.3.4 OTCE—Over Temperature Cell

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	OTCE	Threshold	12	-400	1500	650	0.1°C	Over Temperature Cell trip threshold
Permanent Fail	OTCE	Delay	U1	0	255	2	s	Over Temperature Cell trip delay



Permanent Fail www.ti.com

11.3.5 OTF—Over Temperature FET

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	OTF	Threshold	12	-400	1500	1000	0.1°C	Over Temperature FET trip threshold
Permanent Fail	OTF	Delay	U1	0	255	2	S	Over Temperature FET trip delay

11.3.6 CB—Cell Balance

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	СВ	Max Threshold	12	0	32767	120	2h	Cell Balance max trip threshold
Permanent Fail	СВ	Delta Threshold	U1	0	32767	20	2h	Cell Balance cell delta trip threshold
Permanent Fail	СВ	Delay	U1	0	255	2	cycles	Cell Balance trip delay

11.3.7 VIMR—Voltage Imbalance at Rest

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	VIMR	Check Voltage	12	0	5000	3500	mV	Voltage Imbalance at Rest Check Voltage
Permanent Fail	VIMR	Check Current	12	0	32767	10	mA	Voltage Imbalance at Rest Check Current
Permanent Fail	VIMR	Delta Threshold	12	0	5000	200	mV	Voltage Imbalance at Rest trip threshold
Permanent Fail	VIMR	Delay	U1	0	255	2	s	Voltage Imbalance at Rest Check trip delay
Permanent Fail	VIMR	Duration	U2	0	65535	100	S	Voltage Imbalance at Rest Check Duration

11.3.8 VIMA—Voltage Imbalance Active

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	VIMA	Check Voltage	12	0	5000	3700	mV	Voltage Imbalance active Check Voltage
Permanent Fail	VIMA	Check Current	12	0	32767	50	mA	Voltage Imbalance active Check Current
Permanent Fail	VIMA	Delta Threshold	12	0	5000	300	mV	Voltage Imbalance active trip threshold
Permanent Fail	VIMA	Delay	U1	0	255	2	s	Voltage Imbalance active Check trip delay

11.3.9 CD—Capacity Degradation

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Permanent Fail	CD	Threshold	12	0	32767	4200	mAh	Capacity Degradation threshold
Permanent Fail	CD	Delay	U1	0	255	2	cycles	Capacity Degradation trip delay



www.ti.com Permanent Fail

11.3.10 CFETF—CHG FET Failure

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Permanent Fail	CFETF	OFF Threshold	12	0	500	5	mA	CHG FET OFF current trip threshold
Permanent Fail	CFETF	Delay	U1	0	255	2	S	CHG FET OFF trip delay

11.3.11 DFET—DFET Failure

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Permanent Fail	DFETF	OFF Threshold	12	-500	0	- 5	mA	DSG FET OFF current trip threshold
Permanent Fail	DFETF	Delay	U1	0	255	2	S	DSG FET OFF trip delay

11.3.12 THERM—NTC Thermistor Failure

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	THERM	ADC Delay	U1	0	255	10	s	Thermistor fail trip delay

11.3.13 FUSE—FUSE Failure

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	FUSE	Threshold	12	0	255	5	mA	FUSE activation fail trip threshold
Permanent Fail	FUSE	Delay	U1	0	255	2	S	FUSE activation fail trip delay

11.3.14 AFER—AFE Register

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	AFER	Threshold	U1	0	255	100	counts	AFE Register comparison fail trip threshold
Permanent Fail	AFER	Delay Period	U1	0	255	2	S	AFE Register comparison fail trip delay
Permanent Fail	AFER	Compare Period	U1	0	255	5	s	AFE Register comparison compare period

11.3.15 AFEC—AFE Communication

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	AFEC	Threshold	U1	0	255	100	counts	AFE Communication fail trip threshold
Permanent Fail	AFEC	Delay Period	U1	0	255	5	S	AFE Communication fail trip delay



11.3.16 2LVL—2nd Level OV

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Permanent Fail	2LVL	Threshold	U1	0	255	2	S	2nd Level Protector trip detection delay

11.3.17 OCECO—Open Cell Connection

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Permanent Fail	OCECO	Threshold	U2	0	32767	5000	mV	Open Cell Tab Connection trip threshold
Permanent Fail	OCECO	Delay Period	U1	0	255	2	S	Open Cell Tab Connection trip delay

11.4 Advanced Charging Algorithm

11.4.1 Temperature Ranges

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	Temperature Ranges	T1	I1	-128	127	0		T1 low temperature range lower limit
Advanced Charging Algorithms	Temperature Ranges	T2	I1	-128	127	12		T2 low temperature range to standard temperature range
Advanced Charging Algorithms	Temperature Ranges	T5	I1	-128	127	20		T5 recommended temperature range lower limit
Advanced Charging Algorithms	Temperature Ranges	Т6	I1	-128	127	25		T6 recommended temperature range upper limit
Advanced Charging Algorithms	Temperature Ranges	Т3	I1	-128	127	30		T3 standard temperature range to high temperature range
Advanced Charging Algorithms	Temperature Ranges	T4	I1	-128	127	55		T4 high temperature range upper limit
Advanced Charging Algorithms	Temperature Ranges	Hysteresis	I1	-128	127	0		Temperature Hysteresis, applied when temperature is decreasing

11.4.2 Low Temp Charging

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	Low Temp Charging	Voltage	12	0	32767	3000	mV	Low temperature range ChargingVoltage()
Advanced Charging Algorithms	Low Temp Charging	Current Low	12	0	32767	132	mA	Low temperature range low voltage range ChargingCurrent()
Advanced Charging Algorithms	Low Temp Charging	Current Med	12	0	32767	352	mA	Low temperature range medium voltage range ChargingCurrent()
Advanced Charging Algorithms	Low Temp Charging	Current High	12	0	32767	264	mA	Low temperature range high voltage range ChargingCurrent()



11.4.3 Standard Temp Charging

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	Standard Temp Charging	Voltage	I2	0	32767	4200	mV	Standard temperature range ChargingVoltage()
Advanced Charging Algorithms	Standard Temp Charging	Current Low	I2	0	32767	1980	mA	Standard temperature range low voltage range ChargingCurrent()
Advanced Charging Algorithms	Standard Temp Charging	Current Med	I2	0	32767	4004	mA	Standard temperature range medium voltage range ChargingCurrent()
Advanced Charging Algorithms	Standard Temp Charging	Current High	12	0	32767	2992	mA	Standard temperature range high voltage range ChargingCurrent()

11.4.4 High Temp Charging

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	High Temp Charging	Voltage	12	0	32767	4000	mV	High temperature range ChargingVoltage()
Advanced Charging Algorithms	High Temp Charging	Current Low	I2	0	32767	1012	mA	High temperature range low voltage range ChargingCurrent()
Advanced Charging Algorithms	High Temp Charging	Current Med	I2	0	32767	1980	mA	High temperature range medium voltage range ChargingCurrent()
Advanced Charging Algorithms	High Temp Charging	Current High	12	0	32767	1496	mA	High temperature range high voltage range ChargingCurrent()

11.4.5 REC Temp Charging

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	Rec Temp Charging	Voltage	12	0	32767	4100	mV	Recommended temperature range ChargingVoltage()
Advanced Charging Algorithms	Rec Temp Charging	Current Low	12	0	32767	2508	mA	Recommended temperature range low voltage range ChargingCurrent()
Advanced Charging Algorithms	Rec Temp Charging	Current Med	12	0	32767	4488	mA	Recommended temperature range medium voltage range ChargingCurrent()
Advanced Charging Algorithms	Rec Temp Charging	Current High	12	0	32767	3520	mA	Recommended temperature range high voltage range ChargingCurrent()

11.4.6 PCHG

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description	
Advanced Charging Algorithms	PCHG	Current	12	0	32767	88	mA	Precharge ChargingCurrent()	



11.4.7 MCHG

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	MCHG	Current	12	0	32767	44	mA	Maintenance ChargingCurrent()

11.4.8 Voltage Range

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	Voltage Range	Charging Voltage Low	12	0	32767	2500	mV	Precharge Voltage range to Charging Voltage Low range
Advanced Charging Algorithms	Voltage Range	Charging Voltage Med	12	0	32767	3600	mV	Charging Voltage Low range to Charging Voltage Med range
Advanced Charging Algorithms	Voltage Range	Charging Voltage High	12	0	32767	4000	mV	Charging Voltage Med to Charging Voltage High range
Advanced Charging Algorithms	Voltage Range	Hysteresis	U1	0	255	0	mV	Charging Voltage Hysteresis applied when voltage is decreasing

11.4.9 Termination Config

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	Termination Config	Charge Term Taper Current	12	0	32767	250	mA	Valid Charge Termination taper current qualifier threshold
Advanced Charging Algorithms	Termination Config	Charge Term Voltage	12	0	32767	75	mV	Valid Charge Termination delta voltage qualifier, max cell based

11.4.10 Cell Balancing Config

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	Cell Balancing Config	Balance Time per mAh cell 0	U2	0	65535	367	s/mAh	Required balance time per mAh. For information on how to calculate balancing time, see Section 7.5.
Advanced Charging Algorithms	Cell Balancing Config	Balance Time per mAh cell 1–3	U2	0	65535	514	s/mAh	Required balance time per mAh. For information on how to calculate balancing time, see Section 7.5.
Advanced Charging Algorithms	Cell Balancing Config	Min Start Balance Delta	U1	0	255	3	mV	Minimum cell voltage delta to start cell balancing. This condition is checked in relaxation state and is only applies if cell balancing at rest is enabled.
Advanced Charging Algorithms	Cell Balancing Config	Relax Balance Interval	U4	0	42949672 95	18000	S	Minimum relax time after cell balancing stopped to enable balancing again. This parameter applies to cell balancing at rest only.
Advanced Charging Algorithms	Cell Balancing Config	Min RSOC for Balancing	U1	0	100	80	%	Minimum RelativeStateOfCharge() threshold for cell balancing. This condition is checked during relaxation and is only applies if cell balancing at rest is enabled.

11.4.11 Charging Rate of Change



www.ti.com System Data

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	Charging Rate of Change	Current Rate	U1	1	255	1	steps/s	Number of steps to add between any 2 ChargingCurrent() settings
Advanced Charging Algorithms	Charging Rate of Change	Voltage Rate	U1	1	255	1	steps/s	Number of steps to add between any 2 ChargingVoltage() settings

11.4.12 Charge Loss Compensation

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Advanced Charging Algorithms	Charge Loss Compensation	CCC Current Threshold	12	0	32767	3520	mA	CONSTANT CURRENT CHARGE mode ChargingCurrent() threshold to activate Charge Loss Compensation
Advanced Charging Algorithms	Charge Loss Compensation	CCC Voltage Threshold	12	0	255	4200	mV	CONSTANT CURRENT CHARGE mode max ChargingVoltage() increase limit

11.5 System Data

11.5.1 Manufacturer Data

Class	Subclass	Name	Туре	Min	Max	Unit	Description
System Data	ManufacturerData	ManufacturerInfo	S33				ManufacturerInfo() value
System Data	ManufacturerData	DF Checksum	H2	0	FFFF	Hex	Holding place for DF checksum, not modified or read by device, for reference only

11.6 SBS Configuration

11.6.1 Data

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
SBS Configuration	Data	Remaining Ah Cap. Alarm	12	0	32767	300	mAh	RemainingCapacityAlarm() value in mAh
SBS Configuration	Data	Remaining Wh Cap. Alarm	12	0	32767	432	10 mWh	RemainingCapacityAlarm() value in 10 mWh
SBS Configuration	Data	Remaining Time Alarm	U2	0	65535	10	min	RemainingTimeAlarm() value



SBS Configuration www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
SBS Configuration	Data	Initial Battery Mode	H2	0x0000	0xFFFF	0x81		BatteryMode() value Bit 0: ICC Internal_Charge_Controller 0 = Function not supported Bit 1: PBS Primary_Battery_Support 1 = Primary or Secondary Battery Support Bit 2: Reserved Bit 3: Reserved Bit 4: Reserved Bit 5: Reserved Bit 6: Reserved Bit 7: CF—Condition_Flag 0 = Battery OK 1 = Conditioning cycle requested Bit 8: CCE—Charge_Controller_Enabled (R/W) 0 = Internal charge controller disabled Bit 9: PB—Primary_Battery (R/W) 0 = Battery operating in its secondary role (default) 1 = Battery operating in its primary role Bit 10: Reserved Bit 12: Reserved Bit 13: AM—Alarm Mode (R/W) 0 = Enable Alarm Warning broadcasts to host and smart battery charger Bit 14: CHGM—Charger_Mode (R/W) 0 = Enable ChargingVoltage() and ChargingCurrent() broadcasts to host and smart battery charger 1 = Disable ChargingVoltage() and ChargingCurrent() broadcasts to host and smart battery charger 1 = Disable ChargingVoltage() and ChargingCurrent() broadcasts to host and smart battery charger 1 = Disable ChargingVoltage() and ChargingCurrent() broadcasts to host and smart battery charger 1 = Disable ChargingVoltage() and ChargingCurrent() broadcasts to host and smart battery charger Bit 15: CAPM—Capacity_Mode (R/W) 0 = Report in mA or mAh (default) 1 = Report in 10 mW or 10 mWh
SBS Configuration	Data	Design Voltage	12	0	32767	14400	mV	DesignVoltage() value
SBS Configuration	Data	Specification Information	H2	0x0000	0xFFFF	0x31		SpecificationInfo() value in the following format: Bit 0,1,2,3: Revision Revision 0,0,0,1 = Version 1.0 and 1.1 (default) Bit 4,5,6,7: Version Version 0,0,0,1 = Version 1.0 0,0,1,1 = Version 1.1 0,0,1,1 = Version 1.1 with optional PEC support Bit 8,9,10,11: VScale Voltage Scale Factor is not supported by the firmware. Bits 8–11 must be set to 0,0,0,0 to indicate reported voltages are scaled by 1.Bit 12,13,14,15: IPScale IP Scale Factor is not supported by the firmware. Bits 12–15 must be set to 0,0,0,0 to indicate reported currents and capacities are scaled by 1.
SBS Configuration	Data	Manufacturer Date	U2	0	65535			ManufacturerDate() value in the following format:Day + Month*32 + (Year-1980)*256
SBS Configuration	Data	Serial Number	H2	0x0000	0xFFFF			SerialNumber() value
SBS Configuration	Data	Cycle Count	U2	0	65535		cycles	CycleCount() value
SBS Configuration	Data	Cycle Count Percentage	U1	0	255	90	%	Based on the <i>[CCT]</i> bit setting, the device uses accumulated discharge of <i>FullChargeCapacity()</i> or <i>DesignCapacity()</i> * (Cycle Count Percentage) to increment <i>CycleCount()</i>
SBS Configuration	Data	Max Error Limit	U1	0	100	100	%	MaxError() threshold to set BatteryMode()[CF]
SBS Configuration	Data	Design Capacity	12	0	32767	4400	mAh	DesignCapacity() value in mAh



www.ti.com SBS Configuration

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
SBS Configuration	Data	Design Capacity	12	0	32767	6336	10 mWh	DesignCapacity() value in 10 mWh
SBS Configuration	Data	Manufacturer Name	S21					ManufacturerName() value
SBS Configuration	Data	Device Name	S21					DeviceName() value
SBS Configuration	Data	Device Chemistry	S5					DeviceChemistry() value

11.6.2 FD

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
SBS Configuration	FD	Set Voltage Threshold	12	0	5000	3000	mV	BatteryStatus()[FD] cell voltage set threshold
SBS Configuration	FD	Clear Voltage Threshold	12	0	5000	3100	mV	BatteryStatus()[FD] cell voltage clear threshold
SBS Configuration	FD	Set RSOC % Threshold	U1	0	100	0	%	BatteryStatus()[FD]RemainingStateOfChar ge() set threshold
SBS Configuration	FD	Clear RSOC % Threshold	U1	0	100	5	%	BatteryStatus()[FD]RemainingStateOfChar ge() clear threshold

11.6.3 FC

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
SBS Configuration	FC	Set Voltage Threshold	12	0	5000	4200	mV	BatteryStatus()[FC] cell voltage set threshold
SBS Configuration	FC	Clear Voltage Threshold	12	0	5000	4100	mV	BatteryStatus()[FC] cell voltage clear threshold
SBS Configuration	FC	Set RSOC % Threshold	U1	0	100	100	%	BatteryStatus()[FC]RemainingStateOfCharge() set threshold
SBS Configuration	FC	Clear RSOC % Threshold	U1	0	100	95	%	BatteryStatus()[FC] RemainingStateOfCharge() clear threshold

11.6.4 TDA

Per the Smart Battery Data Specification 1.1, TDA is only active while discharging.

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
SBS Configuration	TDA	Set Voltage Threshold	12	0	5000	3200	mV	BatteryStatus()[TDA] cell voltage set threshold
SBS Configuration	TDA	Clear Voltage Threshold	12	0	5000	3300	mV	BatteryStatus()[TDA] cell voltage clear threshold
SBS Configuration	TDA	Set RSOC % Threshold	U1	0	100	10	%	BatteryStatus()[TDA] RemainingStateOfCharge() set threshold
SBS Configuration	TDA	Clear RSOC % Threshold	U1	0	100	15	%	BatteryStatus()[TDA] RemainingStateOfCharge() clear threshold

11.6.5 TCA

Per the Smart Battery Data Specification 1.1, TCA is only active while charging.

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
SBS Configuration	TCA	Set Voltage Threshold	12	0	5000	4200	mV	BatteryStatus()[TCA] cell voltage set threshold
SBS Configuration	TCA	Clear Voltage Threshold	12	0	5000	4100	mV	BatteryStatus()[TCA] cell voltage clear threshold
SBS Configuration	TCA	Set RSOC % Threshold	U1	0	100	100	%	BatteryStatus()[TCA] RemainingStateOfCharge() set threshold
SBS Configuration	TCA	Clear RSOC % Threshold	U1	0	100	95	%	BatteryStatus()[TCA] RemainingStateOfCharge() clear threshold



Lifetimes www.ti.com

11.6.6 Max Error

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
SBS Configuration	Max Error	Time Cycle Equivalent	U1	0	255	12	2h	After a valid QMAX update, each passed time period of Time Cycle Equivalent increments of MaxError() by Cycle Delta. Time Cycle Equivalent is provided for packs that may not get frequent QMAX updates such as stand-by batteries. Time Cycle Equivalent increments Max Error by 0.05% for every Time Cycle Equivalent time period following the last QMAX update.
SBS Configuration	Max Error	Cycle Delta	U1	0	255	5	0.01%	Each increment of CycleCount() after valid QMAX update will increment of MaxError() by Cycle Delta

11.7 Lifetimes

11.7.1 Voltage

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Lifetimes	Voltage	Max Voltage Cell 0	U1	0	255	0	20 mV	Maximum reported cell voltage 0
Lifetimes	Voltage	Max Voltage Cell 1	U1	0	255	0	20 mV	Maximum reported cell voltage 1
Lifetimes	Voltage	Max Voltage Cell 2	U1	0	255	0	20 mV	Maximum reported cell voltage 2
Lifetimes	Voltage	Max Voltage Cell 3	U1	0	255	0	20 mV	Maximum reported cell voltage 3
Lifetimes	Voltage	Min Voltage Cell 0	U1	0	255	255	20 mV	Minimum reported cell voltage 0
Lifetimes	Voltage	Min Voltage Cell 1	U1	0	255	255	20 mV	Minimum reported cell voltage 1
Lifetimes	Voltage	Min Voltage Cell 2	U1	0	255	255	20 mV	Minimum reported cell voltage 2
Lifetimes	Voltage	Min Voltage Cell 3	U1	0	255	255	20 mV	Minimum reported cell voltage 3
Lifetimes	Voltage	Max Delta Cell Voltage	U1	0	255	0	20 mV	Maximum reported delta between cell voltages 0 to 3

11.7.2 Current

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Lifetimes	Current	Max Chg Current	U1	0	255	0	200 mA	Maximum reported Current() in charge direction
Lifetimes	Current	Max DSG Current	U1	0	255	0	200 mA	Maximum reported <i>Current()</i> in discharge direction
Lifetimes	Current	Max Avg DSG Current	U1	0	255	0	200 mA	Maximum reported AverageCurrent() in discharge direction
Lifetimes	Current	Max Avg DSG Power	U1	0	255	0	W	Maximum reported Power in discharge direction

11.7.3 Safety Events

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Lifetimes	Safety Events	No of COV Events	U1	0	255	0	8 events	Total number of SafetyStatus()[COV] events
Lifetimes	Safety Events	Last COV Event	U1	0	255	0	4 cycles	Last SafetyStatus()[COV] event in CycleCount() cycles
Lifetimes	Safety Events	No of CUV Events	U1	0	255	0	8 events	Total number of SafetyStatus()[CUV] events
Lifetimes	Safety Events	Last CUV Event	U1	0	255	0	4 cycles	Last SafetyStatus()[CUV] event in CycleCount() cycles
Lifetimes	Safety Events	No of OCD1 Events	U1	0	255	0	8 events	Total number of SafetyStatus()[OCD1] events
Lifetimes	Safety Events	Last OCD1 Event	U1	0	255	0	4 cycles	Last SafetyStatus()[OCD1] event in CycleCount() cycles
Lifetimes	Safety Events	No of OCD2 Events	U1	0	255	0	8 events	Total number of SafetyStatus()[OCD2] events



www.ti.com Lifetimes

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Lifetimes	Safety Events	Last OCD2 Event	U1	0	255	0	4 cycles	Last SafetyStatus()[OCD2] event in CycleCount() cycles
Lifetimes	Safety Events	No of OCC1 Events	U1	0	255	0	8 events	Total number of SafetyStatus()[OCC1] events
Lifetimes	Safety Events	Last OCC1 Event	U1	0	255	0	4 cycles	Last SafetyStatus()[OCC1] event in CycleCount() cycles
Lifetimes	Safety Events	No of OCC2 Events	U1	0	255	0	8 events	Total number of SafetyStatus()[OCC2] events
Lifetimes	Safety Events	Last OCC2 Event	U1	0	255	0	4 cycles	Last SafetyStatus()[OCC2] event in CycleCount() cycles
Lifetimes	Safety Events	No of OLD Events	U1	0	255	0	8 events	Total number of SafetyStatus()[OLD] events
Lifetimes	Safety Events	Last OLD Event	U1	0	255	0	4 cycles	Last SafetyStatus()[OLD] event in CycleCount() cycles
Lifetimes	Safety Events	No of SCD Events	U1	0	255	0	8 events	Total number of SafetyStatus()[SCD] events
Lifetimes	Safety Events	Last SCD Event	U1	0	255	0	4 cycles	Last SafetyStatus()[SCD] event in CycleCount()cycles
Lifetimes	Safety Events	No of SCC Events	U1	0	255	0	8 events	Total number of SafetyStatus()[SCC] events
Lifetimes	Safety Events	Last SCC Event	U1	0	255	0	4 cycles	Last SafetyStatus()[SCC] event in CycleCount() cycles
Lifetimes	Safety Events	No of OTC Events	U1	0	255	0	8 events	Total number of SafetyStatus()[OTC] events
Lifetimes	Safety Events	Last OTC Event	U1	0	255	0	4 cycles	Last SafetyStatus()[OTC] event in CycleCount() cycles
Lifetimes	Safety Events	No of OTD Events	U1	0	255	0	8 events	Total number of SafetyStatus()[OTD] events
Lifetimes	Safety Events	Last OTD Event	U1	0	255	0	4 cycles	Last SafetyStatus()[OTD] event in CycleCount() cycles
Lifetimes	Safety Events	No of OTF Events	U1	0	255	0	8 events	Total number of SafetyStatus()[OTF] events
Lifetimes	Safety Events	Last OTF Event	U1	0	255	0	4 cycles	Last SafetyStatus()[OTF] event in CycleCount() cycles

11.7.4 Charging Events

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Lifetimes	Safety Events	No of Valid Charge Terminations	U1	0	255	0	8 events	Total number of valid charge termination events
Lifetimes	Safety Events	Last Valid Charge Termination	U1	0	255	0	4 cycles	Last valid charge termination in CycleCount() cycles

11.7.5 Gauging Events

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Lifetimes	Gauging Events	No of QMAX Updates	U1	0	255	0	8 events	Total number of GaugingStatus()[QMAX] toggles
Lifetimes	Gauging Events	Last QMAX Update	U1	0	255	0	4 cycles	The CycleCount() cycles made at the last event of GaugingStatus()[QMAX] update
Lifetimes	Gauging Events	No of RA Updates	U1	0	255	0	8 events	Total number of GaugingStatus()[RX] toggles
Lifetimes	Gauging Events	Last RA Update	U1	0	255	0	4 cycles	Last GaugingStatus()[RX] toggle in CycleCount() cycles
Lifetimes	Gauging Events	No of RA Disable	U1	0	255	0	8 events	Total number of GaugingStatus()[RU] = 0 events
Lifetimes	Gauging Events	Last RA Disable	U1	0	255	0	4 cycles	The CycleCount() cycles of the last update event of GaugingStatus()[RU] = 1



Settings www.ti.com

11.7.6 Power Events

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Lifetimes	Power Events	No of Shutdowns	U1	0	255	0	events	Total number of Shutdown events

11.7.7 Cell Balancing

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Lifetimes	Cell Balancing	CB Time Cell 0	U1	0	255	0	2h	Total performed cell balancing bypass time cell 0
Lifetimes	Cell Balancing	CB Time Cell	U1	0	255	0	2h	Total performed cell balancing bypass time cell 1
Lifetimes	Cell Balancing	CB Time Cell 2	U1	0	255	0	2h	Total performed cell balancing bypass time cell 2
Lifetimes	Cell Balancing	CB Time Cell	U1	0	255	0	2h	Total performed cell balancing bypass time cell 3

11.7.8 Temperature

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Lifetimes	Temperature	Max Temp Cell	I1	-128	127	-128	°C	Maximum reported cell temperature
Lifetimes	Temperature	Min Temp Cell	I1	-128	127	127	°C	Minimum reported cell temperature
Lifetimes	Temperature	Max Delta Temp Cell	I1	-128	127	0	°C	Maximum reported temperature delta for TSx inputs configured as cell temperature
Lifetimes	Temperature	Max Temp Int Sensor	I1	-128	127	-128	°C	Maximum reported internal temperature sensor temperature
Lifetimes	Temperature	Min Temp Int Sensor	I1	-128	127	127	°C	Minimum reported internal temperature sensor temperature
Lifetimes	Temperature	Max Temp FET	I1	-128	127	-128	°C	Maximum reported FET temperature

11.7.9 Time

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Lifetimes	Time	Total firmware Runtime	U2	0	65535	0	2 h	Total firmware runtime between resets
Lifetimes	Time	Time Spent in UT	U2	0	65535	0	2 h	Total firmware runtime spent below T1
Lifetimes	Time	Time Spent in LT	U2	0	65535	0	2 h	Total firmware runtime spent between T1 and T2
Lifetimes	Time	Time Spent in STL	U2	0	65535	0	2 h	Total firmware runtime spent between T2 and T5
Lifetimes	Time	Time Spent in RT	U2	0	65535	0	2 h	Total firmware runtime spent between T5 and T6
Lifetimes	Time	Time Spent in STH	U2	0	65535	0	2h	Total firmware runtime spent between T6 and T3
Lifetimes	Time	Time Spent in HT	U2	0	65535	0	2 h	Total firmware runtime spent between T3 and T4
Lifetimes	Time	Time Spent in OT	U2	0	65535	0	2 h	Total firmware runtime spent above T6

11.8 Settings

11.8.1 Fuse



www.ti.com Settings

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Fuse	Permanent Fail Fuse 0–15	H2	0x0000	0xFFFF	0	Bit 0: CUV—Cell undervoltage fuse activation 0 = Disabled 1 = Enabled (default) Bit 1: COV—Cell overvoltage fuse activation 0 = Disabled 1 = Enabled (default) Bit 2: CUDEP —Copper Deposition fuse activation 0 = Disabled 1 = Enabled (default) Bit 3: Reserved Bit 4: PF_OTCE—Overtemperature fuse activation 0 = Disabled 1 = Enabled (default) Bit 5: Reserved Bit 6: OTF—Overtemperature FET fuse activation 0 = Disabled 1 = Enabled (default) Bit 7: QIM—QMAX Imbalance fuse activation 0 = Disabled 1 = Enabled (default) Bit 7: QIM—QMAX Imbalance fuse activation 0 = Disabled 1 = Enabled (default) Bit 8: CB—Cell balancing fuse activation 0 = Disabled 1 = Enabled (default) Bit 9: IMP—Cell impedance fuse activation 0 = Disabled 1 = Enabled (default) Bit 10: CD—Capacity Deterioration fuse activation 0 = Disabled 1 = Enabled (default) Bit 11: VIMR—Voltage imbalance at Rest fuse activation 0 = Disabled 1 = Enabled (default) Bit 11: VIMR—Voltage imbalance at Rest fuse activation 0 = Disabled 1 = Enabled (default) Bit 11: VIMR—Voltage imbalance at Rest fuse activation 0 = Disabled 1 = Enabled (default) Bit 14: Reserved Bit 14: Reserved Bit 15: Reserved
Settings	Fuse	Permanent Fail Fuse 16–32	H2	0x0000	0xFFFF	0	Bit 0: CFETF—Charge FET 0 = Disabled 1 = Enabled (default) Bit 1: DFETF—Discharge FET 0 = Disabled 1 = Enabled (default) Bit 2: THERM—Thermistor 0 = Disabled 1 = Enabled (default) Bit 3: Reserved Bit 4: AFE_PAFE Register 0 = n/a 1 = Enabled (default) Bit 5: AFE_CAFE Communication 0 = Disabled 1 = Enabled (default) Bit 6: 2LVL—FUSE input indicating fuse trigger by external 2nd level protection 0 = Disabled 1 = Enabled (default) Bit 7: Reserved Bit 9: OCECO—Open VCx 0 = n/a 1 = Enabled (default) Bit 10: DFW—DF wear out 0 = n/a 1 = Enabled (default) Bit 11: Reserved Bit 13: Reserved Bit 15: Reserved
Settings	Fuse	Min Fuse Blow Voltage	12	0	32767	8000	Minimum voltage required to attempt fuse blow, pack based, FET failures bypass this requirement to blow the fuse.

11.8.2 Manufacturing



Settings www.ti.com

Class Su	ubclass	Name	Туре	Min	Max	Default	Description
	nufacturing	Manufacturing Status	H2	0x0000	0xFFFF	0x8000	Bit 0: PCHG_EN—PCHG Function, only available with FET = 0 0 = Disabled 1 = Enabled Bit 1: CHG_EN—CHG FET, only available with FET = 0 0 = Disabled 1 = Enabled Bit 2: DSG_ENDSG FET, only available with FET = 0 0 = Disabled 1 = Enabled Bit 3: GAUGE_EN—Gauging 0 = Disabled 1 = Enabled (default) Bit 4: FET_EN—FET action 0 = Disabled 1 = Enabled (default) Bit 5: LF_EN—Lifetime data collection 0 = Disabled 1 = Enabled (default) Bit 6: PF_EN—Permanent Fail 0 = Disabled 1 = Enabled (default) Bit 7: BBR_EN—Black Box Recorder 0 = Disabled 1 = Enabled (default) Bit 8: FUSE_EN—FUSE action 0 = Disabled 1 = Enabled (default) Bit 8: FUSE_EN—FUSE action 0 = Disabled 1 = Enabled (default) Bit 1: Reserved Bit 11: Reserved Bit 11: Reserved Bit 12: Reserved Bit 13: Reserved Bit 14: Reserved Bit 14: Reserved Bit 15: CAL_EN—ADC or CC output on ManufacturerData() 0 = Disabled 1 = Enabled (default)

11.8.3 Protection

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Protection	Enabled Protections 0–15	H2	0x0000	0xFFFF	0xFFFF	Bit 0: CUV—Cell Undervoltage 0 = Disabled 1 = Enabled (default) Bit 1: COV—Cell Overvoltage 0 = Disabled 1 = Enabled (default) Bit 2: OCC1—Overcurrent in Charge 1st Tier 0 = Disabled 1 = Enabled (default) Bit 3: OCC2—Overcurrent in Charge 2nd Tier 0 = Disabled 1 = Enabled (default) Bit 4: OCD1—Overcurrent in Discharge 1st Tier 0 = Disabled 1 = Enabled (default) Bit 5: OCD2—Overcurrent in Discharge 1st Tier 0 = Disabled 1 = Enabled (default) Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Disabled 1 = Enabled (default) Bit 6: AOLD—Overload in Discharge 0 = Disabled 1 = Enabled (default) Bit 7: AOLD1—Overload in Discharge latch 0 = Disabled 1 = Enabled (default) Bit 8: ASCC—Short circuit in charge 0 = Disabled 1 = Enabled (default) Bit 9: ASCCL—Short circuit in charge latch 0 = Disabled 1 = Enabled (default) Bit 10: ASCD—Short circuit in discharge 0 = Disabled 1 = Enabled (default) Bit 11: ASCDL—Short circuit in discharge 0 = Disabled 1 = Enabled (default) Bit 11: ASCDL—Short circuit in discharge 0 = Disabled 1 = Enabled (default) Bit 11: ASCDL—Short circuit in discharge 0 = Disabled 1 = Enabled (default) Bit 11: ASCDL—Short circuit in discharge 0 = Disabled 1 = Enabled (default) Bit 12: OTC—Overtemperature in charge 0 = Disabled 1 = Enabled (default) Bit 13: OTD—Overtemperature in discharge 0 = Disabled 1 = Enabled (default) Bit 13: Reserved Bit 15: Reserved



www.ti.com Settings

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Fuse	Enabled Protections 16–32	H2	0x0000	0xFFFF	0xFFFF	Bit 0: OTF—FET overtemperature 0 = Disabled 1 = Enabled (default) Bit 1: HWDF—SBS Host watchdog timeout 0 = Disabled 1 = Enabled (default) Bit 2: PTO—Precharging timeout 0 = Disabled 1 = Enabled (default) Bit 3: PTOS—Precharging timeout suspend 0 = Disabled 1 = Enabled (default) Bit 4: CTO—Charging timeout 0 = Disabled 1 = Enabled (default) Bit 5: CTOS—Charging timeout 0 = Disabled 1 = Enabled (default) Bit 5: CTOS—Charging timeout suspend 0 = Disabled 1 = Enabled (default) Bit 6: OC—Overcharge 0 = Disabled 1 = Enabled (default) Bit 7: CHGC—ChargingCurrent() higher than requested 0 = Disabled 1 = Enabled (default) Bit 8: CHGV—ChargingVoltage() higher than requested 0 = Disabled 1 = Enabled (default) Bit 9: Reserved Bit 10: Reserved Bit 11: Reserved Bit 15: Reserved Bit 15: Reserved Bit 15: Reserved



Settings www.ti.com

11.8.4 Permanent Failure

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Permanent Failure	Enabled PF 0–15	H2	0x0000	0xFFFF	0xFFFF	Bit 0: CUV—Cell undervoltage 0 = Disabled 1 = Enabled (default) Bit 1: COV—Cell overvoltage 0 = Disabled 1 = Enabled (default) Bit 2: CUDEP—Copper Deposition 0 = Disabled 1 = Enabled (default) Bit 3: Reserved Bit 4: PF_OTCE—Overtemperature 0 = Disabled 1 = Enabled (default) Bit 5: Reserved Bit 6: OTF—Overtemperature FET 0 = Disabled 1 = Enabled (default) Bit 7: QIM—QMAX Imbalance 0 = Disabled 1 = Enabled (default) Bit 8: CB—Cell balancing 0 = Disabled 1 = Enabled (default) Bit 8: CB—Cell balancing 0 = Disabled 1 = Enabled (default) Bit 9: IMP—Cell impedance 0 = Disabled 1 = Enabled (default) Bit 9: IMP—Cell impedance 0 = Disabled 1 = Enabled (default) Bit 11: CD—Capacity Degradation 0 = Disabled 1 = Enabled (default) Bit 11: VIMR—Voltage imbalance at Rest 0 = Disabled 1 = Enabled (default) Bit 12: VIMA—Voltage imbalance at Rest 0 = Disabled 1 = Enabled (default) Bit 12: VIMA—Voltage imbalance at Rest 0 = Disabled 1 = Enabled (default) Bit 13: Reserved Bit 14: Reserved Bit 14: Reserved Bit 15: Reserved Bit 15: Reserved
Settings	Permanent Failure	Enabled PF 16–32	H2	0x0000	0xFFFF	0xFFFF	Bit 0: CFETF—Charge FET 0 = Disabled 1 = Enabled (default) Bit 1: DFET—Discharge FET 0 = Disabled 1 = Enabled (default) Bit 2: THERM—Thermistor 0 = Disabled 1 = Enabled (default) Bit 3: FUSE—Fuse 0 = Disabled 1 = Enabled (default) Bit 4: AFER—AFE Register 0 = n/a 1 = Enabled (default) Bit 5: AFEC—AFE Communication 0 = Disabled 1 = Enabled (default) Bit 5: AFEC—AFE Communication 0 = Disabled 1 = Enabled (default) Bit 6: 2LVL—FUSE input indicating fuse trigger by external 2nd level protection 0 = Disabled 1 = Enabled (default) Bit 7: Reserved Bit 8: Reserved Bit 8: Reserved Bit 9: OCECO—Open VCx 0 = n/a 1 = Enabled (default) Bit 10: DFW—DF wearout 0 = n/a 1 = Enabled (default) Bit 11: Reserved Bit 12: Reserved Bit 13: Reserved Bit 13: Reserved Bit 13: Reserved Bit 14: Reserved Bit 15: Reserved Bit 15: Reserved

11.8.5 Configuration

11.8.5.1 Protection Configuration



www.ti.com Settings

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Configuration	Protection Configuration	H1	0x00	0xFF	0x01	Bit 0: Reserved Bit 1: CUV_RECOV_CHG require charge current to recover CUV and CUVC 0 = disable 1 = enable Bit 2: Reserved Bit 4: Reserved Bit 5: Reserved Bit 5: Reserved Bit 7: Reserved Bit 7: Reserved Bit 7: Reserved

11.8.5.2 Temperature Configuration

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Configuration	Temperature Configuration	H2	0x0000	OxFFFF	0x0087	Bit 0: Internal TS enable—Internal 0 = Disable internal TS (default) 1 = Enable internal TS Sit 1: TS1 enable—TS1 0 = Disable TS1 1 = Enable TS1 (default) Bit 2: TS2 enable—TS2 0 = Disable TS2 1 = Enable TS2 (default) Bit 3: Reserved Bit 4: Reserved Bit 5: Internal TS Mode—Cell temp or FET temp 0 = Cell temp (default) 1 = FET temp Bit 6: TS1 Mode—Cell temp or FET temp 0 = Cell temp (default) 1 = FET temp Bit 7: TS2 Mode—Cell temp or FET temp 0 = Cell temp 0 = Cell temp 1 = FET temp Bit 7: TS2 Mode—Cell temp or FET temp 0 = Cell temp 0 = Cell temp 1 = FET temp (default) Bit 8: Reserved Bit 9: Reserved Bit 10: CTEMP—Cell Temperature protection source 0 = MAX (default) 1 = Average Bit 11: FTEMP—FET Temperature protection source 0 = Max (default) 1 = Average Bit 12: OTFET—Overtemperature FET action 0 = FET action (default) 1 = FET action disabled Bit 13: Reserved Bit 15: Reserved Bit 15: Reserved Bit 15: Reserved Bit 15: Reserved

11.8.5.3 Charging Configuration

Class	Subclass	Name	Type	Min	Max	Default	Description
Settings	Configuration	Charging Configuration	н	0x00	0xFF	0	Bit 1, 0: PCHG1, PCHG0 Precharge method 0, 0 = internal Precharge FET (not a valid option for bq30z554-R1) 0, 1 = CHG FET (default) 1, 0 = GPOD pin 1, 1 = Precharge disabled Bit 2: Reserved Bit 3: CHGSU—FET action in charge suspend mode 0 = FET active (default) 1 = Charging and Precharging disabled, FETs off Bit 4: CHGIN—FET action in charge inhibit mode 0 = FET active (default) 1 = Charging and Precharging disabled, FETs off Bit 5: CHGFET—FET action on terminate charge alarm (TCA) 0 = FET active (default) 1 = Charging and Precharging disabled, FET off Bit 6: CCC—Constant Current Mode Loss Compensation 0 = Disabled (default) 1 = ChargingVoltage() and ChargingCurrent() values are compensated for voltage drop Bit 7: Reserved



Settings www.ti.com

11.8.5.4 System Configuration

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Configuration	System Configuration	H2	0x0000	0xFFFF	0x0032	Bit 1,0: CC1, CC0 Cell Count 0,0 = Reserved 0,1 = 2 cell 1,0 = 3 cell 1,1 = 4 cell (default) Bit 2: NR Use PRES in system detection. 0 = Use PRES, removable mode (default). 1 = Non-removable mode Bit 3: SLEEPCHG—CHG FET enabled during sleep 0 = CHG FET off during sleep (default) 1 = CHG FET remains on during sleep Bit 4: SLEEP—SLEEP mode 0 = Disable SLEEP mode (default) Bit 5: CB—Cell balancing 0 = Disabled cell balancing 1 = Enable cell balancing (default) Bit 6: CBM—Cell balancing (default) 1 = External cell balancing (default) 1 = External cell balancing at rest 0 = Disable 1 = Enable Bit 9: OFFSW—Used for earlier versions of emergency shutdown feature 0 = Disable 1 = Enable Bit 10: MFC—Manual FET Control 0 = Disable Manual FET Control 1 = Enable Manual FET Control

11.8.5.5 Gauging Configuration



www.ti.com Settings

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Configuration	Gauging Configuration	H2	0x00	OxFF	0x1FDA	Bit 0: CCT—Cycle count threshold 0 = use CC % of DesignCapacity() (default) 1 = use CC % of FullChargeCapacity() Bit 1: CSYNC Sync RemainingCapacity() with FullChargeCapacity() at valid charge termination 0 = RemainingCapacity() is not synchronized 1 = RemainingCapacity() is synchronized (default) Bit 2: RSOCL—RelativeStateOfCharge() and RemainingCapacity() behavior at end of charge 0 = actual value shown (default) 1 = held at 99% until valid charge termination. On entering valid charge termination update to 100% Bit 3: Reserved Bit 4: LOCKO—Keep RemainingCapacity() and RelativeStateOfCharge() jumping back during relaxation after 0 and FD are reached during discharge. 0 = Disabled (default) 1 = Enabled Bit 5: SMOOTH—Run RemainingCapacity() through a low-pass filter to smooth out jumps at grid point updates, charge termination, and self-discharge adjustments made in relax mode. Smoothing is bypassed at the end of discharge when EDV is reached. Run FullCapacity() through a low-pass filter to smooth out jumps at charge termination and adjustments made in relax mode. Sample settings and associated low-pass filter to smooth out jumps at charge termination and adjustments made in relax mode. Sample settings and associated low-pass filter me constants are in Table C-1. This smoothing feature uses the following formula updated every 1 second. xfilter (k) = drx/filter (k-1) + (1-q)/xadc k, where: xfilter_(k): the new filtered value xfilter constant As such, some lag may be observed between charge/discharge current and RemainingCapacity() changes. The SMOOTH function introduces some delays in IT simulation. It could mask out the ReservedCapacity setting if the capacity setting value is too small. If ReservedCapacity is desired, the user should consider using lower filter time, or increase the ReservedCapacity setting as compensation. The additional amount to compensate can be calculated as follows: Additional ReservedCap(mAH) = AverageLoadCurrent(mA) x SmoothFilterSetting(sec)/3600 0 = Disabled 1 = Enabled (default) Bit
Settings	Configuration	Gauging Configuration	H2	0x00	0xFF	0x1FDA	Bit 8: LFP_RELAX, LiFePO4 chemistry has a unique slow relaxation near full charge. Detailed, in-house test data suggests that the relaxation after a full charge takes a few days to settle. The slow decaying voltage causes RSOC to continue to drop every 5 hours. Depending on the full charge taper current, the fully settled voltage could be close to or even below FlatVoltMax in some cases. For chemID 4xx (LiFePO4) series, the condition to exit the long relax mode is: the pack had previously charged to full or near full state, and then either a significant long relaxation or a non-trivial discharge has happened, such that when in relaxation, the OCV < FlatVoltMax. With the above, QMAX update is disabled because dod will not be taken as long as it is in LFP_relax mode. By the time the gas gauge exits the LFP_relax mode, the OCV is already in the flat zone. So QMAX update takes an alternative approach: Once full charge occurs (FC bit set), dod0=Dod_at_EOC is automatically assigned and valid for QMAX update; VOK is cleared. The dod error as a result of this action is zero or negligible because in the LiFePO4 table, OCV voltage corresponding to dod=0 is much lower. If LFP_RELAX is set, the firmware automatically enables the feature upon detecting that the chemistry is 4xx series. If clear, the feature upon detecting that the chemistry is 4xx series. If clear, the feature is disabled. Lithium Iron Phosphate Relax 0 = Disabled (default) 1 = Enabled



Settings www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Configuration	Gauging Configuration	H2	0x00	0xFF	0x1FDA	Bit 9: RSOC_CONV, addresses the convergence of RemCap to 0 at low temperatures and very high rates which may not be satisfactory because of the high granularity of resistance grids. If termination voltage is reached in DOD region with 10% grid interval or at the moment where voltage / SOC dependency is flat, error can be large. Fast resistance scaling will apply a scale factor to resistance in RemCap simulations leading up to 0. This scale factor is computed from actively measured resistance during the discharge. This measured resistance is an active number and may not be used for an Ra update. RSOC, fast resistance scaling 0 = Disabled 1 = Enabled (default) Bit 10: FAST_QMAX_LRN, Fast QMAX learning: eliminates previously required relaxation periods, to use enable IT with perfectly relaxed cells ~50% RSOC (37% minimum), discharge to empty, QMAX will be learned when discharge stops. Fast QMAX learning, during discharge when update status is 6. Update status changes to 11 if fast learning is successful. 0 = Disabled 1 = Enabled (default) Bit 11: Reserved Bit 12: RSOC_HOLD, prevents RSOC rise during discharge. RSOC will be held until calculated value falls below actual state. 0 = Disabled (default) 1 = Enabled (default) 1 = Enabled Bit 13: TDELTAV, 0 = Enable use of DF.Delta Voltage learned as maximal difference between instantaneous and average voltage. (default) 1 = Enable calculating DeltaVoltage that corresponds to power spike defined in DF.Min Turbo Power. Bit 14: Reserved Bit 15: Reserved

11.8.5.6 SBS Configuration

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Configuration	SBS Configuration	н1	0x00	0xFF	0x20	Bit 0: BCAST—Enable alert and charging broadcast from device to host 0 = Disabled (default) 1 = Enabled Bit 1: CPE—PEC on charger broadcast 0 = Disabled (default) 1 = Enabled Bit 2: HPE—PEC on host communication 0 = Disabled (default) 1 = Enabled Bit 3: HPE—PEC on host communication 0 = Disabled (default) 1 = Enabled Bit 3: XL Enabled Bit 3: XL Enable 400-kHz com mode 0 = Normal SBS bus speed (default) 1 = 400-kHz bus speed Bit 5,4: BLT1, BLT0—Bus low timeout 0,0 = no SBS bus low timeout 0,1 = 1-s SBS bus low timeout 1,0 = 2-s SBS bus low timeout 1,1 = 3-s SBS bus low timeout Bit 6: SmbErrorReset 0 = Disabled Bit 7: Reserved
		SBS Data Config 16–32	н1	0x00	OxFF	OxFF	Bit 0: FDSETV—Enable FD flag set by cell voltage threshold 0 = Disabled 1 = Enabled (default) Bit 1: FDCLEARV—Enable FD flag clear by cell voltage threshold 0 = Disabled 1 = Enabled (default) Bit 2: FDSETRSOC—Enable FD flag set by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 3: FDCLEARRSOC—Enable FD flag clear by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 4: FCASETV—Enable FC flag set by cell voltage threshold 0 = Disabled 1 = Enabled (default) Bit 5: FCACLEARV—Enable FC flag clear by cell voltage threshold 0 = Disabled 1 = Enabled (default) Bit 6: FCASETRSOC—Enable FC flag set by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 6: FCASETRSOC—Enable FC flag set by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 7: FCACLEARRSOC—Enable FC flag clear by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 7: FCACLEARRSOC—Enable FC flag clear by RSOC threshold 0 = Disabled 1 = Enabled (default)



www.ti.com Power

11.8.5.7 SBS Data Configuration

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	Configuration	SBS Data Config 0–15	H2	0x0000	0xFFFF	0x0CAF	Bit 0: TDASETV—Enable TDA flag set by cell voltage threshold 0 = Disabled 1 = Enabled (default) Bit 1: TDACLEARV—Enable TDA flag clear by cell voltage threshold 0 = Disabled 1 = Enabled (default) Bit 2: TDASETRSOC—Enable TDA flag set by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 3: TDACLEARRSOC—Enable TDA flag clear by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 3: TDACLEARRSOC—Enable TDA flag clear by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 4: TCASETV—Enable TCA flag set by cell voltage threshold 0 = Disabled 1 = Enabled (default) Bit 5: TCACLEARV—Enable TCA flag clear by cell voltage threshold 0 = Disabled 1 = Enabled (default) Bit 6: TCASETRSOC—Enable TCA flag set by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 6: TCACLEARRSOC—Enable TCA flag set by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 7: TCACLEARRSOC—Enable TCA flag clear by RSOC threshold 0 = Disabled 1 = Enabled (default) Bit 8: Reserved Bit 9: Reserved Bit 9: Reserved Bit 11: TCASETVCT—Enable FC flag set on valid charge termination 0 = Disabled 1 = Enabled (default) Bit 11: TCASETVCT—Enable TCA flag set on valid charge termination 0 = Disabled 1 = Enabled (default) Bit 11: TCASETVCT—Enable TCA flag set on valid charge termination 0 = Disabled 1 = Enabled (default) Bit 12: Reserved Bit 14: Reserved Bit 14: Reserved Bit 14: Reserved Bit 15: Reser

11.8.6 AFE

Class	Subclass	Name	Туре	Min	Max	Default	Description
Settings	AFE	AFE State Control	Н1	0x00	0xFF	0	AFE state after device start up Bit 0: Reserved Bit 1: Reserved Bit 2: Reserved Bit 3: Reserved Bit 4: RSNS Divide OLD, SCC, SDC1 and SCD2 voltage thresholds by 2 0 = Disabled (default) 1 = Enabled Bit 5: SCDDx2 Double SCD1 and SCD2 delay thresholds 0 = Disabled (default) 1 = Enabled Bit 6: Reserved Bit 7: Reserved

11.9 Power

11.9.1 Power

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Power	Power	Valid Update Voltage	12	0	32767	7500	mV	Min stack voltage threshold for Flash update, pack based



Gas Gauging www.ti.com

11.9.2 Shutdown

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Power	Shutdown	Shutdown Voltage	12	0	32767	1750	mV	Cell based shutdown voltage trip threshold
Power	Shutdown	Shutdown Time	U2	0	255	10	S	Cell based shutdown voltage trip delay
Power	Shutdown	Charger Present Threshold	12	0	32767	3000	mV	Pack pin charger present detect threshold, pack based

11.9.3 Sleep

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Power	Sleep	Sleep Current	12	0	32767	10	mA	Current() threshold to enter SLEEP mode
Power	Sleep	Voltage Time	U1	0	255	5	S	Voltage sampling period in SLEEP mode
Power	Sleep	Current Time	U1	0	255	20	S	Current sampling period in SLEEP mode
Power	Sleep	Wake	H1	0	FF	0		

11.9.4 Ship

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description	
Power	Ship	Delay	U1	0	255	5	s	Delay before entering SHIP mode	

11.9.5 Power Off

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Power	Power Off	Timeout	U2	0	65535	30	min	Timer before FETs are turned back ON, if no action is taken
Power	Power Off	Debounce	U1	0	255	4	sec/4	Debounce for detection
Power	Power Off	MFC Delay	U1	0	255	60	s	Delay before FETs are turned OFF

11.10 Gas Gauging

11.10.1 Current Thresholds

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Gas Gauging	Current Thresholds	DSG Current Threshold	12	-32768	32767	100	mA	DISCHARGE mode Current() threshold
Gas Gauging	Current Thresholds	Chg Current Threshold	12	-32768	32767	50	mA	CHARGE mode Current() threshold
Gas Gauging	Current Thresholds	Quit Current	12	0	32767	10	mA	Current() threshold to enter rest mode

11.10.2 State



www.ti.com Gas Gauging

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Gas Gauging	State	QMAX Cell 0	12	0	32767	4400	mAh	QMAX Cell 0
Gas Gauging	State	QMAX Cell 1	12	0	32767	4400	mAh	QMAX Cell 1
Gas Gauging	State	QMAX Cell 2	12	0	32767	4400	mAh	QMAX Cell 2
Gas Gauging	State	QMAX Cell 3	12	0	32767	4400	mAh	QMAX Cell 3
Gas Gauging	State	QMAX Pack	12	0	32767	4400	mAh	QMAX of the whole stack
Gas Gauging	State	Update Status	Н1	0x00	0xFF	0		Bit 1:0: Update1, Update0 Update Status 0,0 = Impedance Track gauging and lifetime updating is disabled. 0,1 = Ra table updated 1,0 = QMAX and Ra table have been updated Bit 2: Enable—Impedance Track gauging and lifetime updating enable 0 = Disabled 1 = Enabled Bit 3: is_QMAX_Field_Updated QMAX updated with FC and qualified OCV in charge and discharge 0 = Disabled 1 = Enabled (default) Bit 4: Reserved Bit 5: Reserved Bit 6: Reserved Bit 7: Reserved
Gas Gauging	State	Cell 0 Chg Voltage at EoC	12	0	32767	4200	mV	Cell 0 voltage value at end of charge
Gas Gauging	State	Cell 1 Chg Voltage at EoC	12	0	32767	4200	mV	Cell 1 voltage value at end of charge
Gas Gauging	State	Cell 2 Chg Voltage at EoC	12	0	32767	4200	mV	Cell 2 voltage value at end of charge
Gas Gauging	State	Cell 3 Chg Voltage at EoC	12	0	32767	4200	mV	Cell 3 voltage value at end of charge
Gas Gauging	State	Current at EoC	12	-32768	32767	250	mA	Current at end of charge
Gas Gauging	State	Avg I Last Run	12	-32768	32767	-2000	mA	Average current last discharge cycle
Gas Gauging	State	Avg P Last Run	12	-32768	32767	-3022	10 mW	Average power last discharge cycle
Gas Gauging	State	Delta Voltage	12	-32768	32767	0	mV	Voltage() delta between normal and short load spikes to optimize run time calculation
Gas Gauging	State	Max I Last Run	12	-32768	32767	-2000	mA	Max current last discharge cycle
Gas Gauging	State	Max P Last Run	12	-32768	32767	-3022	10 mW	Max power last discharge cycle

11.10.3 Turbo Configuration

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
Gas Gauging	Turbo Cfg	Min Turbo Power	12	-32768	32767	-1000	cW	Min Turbo Power() threshold
Gas Gauging	Turbo Cfg	Pack Resistance	12	0	32767	30	mΩ	Pack Side Resistance() threshold
Gas Gauging	Turbo Cfg	System Resistance	12	0	32767	0	mΩ	System Side Resistance() threshold
Gas Gauging	Turbo Cfg	Max Current Rate	I1	-127	0	-4	С	Max Current Setting() Threshold
Gas Gauging	Turbo Cfg	High Frequency Resistance	12	0	32767	20	mΩ	High Frequency Resistance() threshold
Gas Gauging	Turbo Cfg	Reserve Energy %	l1	0	100	2	%	Energy remaining until max peak power reaches the value reported by the TURBO_POWER command



IT Config www.ti.com

11.11 IT Config

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Gas Gauging	IT Cfg	Load Select	U1	0	255	7		Defines Load compensation mode used by gauging algorithm:IF Load Mode = 0:0 = Avg I Last Run 1 = Present average discharge current 2 = Current 3 = AverageCurrent 4 = DesignCapacity/5 5 = AtRate (mA) 6 = User-Rate-mA 7 = Max Avg I Last RunIF Load Mode = 1:0 = Avg P Last Run 1 = Present average discharge power 2 = Current x Voltage 3 = AverageCurrent x Average Voltage 4 = DesignEnergy/5 5 = AtRate (10 mW) 6 = User-Rate-mW 7 = Max Avg P Last Run
Gas Gauging	IT Cfg	Load Mode	U1	0	255	0		Defines unit used by gauging algorithm:0 = Constant Current1 = Constant Power
Gas Gauging	IT Cfg	Ra Filter	U2	0	999	500	0.1%	Filter value used in Ra Updates, specifies what percentage or Ra update is from new value (100%—setting) vs. old value (setting). The recommended setting is 80% if RSOC_CONV feature is enabled. Otherwise, the setting should be 50% as default.
Gas Gauging	IT Cfg	Ra Max Delta	U1	0	255	15	% of Design Resistance	Maximum value of allowed Ra change
Gas Gauging	IT Cfg	Design Resistance						Averaged cell resistance at Reference Grid point. Automatically updated when Update Status is set to 0x6 by the gauge. To automatically update again set Update Status to 0x4 or manually set when Update Status is set to 0x6.
Gas Gauging	IT Cfg	Reference Grid	UI	0	15	4		Reference grid point used by Design Resistance. The default setting should be used if RSOC_CONV feature is enabled. Otherwise, grid point 11 should be used to ensure resistance updates fast enough at the grid where discharge termination occurs.
Gas Gauging	IT Cfg	Resistance Parameter Filter	U2	1	65534	65124	_	This is one of the filters used for resistance update. Reducing this filter setting can improve low temperature performance at high rates. The default setting is 41-s time constant. It is recommended to keep this filter within the range of 4 s (i.e., DF setting = 61680) up to the default 41 s (i.e. DF setting = 65142). Examining the Term Voltage Delta setting and Fast Scale Start SOC should be done prior to twisting this parameter when trying to improve the RSOC performance. The following is the formula to convert the DF setting into actual filter time constant: Filter time constant = [0.25/(1 - (DF_Value /65536))] - 0.25.



www.ti.com RA Table

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Gas Gauging	IT Cfg	Term Voltage	l2	0	32767	9000	mV	Min stack voltage to be used for capacity calculation. Also this is the minimal Voltage at system power converter input at which the system still operates. This value is used by a capacity gauging algorithm to converge to 0 Remaining Capacity at this voltage. It is also used for computing TURBO_POWER. It can be overwritten with a SBS command MIN_SYS_V.
Gas Gauging	IT Cfg	Term Voltage Delta	12	0	32767	300	mV	Controls when the RSOC_CONV feature becomes active. The recommended setting is 3.3 –Term Voltage / Number Cells. The default setting is 300 mV, which is assuming a typical 3V termination voltage per cell. If a different termination voltage is used, this parameter should be adjusted accordingly.
Gas Gauging	IT Cfg	User-Rate-mA	12	-32768	32768	0	mA	Discharge rate used for capacity calculation selected by Load Select
Gas Gauging	IT Cfg	User-Rate- mW	12	-32768	32768	0	10 mW	Discharge rate used for capacity calculation selected by Load Select
Gas Gauging	IT Cfg	Reserve Cap- mAh	12	0	32768	0	mAh	Capacity reserved available when gauging algorithm reports 0% RemainingStateOfCharge()
Gas Gauging	IT Cfg	Reserve Cap- mWh	l2	0	32768	0	10 mW	Capacity reserved available when gauging algorithm reports 0% RemainingStateOfCharge()
Gas Gauging	IT Cfg	RemCap Smoothing Filter	U1	0	255	250		RemainingCapacity() smoothing filter value. Sample settings and associated low-pass filter time constants are in Table C-1.
Gas Gauging	IT Cfg	Fast Scale Start SOC	U1	0	100	10	%	Controls the start of RSOC_CONV feature based on RSOC %. Rising this setting can improve RSOC drop at the end of discharge. However, the RSOC % chosen for this setting must keep after the sharp drop of the discharge curve (the keen of the discharge curve).

11.12 RA Table

11.12.1 R_a0

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a0	Cell 0 R_A Flag	Н2	0x0000	0xFFFF		High Byte: 0x00: Cell Impedance and QMAX updated 0x05: RELAXATION mode and QMAX update in progress 0x55: DISCHARGE mode and cell updated 0xFF: Cell impedance never updated Low-Byte: 0x00: Table not used and QMAX updated 0x55: Table being used 0xFF: Table never used, no QMAX or cell impedance update.
RA Table	R_a0	Cell 0 R_A 0	12	-32768	32768	2^–10 Ω	Cell 0 resistance at grid point 0
RA Table	R_a0	Cell 0 R_A 1	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 1
RA Table	R_a0	Cell 0 R_A 2	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 2
RA Table	R_a0	Cell 0 R_A 3	12	-32768	32768	2^–10 Ω	Cell 0 resistance at grid point 3
RA Table	R_a0	Cell 0 R_A 4	12	-32768	32768	2^–10 Ω	Cell 0 resistance at grid point 4
RA Table	R_a0	Cell 0 R_A 5	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 5



RA Table www.ti.com

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a0	Cell 0 R_A 6	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 6
RA Table	R_a0	Cell 0 R_A 7	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 7
RA Table	R_a0	Cell 0 R_A 8	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 8
RA Table	R_a0	Cell 0 R_A 9	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 9
RA Table	R_a0	Cell 0 R_A 10	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 10
RA Table	R_a0	Cell 0 R_A 11	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 11
RA Table	R_a0	Cell 0 R_A 12	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 12
RA Table	R_a0	Cell 0 R_A 13	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 13
RA Table	R_a0	Cell 0 R_A 14	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 14

11.12.2 R_a1

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a1	Cell 1 R_A Flag	H2	0x0000	0xFFFF		High-Byte: 0x00: Cell Impedance and QMAX updated 0x05: RELAXATION mode and QMAX update in progress 0x55: DISCHARGE mode and cell updated 0xFF: Cell impedance never updated Low-Byte: 0x00: Table not used and QMAX updated 0x55: Table being used 0xFF: Table never used, no QMAX or cell impedance update
RA Table	R_a1	Cell 1 R_A 0	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 0
RA Table	R_a1	Cell 1 R_A 1	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 1
RA Table	R_a1	Cell 1 R_A 2	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 2
RA Table	R_a1	Cell 1 R_A 3	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 3
RA Table	R_a1	Cell 1 R_A 4	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 4
RA Table	R_a1	Cell 1 R_A 5	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 5
RA Table	R_a1	Cell 1 R_A 6	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 6
RA Table	R_a1	Cell 1 R_A 7	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 7
RA Table	R_a1	Cell 1 R_A 8	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 8
RA Table	R_a1	Cell 1 R_A 9	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 9
RA Table	R_a1	Cell 1 R_A 10	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 10
RA Table	R_a1	Cell 1 R_A 11	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 11
RA Table	R_a1	Cell 1 R_A 12	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 12
RA Table	R_a1	Cell 1 R_A 13	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 13
RA Table	R_a1	Cell 1 R_A 14	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 14

11.12.3 R_a2

Class	Subclass	Name	Type	Min	Max	Unit	Description
RA Table	R_a2	Cell 2 R_A Flag	H2	0x0000	0xFFFF		High-Byte: 0x00: Cell Impedance and QMAX updated 0x05: RELAXATION mode and QMAX update in progress 0x55: DISCHARGE mode and cell updated 0xFF: Cell impedance never updated Low-Byte: 0x00: Table not used and QMAX updated 0x55: Table being used 0xFF: Table never used, no QMAX or cell impedance update



www.ti.com RA Table

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a2	Cell 2 R_A 0	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 0
RA Table	R_a2	Cell 2 R_A 1	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 1
RA Table	R_a2	Cell 2 R_A 2	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 2
RA Table	R_a2	Cell 2 R_A 3	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 3
RA Table	R_a2	Cell 2 R_A 4	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 4
RA Table	R_a2	Cell 2 R_A 5	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 5
RA Table	R_a2	Cell 2 R_A 6	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 6
RA Table	R_a2	Cell 2 R_A 7	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 7
RA Table	R_a2	Cell 2 R_A 8	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 8
RA Table	R_a2	Cell 2 R_A 9	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 9
RA Table	R_a2	Cell 2 R_A 10	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 10
RA Table	R_a2	Cell 2 R_A 11	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 11
RA Table	R_a2	Cell 2 R_A 12	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 12
RA Table	R_a2	Cell 2 R_A 13	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 13
RA Table	R_a2	Cell 2 R_A 14	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 14

11.12.4 R_a3

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a3	Cell 3 R_A Flag	Н2	0x0000	0xFFFF		High-Byte: 0x00: Cell Impedance and QMAX updated 0x05: RELAXATION mode and QMAX update in progress 0x55: DISCHARGE mode and cell updated 0xFF: Cell impedance never updated Low-Byte: 0x00: Table not used and QMAX updated 0x55: Table being used 0xFF: Table never used, no QMAX or cell impedance update
RA Table	R_a3	Cell 3 R_A 0	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 0
RA Table	R_a3	Cell 3 R_A 1	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 1
RA Table	R_a3	Cell 3 R_A 2	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 2
RA Table	R_a3	Cell 3 R_A 3	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 3
RA Table	R_a3	Cell 3 R_A 4	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 4
RA Table	R_a3	Cell 3 R_A 5	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 5
RA Table	R_a3	Cell 3 R_A 6	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 6
RA Table	R_a3	Cell 3 R_A 7	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 7
RA Table	R_a3	Cell 3 R_A 8	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 8
RA Table	R_a3	Cell 3 R_A 9	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 9
RA Table	R_a3	Cell 3 R_A 10	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 10
RA Table	R_a3	Cell 3 R_A 11	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 11
RA Table	R_a3	Cell 3 R_A 12	12	-32768	32768	2^–10 Ω	Cell 3 resistance at grid point 12
RA Table	R_a3	Cell 3 R_A 13	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 13
RA Table	R_a3	Cell 3 R_A 14	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 14

11.12.5 R_a0x



RA Table www.ti.com

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a0x	xCell 0 R_A Flag	H2	0x0000	0xFFFF		High-Byte: 0x00: Cell Impedance and QMAX updated 0x05: RELAXATION mode and QMAX update in progress 0x55: DISCHARGE mode and cell updated 0xFF: Cell impedance never updated Low-Byte: 0x00: Table not used and QMAX updated 0x55: Table being used 0xFF: Table never used, no QMAX or cell impedance update
RA Table	R_a0x	xCell 0 R_A 0	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 0
RA Table	R_a0x	xCell 0 R_A 1	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 1
RA Table	R_a0x	xCell 0 R_A 2	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 2
RA Table	R_a0x	xCell 0 R_A 3	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 3
RA Table	R_a0x	xCell 0 R_A 4	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 4
RA Table	R_a0x	xCell 0 R_A 5	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 5
RA Table	R_a0x	xCell 0 R_A 6	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 6
RA Table	R_a0x	xCell 0 R_A 7	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 7
RA Table	R_a0x	xCell 0 R_A 8	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 8
RA Table	R_a0x	xCell 0 R_A 9	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 9
RA Table	R_a0x	xCell 0 R_A 10	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 10
RA Table	R_a0x	xCell 0 R_A 11	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 11
RA Table	R_a0x	xCell 0 R_A 12	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 12
RA Table	R_a0x	xCell 0 R_A 13	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 13
RA Table	R_a0x	xCell 0 R_A 14	12	-32768	32768	2^-10 Ω	Cell 0 resistance at grid point 14

11.12.6 R_a1x

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a1x	xCell 1 R_A Flag	H2	0x0000	0xFFFF		High-Byte: 0x00: Cell Impedance and QMAX updated 0x05: RELAXATION mode and QMAX update in progress 0x55: DISCHARGE mode and Cell updated 0xFF: Cell impedance never updated Low-Byte: 0x00: Table not used and QMAX updated 0x55: Table being used 0xFF: Table never used, no QMAX or cell impedance update
RA Table	R_a1x	xCell 1 R_A 0	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 0
RA Table	R_a1x	xCell 1 R_A 1	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 1
RA Table	R_a1x	xCell 1 R_A 2	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 2
RA Table	R_a1x	xCell 1 R_A 3	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 3
RA Table	R_a1x	xCell 1 R_A 4	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 4



www.ti.com RA Table

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a1x	xCell 1 R_A 5	12	-32768	32768	2^-10 Ω	Cell 1 resistance at grid point 5
RA Table	R_a1x	xCell 1 R_A 6	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 6
RA Table	R_a1x	xCell 1 R_A 7	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 7
RA Table	R_a1x	xCell 1 R_A 8	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 8
RA Table	R_a1x	xCell 1 R_A 9	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 9
RA Table	R_a1x	xCell 1 R_A 10	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 10
RA Table	R_a1x	xCell 1 R_A 11	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 11
RA Table	R_a1x	xCell 1 R_A 12	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 12
RA Table	R_a1x	xCell 1 R_A 13	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 13
RA Table	R_a1x	xCell 1 R_A 14	12	-32768	32768	2^–10 Ω	Cell 1 resistance at grid point 14

11.12.7 R_a2x

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a2x	xCell 2 R_A Flag	H2	0x0000	0xFFFF		High-Byte: 0x00: Cell Impedance and QMAX updated 0x05: RELAXATION mode and QMAX update in progress 0x55: DISCHARGE mode and cell updated 0xFF: Cell impedance never updated Low-Byte: 0x00: Table not used and QMAX updated 0x55: Table being used 0xFF: Table never used, no QMAX or cell impedance update
RA Table	R_a2x	xCell 2 R_A 0	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 0
RA Table	R_a2x	xCell 2 R_A 1	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 1
RA Table	R_a2x	xCell 2 R_A 2	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 2
RA Table	R_a2x	xCell 2 R_A 3	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 3
RA Table	R_a2x	xCell 2 R_A 4	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 4
RA Table	R_a2x	xCell 2 R_A 5	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 5
RA Table	R_a2x	xCell 2 R_A 6	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 6
RA Table	R_a2x	xCell 2 R_A 7	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 7
RA Table	R_a2x	xCell 2 R_A 8	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 8
RA Table	R_a2x	xCell 2 R_A 9	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 9
RA Table	R_a2x	xCell 2 R_A 10	12	-32768	32768	2^–10 Ω	Cell 2 resistance at grid point 10
RA Table	R_a2x	xCell 2 R_A 11	12	-32768	32768	2^–10 Ω	Cell 2 resistance at grid point 11
RA Table	R_a2x	xCell 2 R_A 12	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 12
RA Table	R_a2x	xCell 2 R_A 13	12	-32768	32768	2^-10 Ω	Cell 2 resistance at grid point 13
RA Table	R_a2x	xCell 2 R_A 14	I2	-32768	32768	2^–10 Ω	Cell 2 resistance at grid point 14



PF Status www.ti.com

11.12.8 R_a3x

Class	Subclass	Name	Туре	Min	Max	Unit	Description
RA Table	R_a3x	xCell 3 R_A Flag	H2	0x0000	0xFFFF		High-Byte: 0x00: Cell Impedance and QMAX updated 0x05: RELAXATION mode and QMAX update in progress 0x55: DISCHARGE mode and cell updated 0xFF: Cell impedance never updated Low-Byte: 0x00: Table not used and QMAX updated 0x55: Table being used 0xFF: Table never used, no QMAX or cell impedance update
RA Table	R_a3x	xCell 3 R_A 0	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 0
RA Table	R_a3x	xCell 3 R_A 1	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 1
RA Table	R_a3x	xCell 3 R_A 2	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 2
RA Table	R_a3x	xCell 3 R_A 3	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 3
RA Table	R_a3x	xCell 3 R_A 4	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 4
RA Table	R_a3x	xCell 3 R_A 5	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 5
RA Table	R_a3x	xCell 3 R_A 6	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 6
RA Table	R_a3x	xCell 3 R_A 7	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 7
RA Table	R_a3x	xCell 3 R_A 8	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 8
RA Table	R_a3x	xCell 3 R_A 9	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 9
RA Table	R_a3x	xCell 3 R_A 10	12	-32768	32768	2^–10 Ω	Cell 3 resistance at grid point 10
RA Table	R_a3x	xCell 3 R_A 11	12	-32768	32768	2^-10 Ω	Cell 3 resistance at grid point 11
RA Table	R_a3x	xCell 3 R_A 12	12	-32768	32768	2^–10 Ω	Cell 3 resistance at grid point 12
RA Table	R_a3x	xCell 3 R_A 13	12	-32768	32768	2^–10 Ω	Cell 3 resistance at grid point 13
RA Table	R_a3x	xCell 3 R_A 14	12	-32768	32768	2^–10 Ω	Cell 3 resistance at grid point 14

11.13 PF Status

11.13.1 Device Status Data



www.ti.com PF Status

Class	Subclass	Name	Type	Min	Max	Default	Description
PF Status	Device Status Data	Safety Alert 0–15	H2	0x0000	0xFFFF	0	SafetyAlert() bit 0 to bit 15 Bit 0: CUV—Cell Undervoltage 0 = Inactive 1 = Detected Bit 1: COV—Cell Overvoltage 0 = Inactive 1 = Detected Bit 2: OCC1—Overcurrent in Charge 1st Tier 0 = Inactive 1 = Detected Bit 3: OCC2—Overcurrent in Charge 2nd Tier 0 = Inactive 1 = Detected Bit 4: OCD1—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 6: OLD—Overload in discharge 0 = Inactive 1 = Detected Bit 7: OLDL—Overload in discharge latch 0 = Inactive 1 = Detected Bit 8: SCC—Short circuit in charge 0 = Inactive 1 = Detected Bit 9: SCCL—Short circuit in charge latch 0 = Inactive 1 = Detected Bit 10: SCD—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: OTC—Overtemperature in charge 0 = Inactive 1 = Detected Bit 12: OTC—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 13: OTD—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 14: CUVC—I*R compensated CUV 0 = Inactive 1 = Detected Bit 15: Reserved



PF Status www.ti.com

Class Subclass	Name	Туре	Min	Max	Default	Description
PF Status Device Status Data	Safety Status 0–15	H2	0x0000	OxFFFF	0	SafetyStatus() bit 0 to bit 15 Bit 0: CUV—Cell Undervoltage 0 = Inactive 1 = Detected Bit 1: COV—Cell Overvoltage 0 = Inactive 1 = Detected Bit 2: OCC1—Overcurrent in Charge 1st Tier 0 = Inactive 1 = Detected Bit 3: OCC2—Overcurrent in Charge 2nd Tier 0 = Inactive 1 = Detected Bit 4: OCD1—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 7: OLDD—Overload in discharge 0 = Inactive 1 = Detected Bit 7: OLDL—Overload in discharge latch 0 = Inactive 1 = Detected Bit 8: SCC—Short circuit in charge 0 = Inactive 1 = Detected Bit 10: SCD—Short circuit in charge latch 0 = Inactive 1 = Detected Bit 10: SCD—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge latch 0 = Inactive 1 = Detected Bit 11: SCD—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: SCDT—Overtemperature in charge 0 = Inactive 1 = Detected Bit 13: OTTO—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 13: OTD—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 15: CSCD—I*R compensated CUV 0 = Inactive 1 = Detected Bit 15: Reserved



www.ti.com PF Status

Class	Subclass	Name	Туре	Min	Max	Default	Description
PF Status	Device Status Data	PF Alert 0–15	H2	0x0000	OxFFFF	0	PFAlert() bit 0 to bit 15 Bit 0: CUV—Cell undervoltage 0 = Inactive 1 = Detected Bit 1: COV—Cell overvoltage 0 = Inactive 1 = Detected Bit 2: CUDEP—Copper Deposition 0 = Inactive 1 = Detected Bit 3: Reserved Bit 4: OTCE—Overtemperature 0 = Inactive 1 = Detected Bit 5: Reserved Bit 6: OTF—Overtemperature FET 0 = Inactive 1 = Detected Bit 7: Reserved Bit 8: CB—Cell balancing 0 = Inactive 1 = Detected Bit 9: Reserved Bit 10: CD—Capacity Deterioration 0 = Inactive 1 = Detected Bit 11: VIMR—Voltage imbalance at Rest 0 = Inactive 1 = Detected Bit 12: VIMA—Voltage imbalance at Rest 0 = Inactive 1 = Detected Bit 12: VIMA—Voltage imbalance at Rest 0 = Inactive 1 = Detected Bit 13: Reserved Bit 14: Reserved Bit 15: Reserved Bit 15: Reserved Bit 15: Reserved
PF Status	Device Status Data	PF Status 0–15	H2	0x0000	0xFFFF	0	PFStatus() bit 0 to bit 15 Bit 0: CUV—Cell undervoltage 0 = Inactive 1 = Active Bit 1: COV—Cell overvoltage 0 = Inactive 1 = Active Bit 2: Reserved Bit 3: Reserved Bit 4: OTCE—Overtemperature 0 = Inactive 1 = Active Bit 5: Reserved Bit 6: OTF—Overtemperature FET 0 = Inactive 1 = Active Bit 7: Reserved Bit 7: Reserved Bit 8: CB—Cell balancing 0 = Inactive 1 = Active Bit 9: Reserved Bit 10: CD—Capacity Deterioration 0 = Inactive 1 = Active Bit 11: VIMR—Voltage imbalance at Rest 0 = Inactive 1 = Active Bit 12: VIMA—Voltage imbalance at Rest 0 = Inactive 1 = Active Bit 12: VIMA—Voltage imbalance at Rest 0 = Inactive 1 = Active Bit 13: Reserved Bit 14: Reserved Bit 15: Reserved Bit 15: Reserved



PF Status www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
PF Status	Device Status Data	Safety Alert 16–31	H2	0x0000	OxFFFF	0	SafetyAlert() bit 16 to bit 31 Bit 16: OTF—FET overtemperature 0 = Inactive 1 = Detected Bit 17: HWD—SBS Host watchdog timeout 0 = Inactive 1 = Detected Bit 18: PTO—Precharging timeout 0 = Inactive 1 = Detected Bit 19: PTOS—Precharging timeout suspend 0 = Inactive 1 = Detected Bit 20: CTO—Charging timeout 0 = Inactive 1 = Detected Bit 21: CTOS—Charging timeout suspend 0 = Inactive 1 = Detected Bit 21: CTOS—Charging timeout suspend 0 = Inactive 1 = Detected Bit 22: OC—Overcharge 0 = Inactive 1 = Detected Bit 23: CHGC—Charging Current higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 26: Reserved Bit 27: Reserved Bit 27: Reserved Bit 27: Reserved Bit 30: Reserved Bit 30: Reserved Bit 30: Reserved Bit 31: Reserved
PF Status	Device Status Data	Safety Status 16–31	H2	0x0000	OxFFFF	0	SafetyStatus() bit 16 to bit 31 Bit 16: OTF—FET overtemperature 0 = Inactive 1 = Detected Bit 17: HWD—SBS Host watchdog timeout 0 = Inactive 1 = Detected Bit 18: PTO—Precharging timeout 0 = Inactive 1 = Detected Bit 19: PTOS—Precharging timeout suspend 0 = Inactive 1 = Detected Bit 20: CTO—Charging timeout 0 = Inactive 1 = Detected Bit 21: CTOS—Charging timeout suspend 0 = Inactive 1 = Detected Bit 21: CTOS—Charging timeout suspend 0 = Inactive 1 = Detected Bit 22: OC—Overcharge 0 = Inactive 1 = Detected Bit 23: CHGC—Charging Current higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 25: Reserved Bit 26: Reserved Bit 27: Reserved Bit 27: Reserved Bit 29: Reserved Bit 30: Reserved Bit 31: Reserved Bit 31: Reserved



www.ti.com PF Status

Class	Subclass	Name	Туре	Min	Max	Default	Description
PF Status	Device Status Data	PF Alert 16–31	H2	0x0000	OxFFFF	0	PFAlert() bit 16 to bit 31 Bit 16: CFETF—Charge FET 0 = Inactive 1 = Detected Bit 17: DFET—Discharge FET 0 = Inactive 1 = Detected Bit 17: DFET—Discharge FET 0 = Inactive 1 = Detected Bit 18: THERM—Thermistor 0 = Inactive 1 = Detected Bit 19: FUSE—Fuse 0 = Inactive 1 = Detected Bit 20: AFER—AFE Register 0 = n/a 1 = Detected Bit 21: AFEC—AFE Communication 0 = Inactive 1 = Detected Bit 22: SCONDLVL—FUSE input indicating fuse trigger by external 2nd level protection 0 = Inactive 1 = Detected Bit 23: PTC—PTC by AFE 0 = Inactive 1 = Detected Bit 24: IFC—Instruction Flash Checksum 0 = n/a 1 = IF checksum failure Bit 25: OCECO—Open VCx 0 = n/a 1 = Detected Bit 26: DFW—Data Flash Wearout 0 = n/a 1 = DF failure Bit 27: Reserved Bit 29: Reserved Bit 30: Reserved Bit 31: Reserved Bit 31: Reserved
PF Status	Device Status Data	PF Status 16–31	H2	0x0000	OxFFFF	0	PFStatus() bit 16 to bit 31 Bit 16: CFETF—Charge FET 0 = Inactive 1 = Active Bit 17: DFET—Discharge FET 0 = Inactive 1 = Active Bit 18: THERM—Thermistor 0 = Inactive 1 = Active Bit 19: FUSE—Fuse 0 = Inactive 1 = Active Bit 20: AFER—AFE Register 0 = n/a 1 = Active Bit 21: AFEC—AFE Communication 0 = Inactive 1 = Active Bit 22: 2LVL—FUSE input indicating fuse trigger by external 2nd level protection 0 = Inactive 1 = Active Bit 23: PTC—PTC by AFE 0 = Inactive 1 = Active Bit 24: IFC—Instruction Flash Checksum 0 = n/a 1 = IF checksum failure Bit 25: OCECO—Open VCx 0 = n/a 1 = Active Bit 27: Reserved Bit 27: Reserved Bit 27: Reserved Bit 31: Reserved



PF Status www.ti.com

Class S	Subclass	Name	Туре	Min	Max	Default	Description
DE Status	Device Status Data	Operation Status 0–15	H2	0x0000	OxFFFF	0	OperationStatus() bit 0 to bit 15 Bit 0: PRES—PRES input state 0 = PRES pin high 1 = PRES pin low detected Bit 1: DSG—DSG FET Status 0 = Disabled 1 = Enabled Bit 2: CHG—CHG FET Status 0 = Disabled 1 = Enabled Bit 3: PCHG—PCHG FET Status 0 = Disabled 1 = Enabled Bit 4: GPOD—GPOD FET Status 0 = Disabled 1 = Enabled Bit 5: FUSE—FUSE input 0 = FUSE pin low 1 = FUSE pin low 1 = FUSE pin high detected Bit 6: CB—Cell Balancing 0 = Inactive 1 = Active Bit 7: LED 0 = Inactive 1 = Active Bit 8:9: SEC0,SEC1—Security Mode 0,1 = Unsealed 1,0 = Full Access 1,1 = Sealed Bit 10: CALCal Raw ADC/CC output active 0 = Inactive 1 = Active Bit 11: SS—SafetyStatus 0 = Inactive 1 = Active Bit 11: SS—SafetyStatus 0 = Inactive 1 = Active Bit 11: NSG—Discharging Disabled 0 = Inactive 1 = Active Bit 13: XDSG—Discharging Disabled 0 = Inactive 1 = Active Bit 14: XCHG—Charging Disabled 0 = Inactive 1 = Active Bit 15: SLEEP—Sleep condition met 0 = Disabled 1 = Enabled



www.ti.com PF Status

Class	Subclass	Name	Type	Min	Max	Default	Description
PF Status	Device Status Data	Operation Status 16–31	H2	0x0000	OxFFFF	0	OperationStatus() bit 16 to bit 31 Bit 16: SDM—Shutdown activated by ManufacturerAccess() 0 = Inactive 1 = Active Bit 17: Reserved Bit 18: AUTH—Authentication ongoing 0 = Inactive 1 = Active Bit 19: AWD—AFE Watchdog failure 0 = Inactive 1 = Active Bit 20: FVS—Fast Voltage Sampling 0 = Inactive 1 = Active Bit 21: CALO—Raw ADC/CC offset output 0 = Inactive 1 = Active Bit 22: SDV—Shutdown activated by voltage 0 = Inactive 1 = Active Bit 23: SLEEPM—SLEEP mode active by ManufacturerAccess() 0 = Inactive 1 = Active Bit 24: INIT—Initialization after full reset, cleared when SBS data calculated and available 0 = Inactive 1 = Active Bit 25: SMBL—CALCC auto offset calibration ongoing after SBS line goes low 0 = Inactive 1 = Active Bit 26: SLEEPQMAX—QMAX update in SLEEP mode 0 = Inactive 1 = Active Bit 27: SLEEPCC—Checking current in SLEEP mode 0 = Inactive 1 = Active Bit 28: XLSBS Fast Mode 0 = Inactive 1 = Active Bit 29: OFF—OFF Switch 0 = Inactive 1 = Active Bit 29: OFF—OFF Switch 0 = Inactive 1 = Active Bit 30: Reserved Bit 30: Reserved Bit 31: Reserved



PF Status www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
PF Status	Device Status Data	Charging Status 0–15	H2	0x0000	OxFFFF	0	ChargingStatus() bit 0 to bit 15 Bit 0: UT—Under Temperature Range 0 = Inactive 1 = Active Bit 1: LT—Low Temperature Range 0 = Inactive 1 = Active Bit 2: ST—Standard Temperature Range 0 = Inactive 1 = Active Bit 3: RT—Recommended Temperature Range 0 = Inactive 1 = Active Bit 4: STH—Standard High Temperature Range 0 = Inactive 1 = Active Bit 5: HT—High Temperature Range 0 = Inactive 1 = Active Bit 6: OT—Over Temperature Range 0 = Inactive 1 = Active Bit 7: PV—Precharge Voltage Range 0 = Inactive 1 = Active Bit 8: LV—Low Voltage Range 0 = Inactive 1 = Active Bit 9: MV—Medium Voltage Range 0 = Inactive 1 = Active Bit 10: HV—High Voltage Range 0 = Inactive 1 = Active Bit 11: IN—Charge Inhibit 0 = Inactive 1 = Active Bit 12: SU—Charge Suspend 0 = Inactive 1 = Active Bit 13: CCR—ChargingVoltage() Rate 0 = Inactive 1 = Active Bit 14: CVR—ChargingCurrent() Rate 0 = Inactive 1 = Active Bit 15: CCC—ChargingCurrent() Compensation 0 = Inactive 1 = Active Bit 15: CCC—ChargingCurrent() Compensation 0 = Inactive 1 = Active Bit 15: CCC—ChargingCurrent() Compensation 0 = Inactive
PF Status	Device Status Data	Charging Status 16–23	H2	0x0000	0xFFFF	0	ChargingStatus() bit 16 to bit 31 Bit 16: VCT—Valid Charge Termination. This flag toggles every time valid charge termination is detected. Bit 17: Reserved Bit 18: MCHG—Maintenance Charge is detected. Bit 19: Reserved Bit 20: Reserved Bit 21: Reserved Bit 22: Reserved Bit 23: Reserved Bit 24: Reserved Bit 24: Reserved



www.ti.com PF Status

Class	Subclass	Name	Туре	Min	Max	Default	Description
PF Status	Device Status Data	Gauging Status	H2	0x0000	0xFFFF	0	GaugingStatus() bit 0 to bit 15 Bit 0: REST—Device at rest 0 = Inactive 1 = Active Bit 1: DSG—Discharge detected 0 = Charging 1 = Discharging Bit 2: RU—Resistance update 0 = Disabled 1 = Enabled Bit 3: VOK—Cell Voltage OK for QMAX update 0 = Inactive 1 = Active Bit 4: QEN—QMAX updates 0 = Disabled 1 = Enabled Bit 5: FD—Fully Discharged detected by gauge algorithm 0 = Disabled 1 = Enabled Bit 6: FC—Fully Charged detected by gauge algorithm 0 = Disabled 1 = Enabled Bit 6: FC—Fully Charged detected by gauge algorithm 0 = Disabled 1 = Enabled 1 = Enabled
	PF Status	Device Status Data	Gaugi ng Status	H2	0x0000	0xFFFF	Bit 7: NSFM—Negative scale factor mode 0 = Disabled 1 = Enabled Bit 8: VDQ—Discharge qualified for learning 0 = Disabled 1 = Enabled Bit 9: QMAX—QMAX updated. This flag toggles every time QMAX is updated. Bit 10: RX—Resistance update This flag toggles every time Resistance is updated Bit 11: LDMD—Load Mode 0 = Constant current mode 1 = Constant power mode Bit 12: OCVFR—OCV in flat region 0 = OCV outside flat region 1 = OCV in flat region 1 = OCV in flat region 0 = OCV outside flat region 1 = COV in f

11.13.2 Device Voltage Data

Class	Subclass	Name	Type	Min	Max	Default	Unit	Description
PF Status	Device Voltage Data	Cell Voltage 0	12	0	32767	0	mV	Cell 0 voltage
PF Status	Device Voltage Data	Cell Voltage 1	12	0	32767	0	mV	Cell 1 voltage
PF Status	Device Voltage Data	Cell Voltage 2	12	0	32767	0	mV	Cell 2 voltage
PF Status	Device Voltage Data	Cell Voltage 3	12	0	32767	0	mV	Cell 3 voltage
PF Status	Device Voltage Data	Bat Direct Voltage	12	0	32767	0	mV	Cell stack voltage
PF Status	Device Voltage Data	Pack Voltage	12	0	32767	0	mV	Pack pin voltage



PF Status www.ti.com

11.13.3 Device Current Data

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
PF Status	Device Current Data	Current	12	-32768	32767	0	mV	Current()

11.13.4 Device Temperature Data

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
PF Status	Device Temperature Data	Internal Temperature	12	0	9999	0	0.1°K	Internal temperature sensor temperature
PF Status	Device Temperature Data	External 1 Temperature	12	0	9999	0	0.1°K	External TS1 temperature
PF Status	Device Temperature Data	External 2 Temperature	12	0	9999	0	0.1°K	External TS2 temperature

11.13.5 Device Gauging Data

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
PF Status	Device Gauging Data	Cell 0 DOD0	12	0	32767	0		Cell 0 depth of discharge
PF Status	Device Gauging Data	Cell 1 DOD0	12	0	32767	0		Cell 1 depth of discharge
PF Status	Device Gauging Data	Cell 2 DOD0	12	0	32767	0		Cell 2 depth of discharge
PF Status	Device Gauging Data	Cell 3 DOD0	12	0	32767	0		Cell 3 depth of discharge
PF Status	Device Gauging Data	Passed Charge	12	0	32767	0	mAh	Passed charge since last QMAX update

11.13.6 AFE Regs

Class	Subclass	Name	Type	Min	Max	Default	Description
PF Status	AFE Regs	AFE Status	H1	0x00	0xFF	0	Bit 0: SCD1—SCD1 0 = Inactive 1 = Active Bit 1: SCD2—SCD2 0 = Inactive 1 = Active Bit 2: SCC—SCC 0 = Inactive 1 = Active Bit 3: OCD—SCD1 0 = Inactive 1 = Active Bit 4: WDF—WDF 0 = Inactive 1 = Active Bit 5: Reserved Bit 6: PTC—PTC 0 = Inactive 1 = Active Bit 7: FUSE—FUSE 0 = Inactive 1 = Active



www.ti.com PF Status

Class	Subclass	Name	Туре	Min	Max	Default	Description
PF Status	AFE Regs	AFE State Control	H1	0x00	0xFF	0	Bit 0: Reserved Bit 1: SHUTDOWN—Enables device shutdown when voltage on PACK pins is removed 0 = Disabled 1 = Enabled Bit 2: WDDIS—Enables device watchdog timer 0 = Enabled Bit 3: WDRST—Enables device reset when watchdog timer times out 0 = Disabled Bit 3: WDRST—Enables device reset when watchdog timer times out 0 = Disabled Bit 4: RSNS—Divide OCD, SCC, SDC1 and SCD2 voltage thresholds by 2 0 = Disabled 1 = Enabled Bit 5: SCDDx2—Double SCD1 and SCD2 Delay thresholds 0 = Disabled 1 = Enabled Bit 6: CTM_ENA—Enable customer test mode 0 = Disabled 1 = Enabled Bit 7: FUSE—A part one of FUSE activation sequence 0 = Disabled 1 = Enabled
PF Status	AFE Regs	AFE Control	Н1	0x00	0xFF	0	Bit 0: LTCLR—Clear latch condition 0 = Inactive 1 = Active Bit 1: DSG 0 = Inactive 1 = Active Bit 2: CHG 0 = Inactive 1 = Active Bit 3: PCHG—CHG 0 = Inactive 1 = Active Bit 4: GPOD—CHG 0 = Inactive 1 = Active Bit 5: PMS_CHG 0 = Inactive 1 = Active Bit 5: PMS_CHG 0 = Inactive 1 = Active Bit 7: FUSEB 0 = Inactive 1 = Active Bit 7: FUSEB 0 = Inactive 1 = Active Bit 7: FUSEB 0 = Inactive 1 = Active
PF Status	AFE Regs	AFE Output Status	H1	0x00	OxFF	0	Bit 0: Reserved Bit 1: DSG 0 = Inactive 1 = Active Bit 2: CHG 0 = Inactive 1 = Active Bit 3: PCHG—CHG 0 = Inactive 1 = Active Bit 4: GPOD—CHG 0 = Inactive 1 = Active Bit 5: PMS_CHG 0 = Inactive 1 = Active Bit 6: CTM 0 = Inactive 1 = Active Bit 6: CTM 0 = Inactive 1 = Active Bit 7: PMS 0 = Inactive 1 = Active Bit 7: PMS 0 = Inactive 1 = Active



PF Status www.ti.com

แนง							www.ti.com
Class	Subclass	Name	Туре	Min	Max	Default	Description
PF Status	AFE Regs	AFE Function Control	Н1	0×00	0xFF	0	Bit 0: VMEN 0 = Inactive 1 = Active Bit 1: PACK 0 = Inactive 1 = Active Bit 2: BATDSG 0 = Inactive 1 = Active Bit 3: SC_REC 0 = Inactive 1 = Active Bit 5: 4C REC 0 = Inactive 1 = Active Bit 7: Reserved Bit 7: Reserved
PF Status	AFE Regs	AFE Cell Select	Н1	0×00	0xFF	0	Bit 1:0: CELL1, CELL0 Cell Select Bit 2: CALCAL 0 = Inactive 1 = Active Bit 3: Reserved Bit 4: CB0 0 = Inactive 1 = Active Bit 5: CB1 0 = Inactive 1 = Active Bit 6: CB2 0 = Inactive 1 = Active Bit 6: CB2 0 = Inactive 1 = Active Bit 4: CB3 0 = Inactive 1 = Active
PF Status	AFE Regs	AFE OCDV	Н1	0×00	0xFF	0	Bit 3:0: Overload Trip Threshold between SRP and SRN 0x00 to 0x0F = 0.050 V to 0.200 V in 10 mV steps when RSNS = 00x00 to 0x0F = 0.025 V to 0.100 V in 5 mV steps when RSNS = 10x00 = 0.050 V or 0.025 V 0x01 = 0.060 V or 0.030 V 0x02 = 0.070 V or 0.035 V 0x03 = 0.080 V or 0.040 V 0x04 = 0.090 V or 0.045 V 0x05 = 0.100 V or 0.050 V 0x06 = 0.110 V or 0.055 V 0x07 = 0.120 V or 0.065 V 0x07 = 0.120 V or 0.065 V 0x08 = 0.130 V or 0.055 V 0x08 = 0.130 V or 0.055 V 0x08 = 0.130 V or 0.055 V 0x09 = 0.140 V or 0.075 V 0x08 = 0.150 V or 0.075 V 0x08 = 0.150 V or 0.080 V 0x0C = 0.170 V or 0.085 V 0x0C = 0.180 V or 0.085 V 0x0C = 0.180 V or 0.095 V 0x0E = 0.180 V or 0.095 V 0x0F = 0.200 V or 0.100 V
PF Status	AFE Regs	AFE OCDT	Н1	0x00	0xFF	0	Bit 3:0: Overload Trip Delay 0x00 to 0x0F = 1 ms to 31 ms in 2-ms steps 0x00 = 1 ms 0x01 = 3 ms 0x02 = 5 ms 0x03 = 7 ms 0x04 = 9 ms 0x05 = 11 ms 0x06 = 13 ms 0x07 = 15 ms 0x08 = 17 ms 0x08 = 17 ms 0x09 = 19 ms 0x0A = 21 ms 0x0A = 21 ms 0x0C = 25 ms 0x0C = 25 ms 0x0C = 27 ms 0x0C = 29 ms



www.ti.com PF Status

Class	Subclass	Name	Туре	Min	Max	Default	Description
PF Status	AFE Regs	AFE SCC	H1	0x00	0xFF	0	Bit 2:0: Short Circuit in Charge Threshold between SRP and SRN 0x00 to 0x04 = -0.100 V to -0.300 V in 50 mV steps when RSNS = 00x00 to 0x04 = -0.050 V to -0.150 V in 25-mV steps when RSNS = 1 0x00 = -0.100 V or -0.050 V 0x01 = -0.150 V or -0.075 V 0x02 = -0.200 V or -0.100 V 0x03 = -0.250 V or -0.125 V 0x04 = -0.300 V or -0.150 V 0x05 = Reserved 0x06 = Reserved Bit 7:4: Short Circuit in Charge Delay Time 0x00 to 0x0F = 0 μs to 915 μs in 61-μs steps 0x01 = 61 μs 0x02 = 122 μs 0x03 = 183 μs 0x04 = 244 μs 0x05 = 305 μs 0x06 = 366 μs 0x07 = 427 μs 0x08 = 488 μs 0x09 = 549 μs 0x0A = 610 μs 0x0C = 732 μs 0x0C = 732 μs 0x0C = 732 μs 0x0C = 854 μs 0x0F = 915 μs
PF Status	AFE Regs	AFE SCD1	H1	0x00	0xFF	0	Bit 2:0: Short Circuit in Discharge 1 Threshold between SRP and SRN 0x00 to 0x07 = 0.100 V to 0.300 V in 50 mV steps when RSNS = 00x00 to 0x07 = 0.050 V to 0.150 V in 25 mV steps when RSNS = 1 0x00 = 0.150 V or 0.050 V 0x01 = 0.150 V or 0.075 V 0x01 = 0.150 V or 0.075 V 0x02 = 0.200 V or 0.100 V 0x03 = 0.250 V or 0.125 V 0x04 = 0.300 V or 0.150 V 0x05 = 0.350 V or 0.175 V 0x06 = 0.400 V or 0.200 V 0x07 = 0.450 V or 0.225 V Bit 3: Reserved
PF Status	AFE Regs	AFE SCD1	Н1	0×00	0xFF	0	Bit 7:4: Short Circuit in Discharge 1 Delay Time 0x00 to 0x0F = 0 μs to 915 μs in 61-μs steps when SCDDx2 = 00x00 to 0x0F = 0 μs to 1830 μs in 122-μs steps when SCDDx2 = 1 0x00 = 0 μs 0x01 = 61 μs or 122 μs 0x02 = 122 μs or 244 μs 0x03 = 183 μs or 366 μs 0x04 = 244 μs or 488 μs 0x05 = 305 μs or 610 μs 0x06 = 366 μs or 732 μs 0x07 = 427 μs or 854 μs 0x08 = 488 μs or 976 μs 0x09 = 549 μs or 1098 μs 0x0A = 610 μs or 1220 μs 0x0B = 671 μs or 1342 μs 0x0C = 732 μs or 1586 μs 0x0C = 793 μs or 1586 μs 0x0E = 854 μs or 1708 μs 0x0F = 915 μs or 1830 μs



Black Box www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
PF Status	AFE Regs	AFE SCD2	Н1	0x00	0xFF	0	Bit 2:0: Short Circuit in Discharge 2 Threshold between SRP and SRN 0x00 to 0x07 = 0.100 V to 0.300 V in 50-mV steps when RSNS = 00x00 to 0x07 = 0.050 V to 0.150 V in 25-mV steps when RSNS = 10x00 = 0.150 V or 0.050 V 0x01 = 0.150 V or 0.075 V 0x02 = 0.200 V or 0.100 V 0x03 = 0.250 V or 0.125 V 0x04 = 0.300 V or 0.150 V 0x05 = 0.350 V or 0.175 V 0x06 = 0.400 V or 0.225 V Bit 3: Reserved Bit 7:4: Short Circuit in Discharge 2 Delay Time 0x00 to 0x0F = 0 μs to 915 μs in 61-μs steps when SCDDx2 = 00x00 to 0x0F = 0 μs to 1830 μs in 122-μs steps when SCDDx2 = 10x00 = 0 μs 0x01 = 30 μs or 61 μs 0x02 = 61 μs or 122 μs 0x03 = 91 μs or 183 μs 0x04 = 122 μs or 244 μs 0x05 = 152 μs or 305 μs 0x07 = 213 μs or 427 μs 0x08 = 244 μs or 488 μs 0x07 = 213 μs or 610 μs 0x08 = 335 μs or 610 μs 0x08 = 335 μs or 610 μs 0x08 = 335 μs or 671 μs 0x0B = 335 μs or 671 μs 0x0B = 335 μs or 671 μs 0x0B = 426 μs or 854 μs 0x0F = 458 μs or 915 μs

11.14 Black Box

11.14.1 Safety Status



www.ti.com Black Box

Class	Subclass	Name	Type	Min	Max	Default	Description
Black Box	Safety Status	1st Safety Status 0–15	H2	0x0000	0xFFFF	0	Bit 0: CUV—Cell Undervoltage 0 = Inactive 1 = Detected Bit 1: COV—Cell Overvoltage 0 = Inactive 1 = Detected Bit 2: OCC1—Overcurrent in Charge 1st Tier 0 = Inactive 1 = Detected Bit 3: OCC2—Overcurrent in Charge 2nd Tier 0 = Inactive 1 = Detected Bit 4: OCD1—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 6: OLD—Overload in discharge 0 = Inactive 1 = Detected Bit 7: OLDL—Overload in discharge latch 0 = Inactive 1 = Detected Bit 8: SCC—Short circuit in charge 0 = Inactive 1 = Detected Bit 8: SCC—Short circuit in charge 0 = Inactive 1 = Detected
Black Box	Safety Status		H2	0x0000	OxFFFF	0	Bit 9: SCCL—Short circuit in charge latch 0 = Inactive 1 = Detected Bit 10: SCD—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge latch 0 = Inactive 1 = Detected Bit 12: OTC—Overtemperature in charge 0 = Inactive 1 = Detected Bit 13: OTD—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 13: OTD—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 14: CUVC—I*R compensated CUV 0 = Inactive 1 = Detected Bit 15: Reserved



Black Box www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
Black Box	Safety Status	1st Safety Status 16–31	H2	0x0000	0xFFFF	0	Bit 16: OTF—FET overtemperature 0 = Inactive 1 = Detected Bit 17: HWD—SBS Host watchdog timeout 0 = Inactive 1 = Detected Bit 18: PTO—Precharging Timeout 0 = Inactive 1 = Detected Bit 19: PTOS—Precharging Timeout Suspend 0 = Inactive 1 = Detected Bit 20: CTO—Charging Timeout 0 = Inactive 1 = Detected
Black Box	Safety Status		H2	0x0000	0xFFFF	0	Bit 21: CTOS—Charging Timeout Suspend 0 = Inactive 1 = Detected Bit 22: OC—Overcharge 0 = Inactive 1 = Detected Bit 23: CHGC—Charging Current higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 25: Reserved Bit 25: Reserved Bit 27: Reserved Bit 28: Reserved Bit 29: Reserved Bit 30: Reserved Bit 30: Reserved Bit 31: Reserved
Black Box	Safety Status	1st Time to Next Event	U1	0	255	0	Time from 1st event to 2nd event



www.ti.com Black Box

Class	Subclass	Name	Туре	Min	Max	Default	Description
Black Box	Safety Status		H2	0x0000	0xFFFF	0	Bit 0: CUV—Cell Undervoltage 0 = Inactive 1 = Detected Bit 1: COV—Cell Overvoltage 0 = Inactive 1 = Detected Bit 2: OCC1—Overcurrent in Charge 1st Tier 0 = Inactive 1 = Detected Bit 3: OCC2—Overcurrent in Charge 2nd Tier 0 = Inactive 1 = Detected Bit 4: OCD1—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 6: OLD—Overload in Discharge 0 = Inactive 1 = Detected
Black Box	Safety Status	2nd Safety Status 0–15	H2	0x0000	OxFFFF	0	Bit 7: OLDL—Overload in discharge latch 0 = Inactive 1 = Detected Bit 8: SCC—Short circuit in charge 0 = Inactive 1 = Detected Bit 9: SCCL—Short circuit in charge latch 0 = Inactive 1 = Detected Bit 10: SCD—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge latch 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge latch 0 = Inactive 1 = Detected Bit 12: OTC—Overtemperature in charge 0 = Inactive 1 = Detected Bit 13: OTD—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 14: CUVC—I*R compensated CUV 0 = Inactive 1 = Detected Bit 15: Reserved



Black Box www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
Black Box	Safety Status		H2	0x0000	0xFFFF	0	Bit 16: OTF—FET overtemperature 0 = Inactive 1 = Detected Bit 17: HWD—SBS Host watchdog timeout 0 = Inactive 1 = Detected Bit 18: PTO—Precharging timeout 0 = Inactive 1 = Detected Bit 19: PTOS—Precharging timeout suspend 0 = Inactive 1 = Detected Bit 20: CTO—Charging timeout 0 = Inactive 1 = Detected Bit 20: CTO—Charging timeout 0 = Inactive 1 = Detected
Black Box	Safety Status	2nd Safety Status 16–31	H2	0x0000	0xFFFF	0	Bit 21: CTOS—Charging timeout suspend 0 = Inactive 1 = Detected Bit 22: OC—Overcharge 0 = Inactive 1 = Detected Bit 23: CHGC—ChargingCurrent higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 25: Reserved Bit 26: Reserved Bit 27: Reserved Bit 28: Reserved Bit 29: Reserved Bit 30: Reserved Bit 30: Reserved Bit 31: Reserved
Black Box	Safety Status	2nd Time to Next Event	U1	0	255	0	Time from 2nd event to 3rd event



www.ti.com Black Box

Class	Subclass	Name	Type	Min	Max	Default	Description
Black Box	Safety Status	3rd Safety Status 0–15	H2	0x0000	0xFFFF	0	Bit 0: CUV—Cell Undervoltage 0 = Inactive 1 = Detected Bit 1: COV—Cell Overvoltage 0 = Inactive 1 = Detected Bit 2: OCC1—Overcurrent in Charge 1st Tier 0 = Inactive 1 = Detected Bit 3: OCC2—Overcurrent in Charge 2nd Tier 0 = Inactive 1 = Detected Bit 4: OCD1—Overcurrent in Discharge 1st Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 5: OCD2—Overcurrent in Discharge 2nd Tier 0 = Inactive 1 = Detected Bit 6: OLD—Overload in discharge 0 = Inactive 1 = Detected Bit 7: OLDL—Overload in discharge latch 0 = Inactive 1 = Detected
Black Box	Safety Status		H2	0x0000	OxFFFF	0	Bit 8: SCC—Short circuit in charge 0 = Inactive 1 = Detected Bit 9: SCCL—Short circuit in charge latch 0 = Inactive 1 = Detected Bit 10: SCD—Short circuit in discharge 0 = Inactive 1 = Detected Bit 11: SCDL—Short circuit in discharge latch 0 = Inactive 1 = Detected Bit 12: OTC—Overtemperature in charge 0 = Inactive 1 = Detected Bit 13: OTD—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 13: CTD—Overtemperature in discharge 0 = Inactive 1 = Detected Bit 14: CUVC—I*R compensated CUV 0 = Inactive 1 = Detected Bit 15: Reserved



Black Box www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
Black Box	Safety Status		H2	0×0000	0xFFFF	0	SafetyStatus() bit 16 to bit 31 Bit 16: OTF—FET Overtemperature 0 = Inactive 1 = Detected Bit 17: HWDSBS—Host Watchdog Timeout 0 = Inactive 1 = Detected Bit 18: PTO—Precharging Timeout 0 = Inactive 1 = Detected Bit 19: PTOS—Precharging Timeout Suspend 0 = Inactive 1 = Detected Bit 20: CTO—Charging Timeout 0 = Inactive 1 = Detected Bit 20: CTO—Charging Timeout 0 = Inactive 1 = Detected
Black Box	Safety Status	3rd Safety Status 16–31	H2	0x0000	0xFFFF	0	Bit 21: CTOS—Charging Timeout Suspend 0 = Inactive 1 = Detected Bit 22: OC—Overcharge 0 = Inactive 1 = Detected Bit 23: CHGC—Charging Current higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 24: CHGV—Charging Voltage higher than requested 0 = Inactive 1 = Detected Bit 25: Reserved Bit 25: Reserved Bit 26: Reserved Bit 27: Reserved Bit 29: Reserved Bit 30: Reserved Bit 30: Reserved Bit 31: Reserved
Black Box	Safety Status	3rd Time to Next Event	U1	0	255		Time since 3rd event

11.14.2 PF Status



www.ti.com Black Box

Class	Subclass	Name	Туре	Min	Max	Default	Description
Black Box	PF Status	1st PF Status 0–15	H2	0x0000	0xFFFF	0	Bit 0: CUV—Cell Undervoltage 0 = Inactive 1 = Active Bit 1: COV—Cell Overvoltage 0 = Inactive 1 = Active Bit 2: CUDEP—Copper Deposition 0 = Inactive 1 = Active Bit 3: Reserved Bit 4: OTCE—Overtemperature 0 = Inactive 1 = Active Bit 5: Reserved Bit 6: OTF—Overtemperature FET 0 = Inactive 1 = Active Bit 7: Reserved
Black Box	PF Status		H2	0x0000	OxFFFF	0	Bit 8: CB—Cell Balancing 0 = Inactive 1 = Active Bit 9: Reserved Bit 10: CD—Capacity Deterioration 0 = Inactive 1 = Active Bit 11: VIMR—Voltage Imbalance at Rest 0 = Inactive 1 = Active Bit 12: VIMA—Voltage Imbalance at Rest 0 = Inactive Bit 12: VIMA—Voltage Imbalance at Rest 0 = Inactive Bit 13: Reserved Bit 14: Reserved Bit 15: Reserved
Black Box	PF Status	2nd PF Status 16–31	H2	0×0000	0xFFFF	0	PFStatus() bit 0 to bit 15 Bit 16: CFETF—Charge FET 0 = Inactive 1 = Active Bit 17: DFET—Discharge FET 0 = Inactive 1 = Active Bit 18: THERM—Thermistor 0 = Inactive 1 = Active Bit 19: FUSE—Fuse 0 = Inactive 1 = Active Bit 20: AFER—AFE Register 0 = n/a 1 = Active Bit 22: AFEC—AFE Communication 0 = Inactive 1 = Active Bit 22: 2LVL—FUSE input indicating fuse trigger by external 2nd level protection 0 = Inactive 1 = Active Bit 23: PTC—PTC by AFE 0 = Inactive 1 = Active Bit 24: IFC—Instruction Flash Checksum 0 = n/a 1 = IF checksum failure Bit 25: OCECO—Open VCx 0 = n/a 1 = Active Bit 26: DFW—DF Wearout 0 = n/a 1 = Active Bit 27: Reserved Bit 28: Reserved Bit 29: Reserved Bit 30: Reserved Bit 31: Reserved Bit 31: Reserved Bit 31: Reserved Bit 31: Reserved
Black Box	PF Status	1st Time to Next Event	U1	0	255	0	Time from 1st event to 2nd event
		Event					



Black Box www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
Black Box	PF Status	2nd PF Status 0–15	H2	0x0000	OxFFFF	0	PFStatus() bit 0 to bit 15 Bit 0: CUV—Cell Undervoltage 0 = Inactive 1 = Active Bit 1: COV—Cell Overvoltage 0 = Inactive 1 = Active Bit 2: CUDEP—Copper Deposition 0 = Inactive 1 = Active Bit 3: Reserved Bit 4: OTCE—Overtemperature 0 = Inactive 1 = Active Bit 5: Reserved Bit 6: OTF—Overtemperature FET 0 = Inactive 1 = Active Bit 7: QIM—QMAX Imbalance 0 = Inactive 1 = Active Bit 8: CB—Cell Balancing 0 = Inactive 1 = Active Bit 9: IMP—Cell Impedance 0 = Inactive 1 = Active Bit 10: CD—Capacity Deterioration 0 = Inactive 1 = Active Bit 11: VIMR—Voltage Imbalance at Rest 0 = Inactive 1 = Active Bit 11: VIMR—Voltage Imbalance at Rest 0 = Inactive 1 = Active Bit 11: VIMR—Voltage Imbalance at Rest 0 = Inactive 1 = Active Bit 13: Reserved Bit 14: Reserved Bit 15: Reserved
Black Box	PF Status	2nd PF Status 16–32	H2	0x0000	0xFFFF	0	PFStatus() bit 16 to bit 31 Bit 16: CFETF—Charge FET 0 = Inactive 1 = Active Bit 17: DFET—Discharge FET 0 = Inactive 1 = Active Bit 18: THERM—Thermistor 0 = Inactive 1 = Active Bit 19: FUSE—Fuse 0 = Inactive 1 = Active Bit 20: AFER—AFE Register 0 = n/a 1 = Active Bit 21: AFEC—AFE Communication 0 = Inactive 1 = Active Bit 22: 2LVL—FUSE input indicating fuse trigger by external 2nd level protection 0 = Inactive 1 = Active Bit 23:PTC—PTC by AFE 0 = Inactive 1 = Active Bit 24: IFC—Instruction Flash Checksum 0 = n/a 1 = IF checksum failure Bit 25: OCECO—Open VCx 0 = n/a 1 = Active Bit 27: Reserved Bit 27: Reserved Bit 27: Reserved Bit 29: Reserved Bit 30: Reserved Bit 31: Reserved Bit 31: Reserved Bit 31: Reserved Bit 31: Reserved



www.ti.com Black Box

Class	Subclass	Name	Туре	Min	Max	Default	Description
Black Box	PF Status	2nd Time to Next Event	U1	0	255	0	Time from 2nd event to 3rd event
Black Box	PF Status	3rd PF Status 0–15	H2	0x0000	OxFFFF	0	PFStatus() bit 0 to bit 15 Bit 0: CUV—Cell undervoltage 0 = Inactive 1 = Active Bit 1: COV—Cell overvoltage 0 = Inactive 1 = Active Bit 2: CUDEP—Copper Deposition 0 = Inactive 1 = Active Bit 3: Reserved Bit 4: OTCE—Overtemperature 0 = Inactive 1 = Active Bit 5: Reserved Bit 6: OTF—Overtemperature FET 0 = Inactive 1 = Active Bit 7: QIM—QMAX Imbalance 0 = Inactive 1 = Active Bit 7: QIM—QMAX Imbalance 0 = Inactive 1 = Active Bit 8: CB—Cell balancing 0 = Inactive 1 = Active Bit 9: IMP—Cell impedance 0 = Inactive 1 = Active Bit 10: CD—Capacity Deterioration 0 = Inactive 1 = Active Bit 11: VIMR—Voltage imbalance at Rest 0 = Inactive 1 = Active Bit 12: VIMA—Voltage imbalance at Rest 0 = Inactive 1 = Active Bit 13: Reserved Bit 13: Reserved Bit 15: Reserved Bit 15: Reserved



Calibration www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
Black Box	PF Status	3rd PF Status 16–32	H2	0x0000	OxFFFF	0	PFStatus() bit 16 to bit 31 Bit 16: CFETF—Charge FET 0 = Inactive 1 = Active Bit 17: DFET—Discharge FET 0 = Inactive 1 = Active Bit 18: THERM—Thermistor 0 = Inactive 1 = Active Bit 19: FUSE—Fuse 0 = Inactive 1 = Active Bit 20: AFER—AFE Register 0 = n/a 1 = Active Bit 21: AFEC—AFE Communication 0 = Inactive 1 = Active Bit 22: 2LVL—FUSE input indicating fuse trigger by external 2nd level protection 0 = Inactive 1 = Active Bit 23:PTC—PTC by AFE 0 = Inactive 1 = Active Bit 24: IFC—Instruction Flash Checksum 0 = n/a 1 = IF checksum failure Bit 25: OCECO—Open VCx 0 = n/a 1 = Active Bit 27: Reserved Bit 28: Reserved Bit 30: Reserved Bit 30: Reserved Bit 30: Reserved Bit 31: Reserved
Black Box	PF Status	3rd Time to Next Event	U1	0	255	0	Time since 3rd event

11.15 Calibration

11.15.1 Voltage

Class	Subclass	Name	Туре	Min	Max	Default	Description
Calibration	Voltage	Cell Scale 0	12	-32768	32767	20451	VC1-VSS Cell 0 gain
Calibration	Voltage	Cell Scale 1	12	-32768	32767	20468	VC2-VC1 Cell 1 gain
Calibration	Voltage	Cell Scale 2	12	-32768	32767	20520	VC3-VC2 Cell 2 gain
Calibration	Voltage	Cell Scale 3	12	-32768	32767	20517	VC4-VC3 Cell 3 gain
Calibration	Voltage	Pack Gain	12	-32768	32767	44100	PACK-VSS gain
Calibration	Voltage	Battery Gain	12	-32768	32767	44100	VC4-VSS gain

11.15.2 Current

Class	Subclass	Name	Type	Min	Max	Default	Description
Calibration	Current	CC Gain	F4	1.00E-001	4.00E+000	0.9419	Coulomb Counter Gain
Calibration	Current	Capacity Gain	F4	2.98E+004	1.19E+006	280932.625	Capacity Gain



www.ti.com Calibration

11.15.3 Current Offset

Class	Subclass	Name	Туре	Min	Max	Default	Description
Calibration	Current Offset	CC Offset	12	-32768	32767	-7204	Coulomb Counter Offset
Calibration	Current Offset	Coulomb Counter Offset Samples	U2	0	65535	64	Coulomb Counter Offset Samples used for averaging
Calibration	Current Offset	Board Offset	12	-32768	32767	0	PCB board offset

11.15.4 Temperature

Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Calibration	Temperature	Internal Temp Offset	I1	-128	127	0	0.1°C	Internal temperature sensor reading offset
Calibration	Temperature	External 1 Temp Offset	I1	-128	127	0	0.1°C	TS1 temperature sensor reading offset
Calibration	Temperature	External 2 Temp Offset	l1	-128	127	0	0.1°C	TS2 temperature sensor reading offset

11.15.5 Internal Temp Model

Class	Subclass	Name	Туре	Min	Max	Default	Description
Calibration	Internal Temp Model	Int Coeff 1	12	-32768	32768	0	Internal temperature calculation polynomial value 1
Calibration	Internal Temp Model	Int Coeff 2	12	-32768	32768	0	Internal temperature calculation polynomial value 2
Calibration	Internal Temp Model	Int Coeff 3	12	-32768	32768	-11136	Internal temperature calculation polynomial value 3
Calibration	Internal Temp Model	Int Coeff 4	12	-32768	32768	5754	Internal temperature calculation polynomial value 4
Calibration	Internal Temp Model	Int Minimum AD	12	-32768	32768	0	Minimum AD count used for calculation
Calibration	Internal Temp Model	Int Maximum Temp	12	-32768	32768	5754	Maximum Temperature boundary

11.15.6 Cell Temp Model

Class	Subclass	Name	Туре	Min	Max	Default	Description
Calibration	Cell Temp Model	Coefficient a1	12	-32768	32768	-14520	Cell Temperature calculation polynomial a1
Calibration	Cell Temp Model	Coefficient a2	12	-32768	32768	23696	Cell Temperature calculation polynomial a2
Calibration	Cell Temp Model	Coefficient a3	12	-32768	32768	-20298	Cell Temperature calculation polynomial a3
Calibration	Cell Temp Model	Coefficient a4	12	-32768	32768	28073	Cell Temperature calculation polynomial a4
Calibration	Cell Temp Model	Coefficient a5	12	-32768	32768	865	Cell Temperature calculation polynomial a5
Calibration	Cell Temp Model	Coefficient b1	12	-32768	32768	-694	Cell Temperature calculation polynomial b1
Calibration	Cell Temp Model	Coefficient b2	12	-32768	32768	1326	Cell Temperature calculation polynomial b2
Calibration	Cell Temp Model	Coefficient b3	12	-32768	32768	-3880	Cell Temperature calculation polynomial b3
Calibration	Cell Temp Model	Coefficient b4	12	-32768	32768	5127	Cell Temperature calculation polynomial b4
Calibration	Cell Temp Model	Rc0	12	-32768	32768	11703	Resistance at 25°C



Calibration www.ti.com

Class	Subclass	Name	Туре	Min	Max	Default	Description
Calibration	Cell Temp Model	Adc0	12	-32768	32768	11703	ADC reading at 25°C
Calibration	Cell Temp Model	Rpad	12	-32768	32768	0	Pad Resistance
Calibration	Cell Temp Model	Rint	12	-32768	32768	0	Pull up resistor resistance

11.15.7 FET Temp Model

Class	Subclass	Name	Туре	Min	Max	Default	Description
Calibration	FET Temp Model	Coefficient a1	I2	-32768	32768	-14520	FET Temperature calculation polynomial a1
Calibration	FET Temp Model	Coefficient a2	12	-32768	32768	23696	FET Temperature calculation polynomial a2
Calibration	FET Temp Model	Coefficient a3	12	-32768	32768	-20298	FET Temperature calculation polynomial a3
Calibration	FET Temp Model	Coefficient a4	12	-32768	32768	28073	FET Temperature calculation polynomial a4
Calibration	FET Temp Model	Coefficient a5	12	-32768	32768	865	FET Temperature calculation polynomial a5
Calibration	FET Temp Model	Coefficient b1	12	-32768	32768	-694	FET Temperature calculation polynomial b1
Calibration	FET Temp Model	Coefficient b2	12	-32768	32768	1326	FET Temperature calculation polynomial b2
Calibration	FET Temp Model	Coefficient b3	12	-32768	32768	-3880	FET Temperature calculation polynomial b3
Calibration	FET Temp Model	Coefficient b4	I2	-32768	32768	5127	FET Temperature calculation polynomial b4
Calibration	FET Temp Model	Rc0	I2	-32768	32768	11703	Resistance at 25°C
Calibration	FET Temp Model	Adc0	12	-32768	32768	11703	ADC reading at 25°C
Calibration	FET Temp Model	Rpad	12	-32768	32768	0	Pad Resistance
Calibration	FET Temp Model	Rint	12	-32768	32768	0	Pull up resistor resistance

11.15.8 Filter

Class	Subclass	Name	Type	Min	Max	Default	Description
Calibration	Filter	Cell Voltage 1	U1	0	255	145	
Calibration	Filter	Cell Voltage 2	U1	0	255	145	Low pass filter settings for
Calibration	Filter	Cell Voltage 3	U1	0	255	145	averaging, sample setting values
Calibration	Filter	Cell Voltage 4	U1	0	255	145	and associated low-pass filter time constants are in Table C-2.
Calibration	Filter	Pack Voltage Out	U1	0	255	10	Chosen filter settings will have an
Calibration	Filter	Direct Battery Voltage	U1	0	255	10	effect on protection delays. Higher filter values will cause voltages and temperature to take longer to
Calibration	Filter	Summed Battery Voltage	U1	0	255	145	respond to stimulus to reach threshold, for example. A filter
Calibration	Filter	Cell Temperature	U1	0	255	145	value of 50 closely matches the behavior of previous gas gauges.
Calibration	Filter	FET Temperature	U1	0	255	145	

11.15.9 Current Deadband



Class	Subclass	Name	Туре	Min	Max	Default	Unit	Description
Calibration	Current Deadband	Deadband	U1	0	255	3	mA	Deadband to report 0 mA
Calibration	Current Deadband	Coulomb Counter Deadband	U1	0	255	34	μV	Coulomb counter deadband to report 0 charge

11.16 Data Flash Values

Table 11-1. bq30z554-R1 Data Flash Subclass ID and Offset

Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	Threshold	12	0	32767	2800	mV
Protections	257	CUV	2	Delay	U1	0	255	2	s
			3	Recovery	12	0	32767	3000	mV
			0	Threshold	12	0	32767	2900	mV
Protections	262	CUVC	2	Delay	U1	0	255	2	S
			3	Recovery	12	0	32767	3000	mV
			0	Threshold Low Temp	12	0	32767	4250	mV
			2	Threshold Standard Temp	I2	0	32767	4250	mV
			4	Threshold High Temp	I2	0	32767	4250	mV
			6	Threshold Rec Temp	12	0	32767	4250	mV
Protections	267	COV	8	Delay	U1	0	255	2	S
			9	Recovery Low Temp	I2	0	32767	4150	mV
			11	Recovery Standard Temp	I2	0	32767	4150	mV
			13	Recovery High Temp	12	0	32767	4150	mV
		15	Recovery Rec Temp	12	0	32767	4150	mV	
Protections	284	OCC1	0	Threshold	12	-32768	32767	6000	mA
FIOLECTIONS	204	0001	2	Delay	U1	0	255	6	s
Protections	287	OCC2	0	Threshold	12	-32768	32767	8000	mA
1 Totections	201	0002	2	Delay	U1	0	255	3	S
Protections	290	occ	0	Recovery Threshold	12	-32768	32767	-50	mA
			2	Recovery Delay	U1	0	255	5	s
Protections	293	OCD1	0	Threshold	12	-32768	32767	-6000	mA
1 Totootions	230	OODT	2	Delay	U1	0	255	6	S
Protections	296	OCD2	0	Threshold	12	-32768	32767	-8000	mA
FIOLECTIONS	290	OCDZ	2	Delay	U1	0	255	3	s
Protections	299	OCD	0	Recovery Threshold	12	-32768	32767	50	mA
			2	Recovery Delay	U1	0	255	5	s
			0	Threshold	H1	0	Of	09	
			1	Delay	H1	0	Of	Of	
Protections	302	OLD	2	Latch Limit	U1	0	255	0	
1 10100110119	302	OLD	3	Counter Dec Delay	U1	0	255	10	s
			4	Recovery	U1	0	255	5	S
			5	Reset	U1	0	255	15	s



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	Threshold	H1	0	ff	77	
			1	Latch Limit	U1	0	255	0	mA
Protections	308	scc	2	Counter Dec Delay	U1	0	255	10	S
			3	Recovery	U1	0	255	5	s
			4	Reset	U1	0	255	15	s
Protections	313	SCD1	0	Threshold	H1	0	ff	77	_
Protections	314	SCD2	0	Threshold	H1	0	ff	e7	_
			0	Latch Limit	U1	0	255	0	mA
			1	Counter Dec Delay	U1	0	255	10	S
Protections	315	SCD	2	Recovery	U1	0	255	5	S
			3	Reset	U1	0	255	15	S
			0	Threshold	12	-400	1500	550	1°C
Protections	319	OTC	2	Delay	U1	0	255	2	S
			3	Recovery	12	-400	1500	500	1°C
			0	Threshold	12	-400	1500	600	1°C
Protections	324	OTD	2	Delay	U1	0	255	2	s
			3	Recovery	12	-400	1500	550	1°C
			0	Threshold	12	-400	1500	800	1°C
Protections	329	OTF	2	Delay	U1	0	255	2	s
			3	Recovery	12	-400	1500	650	1°C
Protections	334	HWD	0	Delay	U1	0	255	10	s
			0	Charge Threshold	12	-32768	32767	2000	mA
Protections	335	РТО	2	Suspend Threshold	12	-32768	32767	1800	mA
			4	Delay	U2	0	65535	1800	S
			6	Reset	12	0	32767	2	mAh
			0	Charge Threshold	12	-32768	32767	2500	mA
Protections	343	сто	2	Suspend Threshold	12	-32768	32767	2000	mA
			4	Delay	U2	0	65535	54000	s
			6	Reset	12	0	32767	2	mAh
			0	Threshold	12	-32768	32767	300	mAh
Protections	351	ОС	2	Recovery	12	-32768	32767	2	mAh
			4	RSOC Recovery	U1	0	100	90	%
			0	Threshold	12	-32768	32767	500	mV
Protections	356	CHGV	2	Delay	U1	0	255	30	s
			3	Recovery	12	-32768	32767	-500	mV
			0	Threshold	12	-32768	32767	500	mA
Protections	361	CHGC	2	Delay	U1	0	255	2	s
			3	Recovery	12	-32768	32767	100	mA
Damas Tail	200	CLIV/	0	Threshold	12	0	32767	2500	mV
Permanent Fail	366	CUV	2	Delay	U1	0	255	2	s
Dormorra C. "	000	001/	0	Threshold	12	0	32767	4400	mV
Permanent Fail	369	COV	2	Delay	U1	0	255	2	s
Dormonart C-"	070	CLIDED	0	Threshold	12	2500	0	32767	mV
Permanent Fail	372	CUDEP	2	Delay	U1	2	0	255	S
Dormonant Call	275	OTOF	0	Threshold	12	-400	1500	650	1°C
Permanent Fail	375	OTCE	2	Delay	U1	0	255	2	s
Dormonant Call	270	OTF	0	Threshold	12	-400	1500	1000	1°C
Permanent Fail	378	OIF	2	Delay	U1	0	255	2	s



Table 11-1. bq30z554-R1 Data Flash Subclass ID and Offset (continued)

Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	Max Threshold	12	0	32767	120	h
Permanent Fail	384	СВ	2	Delta Threshold	U1	0	255	20	h
			3	Delay	U1	0	255	2	cycles
			0	Check Voltage	12	0	5000	3600	mV
			2	Check Current	12	0	32767	10	mA
Permanent Fail	388	VIMR	4	Delta Threshold	12	0	5000	200	mV
			6	Delta Delay	U1	0	255	2	S
			7	Duration	U2	0	65535	100	S
			0	Check Voltage	12	0	5000	3600	mV
Permanent Fail	397	VIMA	2	Check Current	12	0	32767	10	mA
r omanone r an	001	VIIVII	4	Delta Threshold	12	0	5000	300	mV
			6	Delay	U1	0	255	2	S
Permanent Fail	409	CD	0	Threshold	12	0	32767	4200	mAh
T CHINGHETH T GII	400	05	2	Delay	U1	0	255	2	cycles
Permanent Fail	412	CFET	0	OFF Threshold	12	0	500	5	mA
T emilianent i ali	412	OLLI	2	OFF Delay	U1	0	255	2	s
Permanent Fail	415	DFET	0	OFF Threshold	12	-500	0	- 5	mA
T CHINGHETH T GII	410	DI ET	2	OFF Delay	U1	0	255	2	S
Permanent Fail	418	THERM	4	ADC Delay	U1	0	255	10	S
Permanent Fail	423	FUSE	0	Threshold	12	0	255	5	mA
T CHINGHETH T GII	420	1 002	2	Delay	U1	0	255	2	s
			0	Threshold	U1	0	255	100	_
Permanent Fail	426	AFER	1	Delay Period	U1	0	255	2	s
			2	Compare Period	U1	0	255	5	S
Permanent Fail	429	AFEC	0	Threshold	U1	0	255	100	_
T CHINGHETH T GII	423	711 20	1	Delay Period	U1	0	255	5	S
Permanent Fail	431	2LVL	0	Delay	12	0	255	2	S
Permanent Fail	432	OCECO	0	Threshold	12	0	32767	5000	mV
T Official office a call	102		2	Delay	U1	0	255	2	S
			0	T1 Temp	l1	-128	127	0	°C
			1	T2 Temp	l1	-128	127	12	°C
Advanced		Townsersture	2	T5 Temp	l1	-128	127	20	°C
Charging	109	Temperature Ranges	3	T6 Temp	l1	-128	127	25	°C
Algorithm		· ·	4	T3 Temp	l1	-128	127	30	°C
			5	T4 Temp	I1	-128	127	55	°C
			6	Hysteresis Temp	I1	-128	127	0	°C
			0	Voltage	12	0	32767	3000	mV
Advanced Charging	116	Low Temp	2	Current Low	12	0	32767	132	mA
Algorithm	110	Charging	4	Current Med	12	0	32767	352	mA
			6	Current High	12	0	32767	264	mA
			0	Voltage	12	0	32767	4200	mV
Advanced Charging	124	Standard Temp	2	Current Low	12	0	32767	1980	mA
Algorithm	127	Charging	4	Current Med	12	0	32767	4004	mA
			6	Current High	12	0	32767	2992	mA
			0	Voltage	12	0	32767	4000	mV
Advanced	100	High Temp	2	Current Low	12	0	32767	1012	%C
Charging Algorithm	132	Charging	4	Current Med	12	0	32767	1980	%C
=			6	Current High	12	0	32767	1496	%C



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	Voltage	12	0	32767	4100	mV
Advanced		Rec Temp	2	Current Low	12	0	32767	2508	mA
Charging Algorithm	140	Charging	4	Current Med	12	0	32767	4488	mA
			6	Current High	12	0	32767	3520	mA
Advanced Charging Algorithm	148	Pre-Charging	0	Current	12	0	32767	88	mA
Advanced Charging Algorithm	150	Maintenance Charging	0	Current	12	0	32767	44	mA
			0	Charging Voltage Low	12	0	32767	2500	mV
Advanced	450	Voltage	2	Charging Voltage Med	12	0	32767	3600	mV
Charging Algorithm	152	Range	4	Charging Voltage High	12	0	32767	4000	mV
			6	Charging Voltage Hysteresis	U1	0	255	0	mV
Advanced	450	Termination	0	Charge Term Taper Current	12	0	32767	250	mA
Charging Algorithm	159	Config	4	Charge Term Voltage	12	0	32767	75	mV
			0	Bal Time/mAh Cell 0	U2	0	65535	367	s/mAh
			2	Bal Time/mAh Cell 1–3	U2	0	65535	514	s/mAh
Advanced Charging Algorithm	168	Cell Balancing Config	4	Min Start Balance Delta	U1	0	255	3	mV
, ugonumi			5	Relax Balance Interval	U4	0	4294967295	18000	s
			9	Min RSOC for Balancing	U1	0	100	80	%
Advanced		Charging Rate	0	Current Rate	U1	1	255	1	steps
Charging Algorithm	178	of Change	1	Voltage Rate	U1	1	255	1	steps
Advanced	400	Charge Loss	0	CCC Current Threshold	I2	0	32767	3520	mA
Charging Algorithm	180	Compensation	2	CCC Voltage Threshold	12	0	32767	4200	mV
System Data	450	Manufacturer Data	0	ManufacturerInfo	S33	x	х	abcdefghijklmn opqrstuvwzxy01 2345	_
System Data	483	Integrity	4	Data Flash Checksum	H2	0	ffff	0	_



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units	
			0	Remaining AH	1 ype	0	32767	300	mAh	
				Cap. Alarm		Ů	02707	000	117.01	
			2	Remaining WH Cap. Alarm	12	0	32767	432	cWh	
			4	Remaining Time Alarm	U2	0	65535	10	min	
			6	Initial Battery Mode	H2	0	ffff	81	_	
			8	Design Voltage	12	0	32767	14400	mV	
			10	Specification Information	H2	0	ffff	31	_	
			12	Manufacture Date	U2	0	65535	0	date	
SBS Configuration	489	Data	14	Serial Number	H2	0	ffff	1	_	
Comiguration			16	Cycle Count	U2	0	65535	0	_	
			18	Cycle Count Percentage	U1	0	100	90	%	
			19	Max Error Limit	U1	0	100	100	%	
			20	Design Capacity mAh	12	0	32767	4400	mAh	
			22	Design Capacity cWh	12	0	32767	6336	cWh	
			24	Manufacturer Name	S21	х	х	Texas Instruments	_	
			45	Device Name	S21	х	Х	bq30z554-R1	_	
			66	Device Chemistry	S5	х	Х	LION	_	
			0	Set Voltage Threshold	12	0	5000	3000	mV	
SBS	SBS	FD	FD	2	Clear Voltage Threshold	12	0	5000	3100	mV
Configuration	560			4	Set % RSOC Threshold	U1	0	100	0	%
			5	Clear % RSOC Threshold	U1	0	100	5	%	
			0	Set Voltage Threshold	12	0	5000	4200	mV	
SBS	500	F0	2	Clear Voltage Threshold	12	0	5000	4100	mV	
Configuration	566	FC	4	Set % RSOC Threshold	U1	0	100	100	%	
			5	Clear % RSOC Threshold	U1	0	100	95	%	
			0	Set Voltage Threshold	12	0	5000	3200	mV	
SBS	572	TDA	2	Clear Voltage Threshold	12	0	5000	3300	mV	
Configuration	372	IDA	4	Set % RSOC Threshold	U1	0	100	10	%	
			5	Clear % RSOC Threshold	U1	0	100	15	%	
			0	Set Voltage Threshold	12	0	5000	4200	mV	
SBS	570	TCA	2	Clear Voltage Threshold	12	0	5000	4100	mV	
Configuration		ICA	4	Set % RSOC Threshold	U1	0	100	100	%	
			5	Clear % RSOC Threshold	U1	0	100	95	%	
SBS Configuration	584	Max Error	3	Time Cycle Equivalent	U1	0	255	12	h	
Comiguration			4	Cycle Delta	U1	0	255	5	%	



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Unit	
			0	Max Cell Voltage 0	U1	0	255	0	mV	
			1	Max Cell Voltage 1	U1	0	255	0	mV	
			2	Max Cell Voltage 2	U1	0	255	0	mV	
			3	Max Cell Voltage 3	U1	0	255	0	mV	
Lifetimes	704	Voltage	4	Min Cell Voltage 0	U1	0	255	255	mV	
2		remage	5	Min Cell Voltage 1	U1	0	255	255	m√	
			6	Min Cell Voltage 2	U1	0	255	255	m√	
			7	Min Cell Voltage 3	U1	0	255	255	m۱	
			8	Max Delta Cell Voltage	U1	0	255	0	m√	
			0	Max Charge Current	U1	0	255	0	m <i>A</i>	
1.46.45	740		1	Max Discharge Current	U1	0	255	0	m/	
Lifetimes	713	Current	2	Max Avg DSG Current	U1	0	255	0	m/	
			3	Max Avg DSG Power	U1	0	255	0	W	
			0	No Of COV Events	U1	0	255	0	evei	
			1	Last COV Event	U1	0	255	0	cycl	
			2	No Of CUV Events	U1	0	255	0	evei	
			3	Last CUV Event	U1	0	255	0	cyc	
		4	No Of OCD1 Events	U1	0	255	0	eve		
				5	Last OCD1 Event	U1	0	255	0	сус
			6	No Of OCD2 Events	U1	0	255	0	eve	
			7	Last OCD2 Event	U1	0	255	0	сус	
			8	No Of OCC1 Events	U1	0	255	0	eve	
			9	Last OCC1 Event	U1	0	255	0	сус	
Lifetimes	717	Safety Events	10	No Of OCC2 Events	U1	0	255	0	eve	
		-	11	Last OCC2 Event	U1	0	255	0	cyc	
			12	No Of OLD Events	U1	0	255	0	eve	
			13	Last OLD Event	U1	0	255	0	cyc	
			14	No Of SCD Events	U1	0	255	0	eve	
			15	Last SCD Event	U1	0	255	0	cyc	
			16	No Of SCC Events	U1	0	255	0	eve	
			17	Last SCC Event	U1	0	255	0	сус	
			18	No Of OTC Events	U1	0	255	0	eve	
			19	Last OTC Event	U1	0	255	0	сус	
			20	No Of OTD Events	U1	0	255	0	eve	
			21	Last OTD Event	U1	0	255	0	сус	
			22	No Of OTF Events	U1	0	255	0	eve	
			23	Last OTF Event	U1	0	255	0	сус	
		Charging	0	No Valid Charge Term	U1	0	255	0	eve	
Lifetimes	741	Events	1	Last Valid Charge	U1	0	255	0	cyc	



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	No Of QMAX Updates	U1	0	255	0	events
		Causina	1	Last QMAX Update	U1	0	255	0	cycles
Lifetimes	743	Gauging Events	2	No Of Ra Updates	U1	0	255	0	events
			3	Last Ra Update	U1	0	255	0	cycles
			4	No Of Ra Disable	U1	0	255	0	events
			5	Last Ra Disable	U1	0	255	0	cycles
Lifetimes	749	Power Events	0	No Of Shutdowns	U1	0	255	0	events
			0	Cb Time Cell 0	U1	0	255	0	h
Lifatimaa	750	Call Balancina	1	Cb Time Cell 1	U1	0	255	0	h
Lifetimes	753	Cell Balancing	2	Cb Time Cell 2	U1	0	255	0	h
			3	Cb Time Cell 3	U1	0	255	0	h
			0	Max Temp Cell	I1	-128	127	-128	°C
			1	Min Temp Cell	I1	-128	127	127	°C
			2	Max Delta Cell Temp	I1	-128	127	0	°C
Lifetimes	757	Temperature	3	Max Temp Int Sensor	I1	-128	127	-128	°C
			4	Min Temp Int Sensor	I1	-128	127	127	°C
			5	Max Temp Fet	I1	-128	127	-128	°C
			0	Total Fw Runtime	U2	0	65535	0	h
			2	Time Spent In UT	U2	0	65535	0	h
			4	Time Spent In LT	U2	0	65535	0	h
			6	Time Spent In STL	U2	0	65535	0	h
Lifetimes	763	Time	8	Time Spent In RT	U2	0	65535	0	h
			10	Time Spent In STH	U2	0	65535	0	h
			12	Time Spent In HT	U2	0	65535	0	h
			14	Time Spent In OT	U2	0	65535	0	h
			0	PF Fuse 0-15	H2	0	ffff	0	_
Settings	185	Fuse	2	PF Fuse 16–31	H2	0	ffff	0	_
Coungo	100	1 400	4	Min Blow Fuse Voltage	12	0	65535	8000	mV
Settings	191	Manufacturing	0	Manufacturing Status	H2	0	ffff	8000	_
Sottings	193	Protection	0	Enabled Protections 0–15	H2	0	ffff	ffff	_
Settings	193	FIOLECTION	2	Enabled Protections 16–31	H2	0	ffff	ffff	_
Settings	197	Permanent	0	Enabled PF 0-15	H2	0	ffff	ffff	_
Settings	131	Failure	2	Enabled PF 16-31	H2	0	ffff	ffff	_



Class	Subclass ID	Subclass	Offset	Name	Data	Min. Value	Max. Value	Default Value	Units
Class	Subciass ID	Subciass	Oliset		Туре	Willi. Value	wax. value	Delault Value	Units
			0	Protection Configuration	H1	0	ff	01	_
			1	Temperature Configuration	H2	0	ffff	0087	_
			3	Charging Configuration	H1	0	ff	0	_
Settings	201	Configuration	4	System Configuration	H2	0	1ff	32	_
			6	Gauging Configuration	H2	0	fff	1fda	_
			8	Sbs Configuration	H1	0	ff	20	_
			9	Sbs Data Config. 0–15	H2	0	Offf	0caf	_
			11	Sbs Data Config. 16–23	H1	0	ff	ff	_
Settings	213	AFE	1	AFE State Control	H1	0	ff	0	_
Power	228	Power	0	Valid Update Voltage	12	0	32767	7500	mV
			0	Shutdown Voltage	12	0	32767	1750	mV
Power	230	Shutdown	2	Shutdown Time	U1	0	255	10	s
			3	Charger Present Threshold	12	0	32767	3000	mV
			0	Sleep Current	12	0	32767	10	mA
Power	235	Sleep	7	Voltage Time	U1	0	255	5	s
i owei	200	Оівер	8	Current Time	U1	0	255	20	S
			9	Wake	H1	0	ff	0	_
Power	245	Ship	0	Delay	U1	0	255	5	S
Power	246	Power Off	0	Timeout	U2	0	65535	30	min
1 0 0001	2.10	1 01101 011	2	Debounce	U1	0	255	4	s/4
		Current	0	DSG Current Threshold	12	-32768	32767	100	mA
Gas Gauging	249	Current Thresholds	2	CHG Current Threshold	12	-32768	32767	50	mA
			4	Quit Current	12	0	32767	10	mA
			0	QMAX Cell 0	l2	0	32767	4400	mAh
			2	QMAX Cell 1	12	0	32767	4400	mAh
			4	QMAX Cell 2	12	0	32767	4400	mAh
			6	QMAX Cell 3	12	0	32767	4400	mAh
			8	QMAX Pack	12	0	32767	4400	mAh
			12	Update Status	H1	0	ff	0	_
			13	Cell 0 Chg Voltage at EoC	12	0	32767	4200	mV
			15	Cell 1 Chg Voltage at EoC	12	0	32767	4200	mV
Gas Gauging	832	State	17	Cell 2 Chg Voltage at EoC	12	0	32767	4200	mV
			19	Cell 3 Chg Voltage at EoC	12	0	32767	4200	mV
			21	Current at EoC	12	0	32767	250	mA
			23	Avg I Last Run	12	-32768	32767	-2000	mA
			25	Avg P Last Run	12	-32768	32767	-3022	cW
			27	Delta Voltage	l2	-32768	32767	0	mV
			33	Max Avg I Last Run	12	-32768	32767	-2000	mA
			35	Max Avg P Last Run	12	-32768	32767	-3022	cW



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	Load Select	U1	0	255	7	_
			1	Load Mode	U1	0	255	0	_
			16	Ra Filter	U2	0	999	500	%
			19	Ra Max Delta	U1	0	255	15	%
			21	Design Resistance	12	1	32767	42	mΩ
			23	Reference Grid	U1	0	14	4	_
			24	Resistance Parameter Filter	U2	1	65534	65142	
0 0 :	000	IT Of	64	Term Voltage	12	0	32767	9000	mV
Gas Gauging	869	IT Cfg	66	Term Voltage Delta	12	0	32767	300	mV
			83	User Rate-mA	12	-9000	0	0	mA
			85	User Rate-cW	12	-32768	0	0	cW
			87	Reserve Cap-mAh	12	0	9000	0	mAh
			89	Reserve Cap-cWh	12	0	32000	0	cWh
			95	Remcap Smoothing Filter	U1	0	255	250	
			96	Fast Scale Start SOC	U1	0	100	10	%
			0	Min Turbo Power	12	-32768	0	0	cW
			2	Pack Resistance	12	0	32767	30	mΩ
Can Couging	970	Turbo Cfa	4	System Resistance	12	0	32767	0	mΩ
Gas Gauging	970	Turbo Cfg	6	Max Current Rate	I1	-127	0	-4	C-rate
			7	High Frequency Resistance	12	0	32767	20	mΩ
			9	Reserve Energy %	I1	0	100	2	%
			0	Cell0 R_a flag	H2	0	ffff	ff55	_
			2	Cell0 R_a 0	12	0	32767	182	2^-10 Ω
			4	Cell0 R_a 1	12	0	32767	177	2^-10 Ω
			6	Cell0 R_a 2	12	0	32767	175	2^-10 Ω
			8	Cell0 R_a 3	12	0	32767	167	2^–10 Ω
			10	Cell0 R_a 4	12	0	327672	166	2^-10 Ω
			12	Cell0 R_a 5	12	0	32767	182	2^-10 Ω
Ra Table	1280	R_a0	14	Cell0 R_a 6	12	0	32767	194	2^-10 Ω
iva rabie	1200	1_au	16	Cell0 R_a 7	12	0	32767	203	2^-10 Ω
			18	Cell0 R_a 8	12	0	32767	213	2^-10 Ω
			20	Cell0 R_a 9	12	0	32767	223	2^-10 Ω
			22	Cell0 R_a 10	12	0	32767	233	2^-10 Ω
			24	Cell0 R_a 11	12	0	32767	241	2^-10 Ω
			26	Cell0 R_a 12	12	0	32767	250	2^-10 Ω
			28	Cell0 R_a 13	12	0	32767	254	2^-10 Ω
			30	Cell0 R_a 14	12	0	32767	1500	2^-10 Ω



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	Cell1 R_a flag	H2	0	ffff	ff55	_
			2	Cell1 R_a 0	12	0	32767	163	2^-10 Ω
			4	Cell1 R_a 1	12	0	32767	151	2^-10 Ω
			6	Cell1 R_a 2	12	0	32767	152	2^-10 Ω
			8	Cell1 R_a 3	12	0	32767	143	2^-10 Ω
			10	Cell1 R_a 4	12	0	32767	145	2^-10 Ω
			12	Cell1 R_a 5	I2	0	32767	162	2^-10 Ω
Ra Table	1344	R_a1	14	Cell1 R_a 6	I2	0	32767	178	2^-10 Ω
Na Table	1044	N_a1	16	Cell1 R_a 7	I2	0	32767	188	2^-10 Ω
			18	Cell1 R_a 8	I2	0	32767	200	2^-10 Ω
			20	Cell1 R_a 9	12	0	32767	206	2^-10 Ω
			22	Cell1 R_a 10	I2	0	32767	216	2^-10 Ω
			24	Cell1 R_a 11	12	0	32767	230	2^-10 Ω
			26	Cell1 R_a 12	12	0	32767	240	2^-10 Ω
			28	Cell1 R_a 13	12	0	32767	254	2^-10 Ω
			30	Cell1 R_a 14	I2	0	32767	1500	2^-10 Ω
			0	Cell2 R_a flag	H2	0	ffff	ff55	_
			2	Cell2 R_a 0	I2	0	32767	157	2^-10 Ω
			4	Cell2 R_a 1	12	0	32767	147	2^-10 Ω
			6	Cell2 R_a 2	12	0	32767	146	2^-10 Ω
			8	Cell2 R_a 3	I2	0	32767	138	2^-10 Ω
			10	Cell2 R_a 4	I2	0	32767	139	2^-10 Ω
			12	Cell2 R_a 5	I2	0	32767	156	2^-10 Ω
Ra Table	1408	R_a2	14	Cell2 R_a 6	12	0	32767	172	2^-10 Ω
rta rabio	1 100	rt_uz	16	Cell2 R_a 7	I2	0	32767	184	2^-10 Ω
			18	Cell2 R_a 8	12	0	32767	195	2^-10 Ω
			20	Cell2 R_a 9	I2	0	32767	204	2^-10 Ω
			22	Cell2 R_a 10	12	0	32767	214	2^-10 Ω
			24	Cell2 R_a 11	I2	0	32767	226	2^-10 Ω
			26	Cell2 R_a 12	12	0	32767	240	2^-10 Ω
			28	Cell2 R_a 13	12	0	32767	254	2^-10 Ω
			30	Cell2 R_a 14	12	0	32767	1500	2^–10 Ω
			0	Cell3 R_a flag	H2	0	ffff	ff55	_
			2	Cell3 R_a 0	12	0	32767	68	2^–10 Ω
			4	Cell3 R_a 1	12	0	32767	77	2^–10 Ω
			6	Cell3 R_a 2	12	0	32767	88	2^–10 Ω
			8	Cell3 R_a 3	12	0	32767	106	2^-10 Ω
			10	Cell3 R_a 4	12	0	32767	103	2^–10 Ω
			12	Cell3 R_a 5	I2	0	32767	71	2^-10 Ω
Ra Table	1472	R_a3	14	Cell3 R_a 6	I2	0	32767	84	2^-10 Ω
			16	Cell3 R_a 7	I2	0	32767	117	2^–10 Ω
			18	Cell3 R_a 8	I2	0	32767	112	2^-10 Ω
			20	Cell3 R_a 9	I2	0	32767	132	2^–10 Ω
			22	Cell3 R_a 10	I2	0	32767	121	2^-10 Ω
			24	Cell3 R_a 11	I2	0	32767	90	2^-10 Ω
			26	Cell3 R_a 12	12	0	32767	89	2^–10 Ω
			28	Cell3 R_a 13	I2	0	32767	254	2^-10 Ω
			30	Cell3 R_a 14	12	0	32767	1500	2^-10 Ω



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	xCell0 R_a flag	H2	0	ffff	ffff	_
			2	xCell0 R_a 0	12	0	32767	68	2^-10 Ω
			4	xCell0 R_a 1	12	0	32767	77	2^-10 Ω
			6	xCell0 R_a 2	12	0	32767	88	2^-10 Ω
			8	xCell0 R_a 3	12	0	32767	106	2^-10 Ω
			10	xCell0 R_a 4	I2	0	32767	103	2^-10 Ω
			12	xCell0 R_a 5	I2	0	32767	71	2^-10 Ω
Ra Table	1536	R_a0x	14	xCell0 R_a 6	I2	0	32767	84	2^-10 Ω
rta rabio	1000	N_dox	16	xCell0 R_a 7	I2	0	32767	117	2^–10 Ω
			18	xCell0 R_a 8	I2	0	32767	112	2^–10 Ω
			20	xCell0 R_a 9	12	0	32767	132	2^–10 Ω
			22	xCell0 R_a 10	I2	0	32767	121	2^–10 Ω
			24	xCell0 R_a 11	12	0	32767	90	2^–10 Ω
			26	xCell0 R_a 12	I2	0	32767	89	2^–10 Ω
			28	xCell0 R_a 13	12	0	32767	254	2^–10 Ω
			30	xCell0 R_a 14	I2	0	32767	1500	2^–10 Ω
			0	xCell1 R_a flag	H2	0	ffff	ffff	_
			2	xCell1 R_a 0	I2	0	32767	68	2^–10 Ω
			4	xCell1 R_a 1	12	0	32767	77	2^-10 Ω
			6	xCell1 R_a 2	12	0	32767	88	2^–10 Ω
			8	xCell1 R_a 3	I2	0	32767	106	2^–10 Ω
			10	xCell1 R_a 4	12	0	32767	103	2^–10 Ω
			12	xCell1 R_a 5	12	0	32767	71	2^-10 Ω
Ra Table	1600	R_a1x	14	xCell1 R_a 6	12	0	32767	84	2^–10 Ω
			16	xCell1 R_a 7	12	0	32767	117	2^–10 Ω
			18	xCell1 R_a 8	12	0	32767	112	2^–10 Ω
			20	xCell1 R_a 9	12	0	32767	132	2^–10 Ω
			22	xCell1 R_a 10	12	0	32767	121	2^–10 Ω
			24	xCell1 R_a 11	12	0	32767	90	2^–10 Ω
			26	xCell1 R_a 12	12	0	32767	89	2^–10 Ω
			28	xCell1 R_a 13	12	0	32767	254	2^–10 Ω
			30	xCell1 R_a 14	12	0	32767	1500	2^–10 Ω
			0	xCell2 R_a flag	H2	0	ffff	ffff	_
			2	xCell2 R_a 0	12	0	32767	68	2^–10 Ω
			4	xCell2 R_a 1	I2	0	32767	77	2^–10 Ω
			6	xCell2 R_a 2	12	0	32767	88	2^–10 Ω
			8	xCell2 R_a 3	12	0	32767	106	2^–10 Ω
			10	xCell2 R_a 4	12	0	32767	103	2^–10 Ω
			12	xCell2 R_a 5	12	0	32767	71	2^–10 Ω
Ra Table	1664	R_a2x	14	xCell2 R_a 6	I2	0	32767	84	2^–10 Ω
			16	xCell2 R_a 7	I2	0	32767	117	2^–10 Ω
			18	xCell2 R_a 8	I2	0	32767	112	2^–10 Ω
			20	xCell2 R_a 9	12	0	32767	132	2^–10 Ω
			22	xCell2 R_a 10	I2	0	32767	121	2^–10 Ω
			24	xCell2 R_a 11	I2	0	32767	90	2^–10 Ω
			26	xCell2 R_a 12	12	0	32767	89	2^–10 Ω
			28	xCell2 R_a 13	I2	0	32767	254	2^–10 Ω
			30	xCell2 R_a 14	12	0	32767	1500	2^–10 Ω



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	xCell3 R_a flag	H2	0	ffff	ffff	_
			2	xCell3 R_a 0	12	0	32767	68	2^-10 Ω
			4	xCell3 R_a 1	12	0	32767	77	2^-10 Ω
			6	xCell3 R_a 2	12	0	32767	88	2^-10 Ω
			8	xCell3 R_a 3	12	0	32767	106	2^-10 Ω
			10	xCell3 R_a 4	12	0	32767	103	2^-10 Ω
			12	xCell3 R_a 5	12	0	32767	71	2^-10 Ω
D- T-bl-	4700	D -0	14	xCell3 R_a 6	12	0	32767	84	2^-10 Ω
Ra Table	1728	R_a3x	16	xCell3 R_a 7	12	0	32767	117	2^-10 Ω
			18	xCell3 R_a 8	12	0	32767	112	2^-10 Ω
			20	xCell3 R_a 9	12	0	32767	132	2^-10 Ω
			22	xCell3 R_a 10	12	0	32767	121	2^-10 Ω
			24	xCell3 R_a 11	12	0	32767	90	2^-10 Ω
			26	xCell3 R_a 12	12	0	32767	89	2^-10 Ω
			28	xCell3 R_a 13	12	0	32767	254	2^-10 Ω
			30	xCell3 R_a 14	12	0	32767	1500	2^-10 Ω
			0	Safety Alert 0-15	H2	0	ffff	0	_
			2	Safety Status 0–15	H2	0	ffff	0	_
			6	PF Alert 0-15	H2	0	ffff	0	_
			8	PF Status 0-15	H2	0	ffff	0	_
			12	Safety Alert 16–31	H2	0	ffff	0	_
			14	Safety Status 16–31	H2	0	ffff	0	_
			18	PF Alert 16-31	H2	0	ffff	0	_
PF Status	589	Device Status Data	20	PF Status 16-31	H2	0	ffff	0	_
		Data	24	Operation Status 0–15	H2	0	ffff	0	_
			26	Operation Status 16–31	H2	0	ffff	0	_
			28	Charging Status 0–15	H2	0	ffff	0	_
			30	Charging Status 16–23	H1	0	ffff	0	_
			31	Gauging Status	H2	0	ffff	0	_
			0	Cell Voltage 0	12	-32768	32768	0	mV
			2	Cell Voltage 1	12	-32768	32768	0	mV
		Device	4	Cell Voltage 2	12	-32768	32768	0	mV
PF Status	622	Voltage Data	6	Cell Voltage 3	12	-32768	32768	0	mV
			8	Battery Direct Voltage	12	-32768	32768	0	mV
			10	Pack Voltage	12	-32768	32768	0	mV
PF Status	634	Device Current Data	0	Current	12	-32768	32767	0	mA
		Davidas	0	Internal Temperature	12	-32768	32768	0	°C
PF Status	636	Device Temperature Data	2	External 1 Temperature	12	-32768	32768	0	°C
			4	External 2 Temperature	12	-32768	32768	0	°C
			0	Cell0 Dod0	12	-32768	32767	0	_
		Dovice	2	Cell1 Dod0	12	-32768	32767	0	_
PF Status	642	Device Gauging Data	4	Cell2 Dod0	12	-32768	32767	0	_
			6	Cell3 Dod0	12	-32768	32767	0	_
			8	Passed Charge	12	-32768	32768	0	mAh



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	AFE Status	H1	0	ff	0	_
			1	AFE State Control	H1	0	ff	0	_
			2	AFE Control	H1	0	ff	0	_
			3	AFE Output Status	H1	0	ff	0	
			4	AFE Function Control	H1	0	ff	0	_
PF Status	652	AFE Regs	5	AFE Cell Select	H1	0	ff	0	-
			6	AFE OCDV	H1	0	ff	0	_
			7	AFE OCDT	H1	0	ff	0	_
			8	AFE SCC	H1	0	ff	0	_
			9	AFE SCD1	H1	0	ff	0	_
			10	AFE SCD2	H1	0	ff	0	-
			11	AFE REF TRIM	H1	0	ff	0	-
			0	1st Status Status 0–15	H2	0	ffff	0	_
			2	1st Safety Status 16–31	H2	0	ffff	0	
			4	1st Time to Next Event	U1	0	255	0	s
			5	2nd Safety Status 0–15	H2	0	ffff	0	-
Black Box	664	Safety Status	7	2nd Safety Status 16–31	H2	0	ffff	0	
			9	2nd Time to Next Event	U1	0	255	0	s
			10	3rd Safety Status 0–15	H2	0	ffff	0	_
			12	3rd Safety Status 16–31	H2	0	ffff	0	-
			14	3rd Time to Next Event	U1	0	255	0	S
			0	1st PF Status 0–15	H2	0	ffff	0	_
			2	1st PF Status 16–31	H2	0	ffff	0	_
			4	1st Time to Next Event	U1	0	255	0	s
			5	2nd PF Status 0–15	H2	0	ffff	0	_
Black Box	679	PF Status	7	2nd PF Status 16–31	H2	0	ffff	0	_
			9	2nd Time to Next Event	U1	0	255	0	S
			10	3rd PF Status 0–15	H2	0	ffff	0	_
			12	3rd PF Status 16–31	H2	0	ffff	0	_
			14	3rd Time to Next Event	U1	0	255	0	S
			0	Cell Scale 0	12	-32767	32767	20451	_
			2	Cell Scale 1	I2	-32767	32767	20468	_
Calibration	0	Voltage	4	Cell Scale 2	12	-32767	32767	20520	_
			6	Cell Scale 3	12	-32767	32767	20517	_
			8	Pack Gain	U2	0	65535	44100	
			10	BAT Gain	U2	0	65535	44100	_



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			0	CC Gain	F4	1.00E-01	4.00E+00	0.9419	
Calibration	12	Current	4	Capacity Gain	F4	2.9826E+0 4	1.193046E+ 06	280932.625	-
			0	CC Offset	12	-32767	32767	-7204	
Calibration	20	Current Offset	2	Coulomb Counter Offset Samples	U2	0	65535	64	_
			4	Board Offset	12	-32768	32767	0	
			0	Internal Temp Offset	I1	-128	127	0	°C
Calibration	26	Temperature	1	External1 Temp Offset	l1	-128	127	0	ç
			2	External2 Temp Offset	l1	-128	127	0	ç
			0	Int Coeff 1	12	-32768	32767	0	_
			2	Int Coeff 2	12	-32768	32767	0	
		Internal Temp	4	Int Coeff 3	12	-32768	32767	-11136	I
Calibration	29	Model	6	Int Coeff 4	12	-32768	32767	5754	-
			8	Int Minimum AD	12	-32768	32767	0	
			10	Int Maximum Temp	12	-32768	32767	5754	0.1°K
			0	Coeff a1	12	-32768	32767	-14520	
			2	Coeff a2	12	-32768	32767	23696	_
			4	Coeff a3	12	-32768	32767	-20298	_
			6	Coeff a4	12	-32768	32767	28073	_
			8	Coeff a5	12	-32768	32767	865	_
		Cell	10	Coeff b1	12	-32768	32767	-694	_
Calibration	41	Temperature	12	Coeff b2	12	-32768	32767	1326	_
		Model	14	Coeff b3	12	-32768	32767	-3880	
			16	Coeff b4	12	-32768	32767	5127	-
			18	RC0	12	-32768	32767	11703	
			20	ADC0	12	-32768	32767	11703	_
			22	RPAD	12	-32768	32767	0	
			24	RINT	12	-32768	32767	0	I
			0	Coeff a1	12	-32768	32767	-14520	I
			2	Coeff a2	12	-32768	32767	23696	_
			4	Coeff a3	12	-32768	32767	-20298	1
			6	Coeff a4	12	-32768	32767	28073	_
			8	Coeff a5	l2	-32768	32767	865	_
		Fet	10	Coeff b1	12	-32768	32767	-694	_
Calibration	67	Temperature	12	Coeff b2	l2	-32768	32767	1326	_
		Model	14	Coeff b3	12	-32768	32767	-3880	
			16	Coeff b4	12	-32768	32767	5127	_
			18	RC0	12	-32768	32767	11703	-
			20	ADC0	12	-32768	32767	11703	_
			22	RPAD	12	-32768	32767	0	_
			24	RINT	12	-32768	32767	0	_



Class	Subclass ID	Subclass	Offset	Name	Data Type	Min. Value	Max. Value	Default Value	Units
			1	Cell Voltage 1	U1	0	255	145	_
			2	Cell Voltage 2	U1	0	255	145	_
			3	Cell Voltage 3	U1	0	255	145	_
			4	Cell Voltage 4	U1	0	255	145	_
			5	Pack Voltage Out	U1	0	255	10	_
Calibration	93	Filter	6	Direct Battery Voltage	U1	0	255	10	_
			7	Summed Battery Voltage	U1	0	255	145	_
			8	Cell Temperature	U1	0	255	145	_
			9	FET Temperature	U1	0	255	145	_
		Current	0	Deadband	U1	0	255	3	mA
Calibration	103	Deadband	1	Coulomb Counter Deadband	U1	0	255	34	290 nV



AFE Threshold and Delay Settings

A.1 Overload in Discharge Protection (OLD)

Table A-1. Overload in Discharge Protection Threshold (Settings: AFE State Control [RSNS] = 0)

	OLD Threshold	i ([RSNS] = 0)	
Setting	Threshold	Setting	Threshold
0x00	0.050 V	0x08	0.130 V
0x01	0.060 V	0x09	0.140 V
0x02	0.070 V	0x0a	0.150 V
0x03	0.080 V	0x0b	0.160 V
0x04	0.090 V	0x0c	0.170 V
0x05	0.100 V	0x0d	0.180 V
0x06	0.110 V	0x0e	0.190 V
0x07	0.120 V	0x0f	0.200 V

Table A-2. Overload in Discharge Protection Threshold (Settings: AFE State Control [RSNS] = 1)

	OLD Threshold	I ([RSNS] = 1)	
Setting	Threshold	Setting	Threshold
0x00	0.025 V	0x08	0.065 V
0x01	0.030 V	0x09	0.070 V
0x02	0.035 V	0x0a	0.075 V
0x03	0.040 V	0x0b	0.080 V
0x04	0.045 V	0x0c	0.085 V
0x05	0.050 V	0x0d	0.090 V
0x06	0.055 V	0x0e	0.095 V
0x07	0.060 V	0x0f	0.100 V

Table A-3. Overload in Discharge Protection Delay

Setting	Time	Setting	Time	Setting	Time	Setting	Time
0x00	1 ms	0x04	9 ms	0x08	17 ms	0x0c	25 ms
0x01	3 ms	0x05	11 ms	0x09	19 ms	0x0d	27 ms
0x02	5 ms	0x06	13 ms	0x0a	21 ms	0x0e	29 ms
0x03	7 ms	0x07	15 ms	0x0b	23 ms	0x0f	31 ms

A.2 Short Circuit in Charge (SCC)

Table A-4. Short Circuit in Charge Threshold (Settings: AFE State Control [RSNS] = 0)(1)

Setting	Threshold	Setting	Threshold
0x00	−0.100 V	0x04	-0.300 V
0x01	−0.150 V	0x05	N/A
0x02	−0.200 V	0x06	N/A

⁽¹⁾ Data flash setting Protection: SCC Threshold[2:0] sets the voltage threshold.



Table A-4. Short Circuit in Charge Threshold (Settings: AFE State Control [RSNS] = 0)⁽¹⁾ (continued)

Setting	Threshold	Setting	Threshold
0x03	−0.250 V	0x07	N/A

Table A-5. Short Circuit in Charge Threshold (Settings: AFE State Control [RSNS] = 1)(1)

Setting	Setting Threshold Setting		Threshold
0x00	0x00 -0.050 V 0x04		–0.150 V
0x01	−0.075 V	0x05	−0.175 V
0x02	-0.100 V	0x06	-0.200 V
0x03	−0.125 V	0x07	−0.225 V

⁽¹⁾ Data flash setting Protection: SCC Threshold[2:0] sets the voltage threshold.

Table A-6. Short Circuit in Charge Delay(1)

Setting	Time	Setting	Time	Setting	Time	Setting	Time
0x00	0 µs	0x04	244 µs	0x08	488 µs	0x0c	732 µs
0x01	61 µs	0x05	305 µs	0x09	549 µs	0x0d	793 µs
0x02	122 µs	0x06	366 µs	0x0a	610 µs	0x0e	854 µs
0x03	183 µs	0x07	427 µs	0x0b	671 µs	0x0f	915 µs

⁽¹⁾ Data flash setting Protection: SCC Threshold[7:4] sets the delay time.

A.3 Short Circuit in Discharge (SCD1 and SCD2)

Table A-7. Short Circuit in Discharge Threshold (Settings: AFE State Control [RSNS] = 0)(1)

Setting	Threshold Setting		Threshold
0x00	0x00 0.100 V 0x0		0.300 V
0x01	0.150 V	0x05	0.350 V
0x02	0.200 V	0x06	0.400 V
0x03	0.250 V	0x07	0.450 V

Data flash setting Protection: SCD1 and SCD2 Threshold[2:0] sets the voltage threshold.

Table A-8. Short Circuit in Discharge Threshold (Settings:AFE State Control[RSNS] = 1)(1)

Setting	Setting Threshold		Threshold
0x00	0.050 V	0x04	0.150 V
0x01	0.075 V	0x05	0.175 V
0x02	0.100 V	0x06	0.200 V

⁽¹⁾ Data flash setting Protection: SCD1 and SCD2 Threshold[2:0] sets the voltage threshold.

Table A-9. Short Circuit in Discharge 1 Delay (Settings: AFE State Control[SCDDx2] = 0)(1)

Setting	Time	Setting	Time	Setting	Time	Setting	Time
0x00	0 μs	0x04	244 µs	0x08	488 µs	0x0c	732 µs
0x01	61 µs	0x05	305 µs	0x09	549 µs	0x0d	793 µs
0x02	122 µs	0x06	366 µs	0x0a	610 µs	0x0e	854 µs
0x03	183 µs	0x07	427 µs	0x0b	671 µs	0x0f	915 µs

Data flash setting Protection: SCD1 and SCD2 Threshold[7:4] sets the delay time.

Table A-10. Short Circuit in Discharge 1 Delay (Settings: AFE State Control[SCDDx2] = 1)(1)

Setting	Time	Setting	Time	Setting	Time	Setting	Time
0x00	0 μs	0x04	488 µs	0x08	976 µs	0x0c	1464 µs

⁽¹⁾ Data flash setting Protection:SCD1 Threshold[7:4] sets the delay time.



Table A-10. Short Circuit in Discharge 1 Delay (Settings:AFE State Control[SCDDx2] = 1)⁽¹⁾ (continued)

Setting	Time	Setting	Time	Setting	Time	Setting	Time
0x01	122 µs	0x05	610 µs	0x09	1098 µs	0x0d	1586 µs
0x02	244 µs	0x06	732 µs	0x0a	1220 µs	0x0e	1708 µs
0x03	366 µs	0x07	854 µs	0x0b	1342 µs	0x0f	1830 µs

Table A-11. Short Circuit in Discharge 2 Delay (Settings:AFE State Control[SCDDx2] = 0)(1)

Setting	Time	Setting	Time	Setting	Time	Setting	Time
0x00	0 µs	0x04	122 µs	0x08	244 µs	0x0c	366 µs
0x01	30 µs	0x05	152 µs	0x09	275 µs	0x0d	396 µs
0x02	61 µs	0x06	183 µs	0x0a	305 µs	0x0e	426 µs
0x03	91 µs	0x07	213 µs	0x0b	335 µs	0x0f	458 µs

⁽¹⁾ Data flash setting Protection: SCD2 Threshold[7:4] sets the delay time.

Table A-12. Short Circuit in Discharge 2 Delay (Settings: AFE State Control[SCDDx2] = 1)(1)

Setting	Time	Setting	Time	Setting	Time	Setting	Time
0x00	0 µs	0x04	244 µs	0x08	488 µs	0x0c	732 µs
0x01	61 µs	0x05	305 µs	0x09	549 µs	0x0d	793 µs
0x02	122 µs	0x06	366 µs	0x0a	610 µs	0x0e	854 µs
0x03	183µs	0x07	427 µs	0x0b	671 µs	0x0f	915 µs

⁽¹⁾ Data flash setting Protection: SCD2 Threshold[7:4] sets the delay time.



Reading and Writing to Data Flash

Use *ManufacturerAccess()* 0x01yy and ManufacturerInput() 0x2F to read and right to data flash, which is a 32-byte operation. First, determine the physical address of the target data flash parameter. This information is reflected by the subclass ID and offset, available in Table 11-1.

Below is an example of updating data flash setting Protections: CUV Recovery

Subclass ID of Protections: CUV Recovery = 235

Offset of Protections: CUV Recovery = 3.

Data Type = I2.

- 1. Identify the data flash row number and byte index:
 - (a) Identify the physical address of the target parameter.

The physical address of Protections: CUV Recovery = Subclass ID + Offset = 238.

(b) Find the row number of Protections: CUV Recovery.

Each data flash row is 32-byte long.

Row number of Protections: $CUV Recovery = 238\32 = 7$.

(c) Find out which byte(s) the target parameter resides with the row.

Byte Index = Physical location—(row number * row length).

Byte Index for Protections: CUV Recovery = 238-(7*32) = 14.

Since the data type of Protections: *CUV Recovery* is I2, this means the target parameter resides at row 7, byte index 14 and 15.

- 2. Read data flash parameter:
 - (a) Send the data flash row number to bq30z554-R1 using MAC command 0x1yy.

From Step A2, the row number of CUV Recovery is 7.

Issue SMBus write word. cmd = 0x00, word = 0x107.

Note: The row number issued through command 0x1yy must be in hex.

(b) Use ManufacturerInput() 0x2F to read the data flash row where the target parameter is located.

Issue SMBus block read, cmd = 0x2F, length = 32.

Note: Store the read data into a memory array, e.g., yRowDataArray(0 to 31).

- (c) Data flash parameter Protections:CUV Recovery is located at yRowDataArrray(14) and yRowDataArrray(15).
- 3. Update data flash parameter.
 - (a) From Step B3, update the desired value of the target data flash parameter.
 - (b) Follow Step B1 to set up the row number.
 - (c) Use ManufacturerInput() 0x2F to write the updated yRowDataArray(0 to 31) back to the device data flash.

Issue SMBus block write, cmd = 0x2F, length = 32.

(d) A read verify (repeat Steps B1 to B3) is recommended to ensure correct data is written to the data flash.

See Section 11.16 for the data flash values.



Sample Filter Settings

Table C-1. Sample Remcap Filter Settings and Associated Low-Pass Filter Time Constants

Remcap Smoothing Filter	Effective Low-Pass Time Constant
200	11 seconds
230	22 seconds
240	36 seconds
245	54 seconds
250	100 seconds
252	146 seconds
253	3.2 minutes
254	4.8 minutes
255 (max)	9.6 minutes

Table C-2. Sample V/I/T Filter Settings and Associated Low-Pass Filter Time Constants

V/I/T Smoothing Filter	Effective Low-Pass Time Constant
10	0.25 seconds
50	0.5 seconds
145	1 second
200	3 seconds

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have *not* been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products Applications

Audio www.ti.com/audio Automotive and Transportation www.ti.com/automotive Communications and Telecom **Amplifiers** amplifier.ti.com www.ti.com/communications **Data Converters** dataconverter.ti.com Computers and Peripherals www.ti.com/computers **DLP® Products** www.dlp.com Consumer Electronics www.ti.com/consumer-apps

DSP **Energy and Lighting** dsp.ti.com www.ti.com/energy Clocks and Timers www.ti.com/clocks Industrial www.ti.com/industrial Interface interface.ti.com Medical www.ti.com/medical logic.ti.com Logic Security www.ti.com/security

Power Mgmt power.ti.com Space, Avionics and Defense www.ti.com/space-avionics-defense

Microcontrollers <u>microcontroller.ti.com</u> Video and Imaging <u>www.ti.com/video</u>

RFID www.ti-rfid.com

OMAP Applications Processors <u>www.ti.com/omap</u> TI E2E Community <u>e2e.ti.com</u>

Wireless Connectivity <u>www.ti.com/wirelessconnectivity</u>