PRODUCT GUIDE

Lumora Thermostat T3 Product Guide

Document number	LHS-PG-T3-001
Revision	2.2
Effective date	April 20, 2026
Document owner	Product Support Engineering
Audience	Customer Care, Technical Support, Certified Installers
Classification	Internal - do not distribute outside Lumora

Purpose. Reference for supporting the Lumora Thermostat T3 (model LT-T3): specifications, installation including homes without a C-wire, multi-stage and heat pump configuration, humidity control, troubleshooting and error codes.

1. Product Overview

The Lumora Thermostat T3 is the premium model of the Lumora climate line. It has a 3.5 in color touchscreen, a built-in humidity sensor, support for multi-stage equipment and heat pumps with auxiliary heat, and a rechargeable battery that keeps it running during short power interruptions.

The T3 is sold under SKU LT-T3-01 at a list price of $229.00. New T3 customers receive a 30-day free trial of the Lumora Plus subscription. Several specifications differ from the Thermostat T2, including the setpoint range, the number of supported room sensors, the meaning of some error codes and the warranty term.

1.1 What Is in the Box

- Thermostat T3 display unit and wall plate with built-in level
- Trim plate, two wall screws, two drywall anchors and wire labels
- One Lumora Room Sensor S1 (T3 bundle SKU LT-T3-02 only)
- Quick Start card with pairing code

1.2 System Compatibility

The T3 supports 24 VAC conventional systems with up to 3 heat and 2 cool stages, and heat pumps with up to 2 compressor stages plus auxiliary and emergency heat. Dual-fuel systems are supported from firmware 2.3. Like the T2, the T3 is not compatible with line-voltage (120 V or 240 V) heaters.

2. Specifications

Item	Thermostat T3 (LT-T3)
Display	3.5 in color capacitive touchscreen with proximity wake
Setpoint range	40 °F to 92 °F (4.5 °C to 33 °C)
Temperature accuracy	±0.5 °F (±0.3 °C)
Humidity sensing	0-100% RH, accuracy ±3% RH
Supported stages	Up to 3 heat / 2 cool (conventional); heat pump up to 2 compressor stages with auxiliary and emergency heat
Power	24 VAC, 50/60 Hz; C-wire recommended (see 3.3)
Battery	Rechargeable Li-ion, approx. 6 hours of operation without power
Wireless	802.11 a/b/g/n/ac, 2.4 GHz and 5 GHz; LumoraLink radio
Room Sensor S1 support	Up to 6 sensors
Compressor protection	5-minute minimum off-time, adjustable 2-10 minutes
Dimensions	4.3 x 4.3 x 0.9 in (109 x 109 x 23 mm)
Operating environment	32 °F to 104 °F, 5% to 90% RH non-condensing
Warranty	3 years (36 months) limited warranty

Table 2-1. Thermostat T3 technical specifications.

Comparison: Customers frequently compare the T2 and T3. The key differences are the setpoint range (T2: 45-90 °F, T3: 40-92 °F), room sensor support (T2: 2, T3: 6), C-wire requirement (T2: required, T3: recommended) and warranty (T2: 2 years, T3: 3 years).

3. Installation

Installation takes 30 to 60 minutes. Homes with heat pumps or more than two stages should be referred to a Lumora Certified Installer; professional installation costs a flat $129 and can extend the warranty (see the Lumora Limited Warranty Policy, LHS-POL-001).

3.1 Before You Start

1. Switch off power to the heating and cooling equipment at the circuit breaker or service switch. Confirm the system is off by raising the setpoint on the old thermostat and waiting two minutes; the equipment must not start.
2. Remove the faceplate of the existing thermostat and take a clear photo of the wiring before disconnecting anything. Installers must attach this photo to the installation record.
3. Label each wire with the supplied wire labels according to the terminal letter it was connected to, not by wire color. Wire colors are not standardized between installers.
4. Disconnect the wires and remove the old wall plate. Wrap the wire bundle around a pencil so that it cannot fall back into the wall.

3.2 Wiring Terminals

Terminal	Function
R / Rc	24 VAC power; the T3 detects a jumper automatically
C	24 VAC common (recommended; required in the cases listed in 3.3)
W1 / W2 / W3	Conventional heat stages 1-3
Y1 / Y2	Cool or compressor stages 1-2
G	Fan
O/B	Heat pump reversing valve
AUX / E	Auxiliary heat / emergency heat
ACC+ / ACC-	Accessory: humidifier or dehumidifier dry contacts

Table 3-1. T3 wall plate terminals.

The T3 wall plate accepts solid or stranded wire from 18 to 22 AWG. If the home has an unused wire in the bundle, installers should connect it as the C-wire at both the wall plate and the equipment control board rather than installing a PEK-1. Always confirm with a voltmeter that R to C measures between 20 and 30 VAC before attaching the display.

3.3 Homes Without a C-Wire

Unlike the T2, the T3 can usually be installed without a C-wire. It charges its internal battery from the heating and cooling circuits while the equipment is idle, and runs on the battery for up to about 6 hours during power interruptions. The battery-only mode is designed for single-stage conventional systems and has been validated on furnaces and boilers.

However, a C-wire or the Power Extender Kit PEK-1 is **mandatory** in three cases: heat pump systems that use auxiliary or emergency heat, any system with more than one cooling stage, and homes where the T3 controls a humidifier or dehumidifier through the ACC terminals. In these cases the T3 displays error E10 within 24 hours if no C-wire is detected, and Customer Care must arrange a PEK-1 before the case can be closed.

3.4 Mounting

1. Mount the wall plate 52 to 60 in (1.3 to 1.5 m) above the floor on an interior wall, away from supply vents, windows and direct sunlight.
2. Insert the labelled wires into the matching terminals and push the excess back into the wall.
3. Attach the display. The T3 starts on battery immediately and asks for the equipment configuration.
4. Restore power at the breaker and complete the setup wizard.

4. Configuration

4.1 Equipment Setup

The setup wizard detects connected terminals and proposes an equipment configuration. Installers must confirm the heat pump changeover setting (O or B), the auxiliary heat lockout temperature (default 35 °F outdoor) and the number of stages before finishing.

4.2 Humidity Control

With a humidifier or dehumidifier connected to the ACC terminals, the T3 can hold indoor humidity between 30% and 60% RH. Without accessory equipment, the T3 can still dehumidify by overcooling: it runs the air conditioner up to 3 °F below the cooling setpoint while humidity is above target.

4.3 Room Sensors and Occupancy

The T3 supports up to six Lumora Room Sensor S1 units. Each schedule period can use a different set of sensors, and the Follow Me mode averages only rooms where occupancy was detected in the last 30 minutes.

5. Troubleshooting

Check the firmware version under Settings > About before troubleshooting. The current T3 release is 2.6.1. Battery status is shown under Settings > Power; a battery below 20% while the system is idle usually means the battery cannot charge without a C-wire.

Symptom	Likely cause	Resolution
Thermostat restarts every few hours	Battery not charging (no C-wire, multi-stage system)	Install C-wire or PEK-1; see section 3.3.
Humidity reading stuck at 0% or 100%	Humidity sensing element failure	Power-cycle; if it persists the code E4 is shown - start a warranty claim.
Auxiliary heat runs too often	Aux lockout set too high or droop too small	Lower aux lockout; set aux droop to 2 °F or more.
Touchscreen does not respond	Screen frozen during update	Hold the screen for 10 seconds to force a restart.
Sensor rooms ignored	Sensor not assigned to the current schedule period	Assign sensors in the app under Comfort > Sensors.

Table 5-1. Common T3 symptoms.

5.1 Factory Reset

On the T3, open Settings > Reset > Factory Reset and confirm with the 4-digit code shown on screen. If the touchscreen is unusable, remove the display from the wall plate, then press the recessed reset button on the back for 10 seconds while reattaching it.

6. Error Codes

T3 error codes share some numbers with the T2 but not their meanings. In particular, network problems are reported as E12 on the T3, while E4 on the T3 refers to the humidity sensor.

Code	Meaning	Recommended action
E1	Internal temperature sensor failure	Warranty claim.
E2	No heat detected after 20 minutes	Check W1 and the furnace.
E3	No cooling detected after 20 minutes	Check Y1 and the outdoor unit.
E4	Humidity sensor fault	Power-cycle; warranty claim if persistent.
E5	Room sensor not reporting for 2 hours	Replace S1 battery.
E6	Auxiliary heat running during lockout	Check AUX wiring and the outdoor temperature source.
E7	Battery critically low	Check C-wire; charge on USB-C if removed.
E10	No C-wire detected on a configuration that requires one	Install C-wire or PEK-1 (section 3.3).
E11	Accessory (ACC) relay fault	Check humidifier wiring.

Code	Meaning	Recommended action
E12	Lost connection to the wireless network for more than 10 minutes	Reconnect in Settings > Network.
E13	Firmware update failed	Retry after 1 hour.

Table 6-1. Thermostat T3 error codes.

7. Warranty and Support

7.1 Warranty Summary

The Thermostat T3 carries a 3-year (36-month) limited warranty from the date of delivery, one year longer than the T2. The warranty can be extended when the T3 is professionally installed; the conditions are defined only in the Lumora Limited Warranty Policy (LHS-POL-001). Advance replacement is available for the T3 to all customers (see the Warranty Claims SOP).

7.2 Escalation Triggers

- Burning smell, scorch marks or a swollen battery: safety case, P1 in the Ticket Escalation SOP. Instruct the customer to remove the display from the wall and keep it away from flammable material.
- E1 or E4 that persists after a power-cycle: warranty claim.
- E10 after a PEK-1 has been installed: Tier 2 Technical Support.

8. Appendix A: Heat Pump Configuration Reference

Use this table when helping an installer or customer configure a heat pump. Settings are under Settings > Equipment > Heat Pump. Values outside the allowed range are rejected by the setup wizard.

Setting	Default	Allowed range	Guidance
Reversing valve	O (energize in cool)	O or B	Most systems use O; B is common on older systems from some manufacturers.
Auxiliary heat lockout	35 °F outdoor	0 °F to 50 °F	Raise in cold climates if the heat pump cannot keep up.
Compressor lockout	Off	-10 °F to 40 °F	Used for dual-fuel systems only.
Aux heat droop	2 °F	1 °F to 5 °F	Temperature drop below setpoint before aux heat starts.
Defrost aux heat	On	On / Off	Prevents cold air during defrost cycles.
Emergency heat timeout	None	None, 2, 4, 8 h	Returns to normal heat after the timeout.

Table 8-1. T3 heat pump settings.

9. Appendix B: Accessories and Quick Answers

9.1 Compatible Accessories

- Lumora Room Sensor S1 (up to six per T3)
- Lumora Hub H1 (required for homes with more than one thermostat)
- Power Extender Kit PEK-1 (for the mandatory C-wire cases in section 3.3)
- T3 trim plate in white or graphite (sold separately, $12)

9.2 Quick Answers

Can the T3 show outdoor temperature?

Yes. The T3 shows outdoor temperature and humidity from a weather service based on the home address. An outdoor sensor is not required.

Does the T3 work during a power outage?

The display and network connection stay on battery for about 6 hours, so the app continues to show indoor conditions. The heating and cooling equipment does not run without power.

Can the T3 screen be locked?

Yes. Settings > Lock sets a 4-digit PIN. A locked T3 still allows temperature changes within a range set by the home Owner, by default ±2 °F of the scheduled setpoint.

Revision History

Revision	Date	Change
2.2	April 20, 2026	Clarified mandatory C-wire cases; firmware 2.6.1.
2.1	December 1, 2025	Added E13 and dual-fuel support.
2.0	August 18, 2025	Initial release for T3 hardware revision B.