

Preliminary SlimSat Data Dictionary

1/16/2026

Eric Tapio

Command Description	Command ID	Use Case
Get S/C Bus DB Register Values	2	Standard Student User
Get S/C Bus Data	3	Standard Student User
Get Payload Data	4	Standard Student User
Get Beacon Period	24	Super Student User
Set Beacon Period	25	Super Student User
Get S/C Bus Mode	26	Super Student User
Set S/C Bus Mode	27	Super Student User
Get S/C Safe-Mode Voltage (in mV)	31	Super Student User
Set S/C Safe-Mode Voltage (in mV)	32	Super Student User
Get S/C Bus Data Rec Period	33	Super Student User
Set S/C Bus Data Rec Period	34	Super Student User
Get Payload Operation Period	35	Super Student User
Set Payload Operation Period	36	Super Student User
Reboot	37	Super Student User
Erase Flash Chip Memory	40	Super Student User
Erase S/C Bus Data Flash Blocks	43	Super Student User
Erase Payload Data Flash Blocks	44	Super Student User
Ping	1	GS User
Get LoRa Frequency	5	GS User
Set LoRa Frequency	6	GS User
Get LoRa Bandwidth	7	GS User
Set LoRa Bandwidth	8	GS User
Get LoRa Spread Factor	9	GS User
Set LoRa Spread Factor	10	GS User
Get LoRa Coding Rate	11	GS User
Set LoRa Coding Rate	12	GS User
Get LoRa Output Power	13	GS User
Set LoRa Output Power	14	GS User
Get LoRa Current Limit	15	GS User
Set LoRa Current Limit	16	GS User
Get LoRa Preamble Length	17	GS User
Set LoRa Preamble Length	18	GS User
Get LoRa Gain	19	GS User
Set LoRa Gain	20	GS User
Get Frequency Error	21	GS User
Get LoRa SNR	22	GS User
Get LoRa RSSI (Received Signal Strength)	23	GS User
Get S/C Bus GPS Position	45	Balloon Flight User
Cutdown (Burn wire)	46	Balloon Flight User
Get S/C Bus Epoch Time	28	Will Likely Remove
Set S/C Bus Epoch Time	29	Will Likely Remove
Get S/C Bus Time	30	Will Likely Remove
Get Flash Register Sector Value	38	Will Likely Remove
Set Flash Register Sector Value	39	Will Likely Remove
Erase Flash Block Number	41	Will Likely Remove
Erase Flash Sector Number	42	Will Likely Remove