

OTAP - Overview



Description:

- § OTAP is a mechanism to install, update and delete Java applications over the air interface
- § OTAP can be fully controlled over SMS
- § or over the AT command at^sjotap


Requirements:

- § web server for .jad & .jar files (http authentication)
- § GPRS or CSD data connection (set the right parameters)
- § OTAP Controller (something to sent SMS to TC45)



OTAP – how it works





OTAP - parameters



Parameters which control OTAP procedure set by AT^SJOTAP or SMS

- § sms passwort to protect TC45
- § url from java application server (location for install and update procedures)
- § http username and password (http authentication)
- § Destination folder on nTC45 (a:/tc45/otap/newappl)
- § data connection "gprs" or "csd"
- § APN (Access Point Name or number to dial)
- § Username and password for the GPRS network (opt.)
- § DNS (Domain Name Server)



OTAP - pay attention (1)



- § The SMS MUST be a submit PDU sms with 8 bit encoding (140 characters)
- § Can be class 0 or 1 and the Pid 7d or 00
- § Use always the PWD: command in the SMS, even if you have not set a password (PWD:"")
- § If you have to set more parameters with SMS just create and sent more than one sms
- § Set always the password to protect your TC45

OTAP - pay attention (2)



- § Start each SMS with OTAP_IMP1.0 PWD:"password"
- § Insert <line feed> hex 0A after each command, also on the end of the sms
- § Is not possible to change the parameters set by at^sjotap command via SMS (security)
- § Error reports are posted to the web server (http)
- § .JAD file is very important for OTAP
- § If the destination folder doesn't exist TC45 will create it

OTAP - example - use at^sjotap



otap over gprs/csd

Password: siemens (OTAP password for sms)

JAD-URL: http://www.wmae.com/otap/infosms/infosms.jad

Application folder for the java file: a:/ota

Bearer service: gprs

Access Point Name: e.g. web.vodafone.de (Germany)

User name: none Password: none

Primary DNS 139.7.30.125

at^sjotap="siemens","http://www.wmae.com/otap/infosms/infosms.jad","a:/ota","","","gprs"," web.vodafone.de", "", "", "139.7.30.125,,

at^sjotap="siemens","<a href="http://www.wmae.com/otap/infosms/infosms.jad","a:/ota","","","csd","02113005244","internet","internet",","

at^sjotap <return> starts otap

OTAP - example - use submit PDU SMS



sms receiver +491751839832 service center adr. +491710760000 class 0/8bit, validity period not present

Text:

OTAP_IMP1.0 PWD:siemens START:install

079194710167000001000C9194711538892300F4264F54415011494D50312 E300A5057443A7369656D656E730A53544152543A696E7374616C6C0A length = 51

at+cmgs=51 <return>
>079194710167000001000C9194711538892300F4264F54415011494D50312
E300A5057443A7369656D656E730A53544152543A696E7374616C6C0A
<cntrl Z>

OTAP - example - SMS commands - install



First SM

OTAP_IMP1.0 PWD:secret

JADURL: http://www.greatcompany.com/coolapps/mega.jad

APPDIR:a:/work/appdir

HTTPUSER:user

HTTPPWD:anothersecret

Second SM

OTAP_IMP1.0 PWD:secret

BEARER:gprs

APNORNUM: access.to-thenet.net

NETUSER:nobody **NETPWD:**nothing **DNS:**192.168.1.2

START:install

OTAP - example - SMS commands - delete



OTAP_IMP1.0

PWD:secret

APPDIR:a:/work/appdir

START:delete

Only folders can be deleted

OTAP summary




- Installing, Updating and Deleting JAVA applications over the Air
- No serial interface is needed
- Http server must be reachable by the TC45 over TCP / IP connection
- Check errors by Result Codes returned by the module
- Old application is deleted after otap was succesfull
- To protect old application use different name
- Space in flash for old and new application
- If no enough space, delete old application first
- For more details -> TC45 Java Users Guide
- Free tools to create PDU SMS (pduspy, pdugen)



OTAP (10)







Thank you for your attention

www.siemens.com/wm