
9a) Live visualization of head orientation (when IMU is on)
Default web app address when access from the same PC as server
localhost:3000
OptoGrid App
1) Scan
2) Select your OptoGrid device
3) Connect
Scan
FKY-O-0025
Connect
[03:01:21] Connecting to FKY-O-0025...
[03:01:25] Connected to FKY-O-0025
[03:01:26] GATT table populated with 9 characteristics
[03:01:26] Reading battery voltage...
[03:01:26] Reading uLED check...
[03:01:26] LED Selection synced: 18446744073709551615
[03:01:26] Battery: 3956 mV
[03:01:26] uLED Check: 18446744073709551487
[03:01:38] Sending command: optogrid.disableIMU (current state: true, new state: false)
[03:01:38] IMU Enable: False
5) Click to trigger the current programmed stimulation
7) Click to program the current Parameter Table to the device
Read
Write
Trigger
GATT Table:
Parameter | Current Value | Write Value | Unit
Sequence Length | 1 | 1 | count
LED Selection | 18446744073709551615 | 18446744073709551615 | bitmap
Duration | 550 | 550 | ms
Period | 100 | 100 | ms
Pulse Width | 1 | 1 | ms
Amplitude | 100 | 100 | %
PWM Frequency | 50000 | 50000 | Hz
Ramp Up Time | 0 | 0 | ms
Ramp Down Time | 0 | 0 | ms
6a) Input your desired parameter value in this column; change "Sequence Length" to 2 or more if you want to program a sequence of opto
Toggle the LEDs to select:
SHAM
IMU
STATUS
uLED Scan
Last Stim
Read Battery
3956 mV
IMU Raw Data (most recent 500 samples):
Accelerometer (g)
Gyroscope (°/s)
Magnetometer (μT)
X Y Z
3.7
-2.5
1588.8
-1656.2
7.3
-19.1
6b) Toggle the LEDs here in this brainmap to intuitively select your LEDs
8b) Example of "uLED Scan" function that found this device's LED8 is broken
4) These toggles the on/off of:
- Sham LED (Blue)
- Status LED (Red)
9) Toggle IMU recording
Recorded data can be found in the folder named "data"
8) Try the debug functions:
- uLED Scan: Scans all 64 LEDs, and the broken LEDs will be marked with a red X in the LED map above
- Last Stim: Prints the last triggered stimulation's timestamp
- Read Battery: Updates to the latest battery voltage value
9b) Live IMU raw data (when IMU is on)