

<テキスト資料> turtlesimをPythonノードで動かしてみよう

my_node.pyを書き換え

```
import rclpy
from rclpy.node import Node
from geometry_msgs.msg import Twist

class TurtleController(Node):
    def __init__(self):
        super().__init__('turtle_controller')
        self.publisher_ = self.create_publisher(Twist, '/turtle1/cmd_vel', 10)
        self.timer = self.create_timer(1.0, self.timer_callback)

    def timer_callback(self):
        msg = Twist()
        msg.linear.x = 2.0
        msg.angular.z = 1.0
        self.publisher_.publish(msg)
        self.get_logger().info(f'Published: linear={msg.linear.x}, angular={msg.angular.z}')

def main(args=None):
    rclpy.init(args=args)
    node = TurtleController()
    rclpy.spin(node)
    node.destroy_node()
    rclpy.shutdown()
```

パッケージをビルド

```
cd ~/colcon_ws
colcon build
source install/setup.bash
```

別ターミナルでTurtlesimを起動

```
ros2 run turtlesim turtlesim_node
```

元ターミナルで自作ノードを起動

```
ros2 run my_py_pkg my_node
```