

1. This library provides two files:

DP_Print_lib.lib: driver library file

DP_Print_inc.h: header file description file, including instructions for using the library

2. Usage:

Copy the above two files to the MCU project directory, add them to the MCU project, and set the header file.

This library is compiled in the Keil MDK environment and can only be used for development in the Keil MDK environment.

The user needs to write the interface program void UART_SendByte(unsigned char Send_Dat), that is, for the specific

Write a function for sending one byte through the serial port.

Before using the functions provided by the library, you need to call void CheckPassWord(unsigned char *InputPassWord) to verify the password.

code.

3. Function library description: In the header file, each function is preceded by a macro definition of Ena_+function name, which is 0, indicating that it will not be compiled.

1 means compile. This function is optional to avoid wasting unnecessary space and RAM when 51 resources are tight.

Serial number	Function	Function
1	name void CheckPassWord(unsigned char *InputPassWord)	Verify the password. This library can only be used after the password is verified.
2	void InitializePrint(void) void	Initialize the printer
3	Print_ASCII(unsigned char *Str,unsigned char StrLen) void	Send Print Content
4	print_And_Line(void)	Print buffer contents and feed paper
5	void Set_Right_Interval(unsigned char interval) void	Set the right character spacing
6	Set_Print_Mode(unsigned char optbit) void	Select Print Mode
7	Set_Print_Position(unsigned char Lpos,unsigned char Hpos)	Set the position from the beginning of a line to the position where the characters are to be printed The distance from the beginning of a line to the print position. The distance is $[(nL + nH \times 256) \times 0.125 \text{ mm}]$.
8	void Set_Left_Interval(unsigned char Interval)	Set the left margin

9	void UserDefineCharacter(unsigned char yByte, unsigned char xDot, unsigned char DefChar, unsigned char *pData)	Define user-defined characters
10	void Sel_Custom_Character(unsigned char SelOpt)	Select/cancel user-defined characters. This function should be used with the function Number 9 Use with
11	void Sel_Bitmap_Mode(unsigned char mode, unsigned char DatLenLowByte, unsigned char DatLenHighByte, unsigned *pDotData)	Select Bitmap Mode
11	void Set_UnderLine(unsigned char Opt)	Select Underline (only valid for English)
12	void SetDefaultLineInterval(void)	Select the default line spacing, which is 3.75 mm (30 × 0.125 mm)
13	void SetBold(unsigned char opt)	Set/unset bold printing (only valid for English)
14	void PrintGoPage(unsigned char nstep)	Print out the data in the print buffer and feed paper [n × 0.125 mm]
15	void Set_Rotate(unsigned char nsel)	Set/release 90° clockwise rotation
16	void Get_Print_State(void)	Send printer status
17	void Sel_Align_Way(unsigned char nsel)	Select alignment
18	void SetReversal(unsigned char nsel)	Set/release upside-down printing mode
19	void SetCharacterSize(unsigned char width, unsigned char hight) void DownloadBitmap(unsigned	Set character size
20	char xDot, unsigned char yDot, unsigned char *pDat)	Define the download bitmap
	void PrintDownLoadBitmap(unsigned char mode)	To print the downloaded bitmap, you must first call function 20 and then call This function
	void Set_Inverse(unsigned char opt)	Set/release reverse printing mode
	void Set_HRIPosition(unsigned char opt)	Select the print position of the barcode HRI characters

	void Set_BarCodeHight(unsigned char verticalDotNum)	Set barcode height
25	void Set_BarCodeLeftSpace(unsigned char SpaceNum) void	Set the left margin of barcode printing
26	Set_BarCodeWidth(unsigned char widthsel)	Set barcode width
27	void PrintBarcode(unsigned char CodeType,unsigned char *pData,unsigned char pDataLen)	Print barcode
28	void SetChinesemode(unsigned char opt)	Set the Chinese character printing mode
29	void Set_ChineseCode(unsigned char selopt) void	Set Chinese encoding format
30	TestPrintPage(void)	Print a test page
31	void PrintGratinmap(unsigned char mode,unsigned int xDot,unsigned int yDot,unsigned char *pData)	Printing raster bitmaps
32	void Set_QRCodeAdjuLevel(unsigned char level) void	Set the error correction level of the QR code
33	Set_QRCodeBuffer(unsigned int Len, unsigned char *pData) void	Store the QR code data into the QR code buffer
34	PrintQRCode(void)	Print QR code