

Home / text commands / SMS Commands GT06N Vehicle Tracking Device Activation Codes

SMS Commands GT06N Vehicle Tracking Device Activation Codes



mbfallata to the server, text commands, Activate the GPS tracking device, vehicle tracking device

13/02/2024

Contact US





Contact US



Table of contents

1. GT06N Query SMS Commands
2. GT06N Settings SMS Commands Settings commands and codes
3. How To Send Codes To The GT06N Device

To Activate And Program Tracking Devices And Obtain The Best tracking Software, Contact Us

WhatsApp: 966570960313+

Telegram: @Trkify

GT06N Query Commands And Codes SMS Commands

No.	Occupation	Command/code	Reply
1	Check GT06N firmware version	VERSION#	e.g.[VERSION]GT06B_10_8MM_B25_V11_LA [BUILD]2013/01/04 17:45
2	Check GT06N parameters	PARAM#	eg GPS report on time interval : IMEI:868120103643505;TIMER:20,20; SENDS:5; SOS:1373045482 Center Number;;Sensorset:10,1,5,1; Defense time:10;

Contact US



			TimeZone:E,8,0; GPS report on distance interval: IMEI:868120103643505;Distance:200; SENDS:5; SOS:13730454825,,; Center Number::Sensorset:10,1,5,1; Defense time:10; TimeZone:E,8,0;
3	Query GT06N network setting	GPRSSET#	egGPRS:ON; APN:CMNET,,; Server:1,hgt06.szdatasource.com,8841,0; URL:http://maps.google.com/maps?q=;
4	Check GT06N status	STATUS#	egBattery:3.41V,Battery too low! Warning; GPRS:Link Up; GSM Signal Level:Strong; GPS:Successful positioning, SVS Used in fix:10(11), GPS Signal Level:32,31,32,31,28,29,29,36,32,33; ACC:OFF; Defense:OFF
5	Check position status	WHERE#	egCurrent position! Lat:N22.577156,Color:E113.916748,Course:0.00,Speed:0.00Km/h,Date Time:2013-01-08 17:35:32
6	Check URL	URL#	eg<01-08 17:36>http://maps.google.com/maps?q=N22.577156,E113.916748
7	Check position	POSITION# OR 123	eg GPS location: <01-08 17:36>http://maps.google.com/maps?q=N22.577156,E113.916748

Contact US



			GPS not located: GPS not fixed, please wait for a while, and then try again.
8	Check geo fence status	FENCE#	egFenceType:Circle, ON, Latitude:N22.577091, Longitude:E113.916748, radius:600m, in out:IN or OUT, alarm type:1 FenceType:Circle, OFF, Latitude:0.000000, Longitude:0.000000, radius:0m, in out:IN or OUT, alarm type:1
9	Check moving status	MOVING#	egMoving Switch:OFF; Radius:300m; Alarm type:1 Moving Switch:ON; Lat:N22.577080; Color:E113.916794; Radius:300m; Alarm type:1

GT06N Query SMS Commands

Related Links:

- [How To Activate The GT06N Device](#)
- [GT06N Server And Tracking Software](#)

GT06N Settings SMS Commands

No.	Occupation	Command/code	Reply	Explanation
	GT06N SETTING CLASS			

Contact US



1	Set APN	APN, [apnname]# OR APN, [apnname],[user],[pwd]#		Close automatic APN and yourself.
		APN#		Check the current APN parameters.
2	Set automatic APN	ASETAPN, [X]#		X=ON/OFF; ON: open automatic APN OFF: close automatic APN
		ASETAPN#		Check automatic APN sta
3	Set server parameters	SERVER,mode,domainName/IP,port,protocol#		eg: SERVER,1,www.ydpat.com SERVER,0,211.154.135.113,8 mode = 1 means set with name mode = 0 means set with address protocol = 0 means conn server with TCP protocol protocol = 1 means conn server with UDP pr

Contact US



		SERVER#		Check the current saving parameters
4	Set GMT parameter For GT06N	GMT,[A],[b],[C]#		A: E or W; "E" means ea time zone,"W" means wes time zone; default: E B: 0 ~ 12; time zone de 8 C: 0/15/30/45; half tim zone; default: 0
		GMT#		Check the current time z parameters
5	Restore GT06N to factory	FACTORY#		Restore to factory settin
6	Edit URL	EURL,network links#		set the network links for and longitude, default: http://maps.google.com/r
		EURL#		Check the current URL
7	GPRS Switch	GPRSON,X#		X=0 or 1;"1" means GPRS C means GPRS OFF, default
		#NOSRPG		Check the current GPRS

Contact US



8	Reboot GT06N	RESET#		The device would reboot after receiving the comm
9	GPRS blocking alarm	GPRSALM,X#		X=ON/OFF, default: OFF
		GPRSALM#		Check the GPRS alarm st
10	SOS setting	SOS,A,[phone number 1][phone number 2][phone number 3]#		Add SOS phone number.
		SOS,D,[sequence number 1][sequence number 2][sequence number 3]#		Delete the phone numbe according to the sequenc number.
		SOS,[D],[phone number]#		Delete the matching SOS number.
		SOS#		Check the SOS phone nu
11	Center phone number setting	CENTER, A, [phone number]#		Add center phone numbe
		CENTER, D#		Delete center phone num
		CENTER#		Check the center phone i
12	Heartbeat interval setting	HBT,[T1],[T2]#		T1 ranges 1~19(minutes), heartbeat packet upload when ACC ON; default is : T2 ranges 1~19 (min

Contact US



				heartbeat packet upload when ACC OFF; default is
		HBT#		Check the current param T1 and T2.
13	Set GPS data sending interval	TIMER,[T1],[T2]#		T1 ranges 5~18000 or 0(s upload interval when ACC means no upload, default T2 ranges 5~18000 (seco upload interval when ACC default is 10;
		TIMER#		Check the current param T1 and T2.
14	Set distance interval of GPS data sending	DISTANCE,[D]#		D ranges 50~10000 or 0(m distance interval, default
		DISTANCE#		Check the current distan interval.
15	Set the angle upload	ANGLEREP,[X],[A],[B]#		X=ON/OFF, default: ON A=5 ~ 180 degrees, diver angle degree, default: 3 degrees; B=2 ~ 5 seconds, de default: 3 seconds,

Contact US



		ANGLEREP,OFF#		Close the angle upload.
		ANGLEREP#		Check the angle upload s and its parameters.
16	Set the upload for ACC status change	ACCREP,[A]#		A=ON/OFF, upload for ACC change, default: ON
		ACCREP#		Check the upload for ACC change.
17	Set the GPS data sending batch	BATCH,[A][N]#		A= A=ON/OFF, data sendi batch function on or off, default:OFF N=1 ~ 50, N means the nu messages in the batch, do 10;
		BATCH#		Check the number of me in a batch.
18	Set the delay of the defense	DEFENSE,[A]#		A= 1 ~ 60 (minute), delay defense, default: 10 (min)
		DEFENSE#		Check the parameters of defense.
19	Set vibration sensor detecting	SENSOR, [,B][C]#		A=10-300 seconds, time. Default: 10 seconds

Contact US



	time			B=10-300 seconds, alert c Deault:180 seconds C=1-3000 minutes, vibrat alert interval. Default: 30 minutes SENSOR# Check the para of the status
20	Set the GPS time controlled by sensor	SENDS,[A]#		A=0-300(minute), time du
		SENDS#		for GPS to work once vib detected, 0 means GPS al on work, default: 5(minut
21	disarm	DSRESET#		DSRESET# Cancel the cu
22	Clear the backup data	CLEAR#		Arm status
23	Set the static data filtering	SF,[A],[B]#		A=ON/OFF; static drift f switch; default: ON B=10-1000(m); maximal filtering distance; 100(m);

Contact US



		SF#		Check the parameters.
24	Set the petrol/electricity control	RELAY,[A]#		A=0/1; 0 means connect means cut off; default:
		RELAY#		Check the status of the c
25	Set delay time of voice monitor	DELAY, #		A=0、 5-18 seconds; Defa seconds (Enter Listen-In senconds calling)
26	Set the fence alarm	FENCE,[B],0,[D],[E],[F],[X],[M]#		circle area; B=ON/OFF, open or close alarm, default: close; D=the latitude of the circ center; E=the longitude of the ci center; F=1 ~ 9999, the fence rad unit: 100 meters; X = in/out ; in: Alarming get in the fence, out: alar where get out the fence, Means Both Alarming Wh in or Get Out the Fc Blank.

Contact US

