

Starting Up the System

IS TOUCH PANEL OFF?:


Tap touch panel with flat of finger to wake up.

DO YOU NEED TO LOG IN?

Tap UW Husky Card ID onto Red Dot on Podium to LOGIN.

ALL DONE?

Don't forget to Log Off the system by pressing:



Setting up Desktop PC

WHERE IS IT LOCATED?:

- Inside the podium.
- Look for the Dell Logo.

IS IT ON?:


- Circular Power button on left side.
- Clear strip illuminated if ON.
- If OFF press circular button to turn ON.

SEND TO SCREEN?: On Touch Panel

- Press [Desktop] on Left
- Press [Send to Projector] in Center
- i lcons will turn blue when selected.

Example:

Desktop
















Setting up Laptop HDMI

WHERE TO START?:

- Look for a type connection on laptop.
- Locate the HDMI cable in room.
- Connect cable to port on laptop.
- Audio goes through HDMI from laptop.

HAVE A HDMI ADAPTER?:

- Connect adapter to HDMI cable first.
- Next connect both to laptop.



SEND TO SCREEN?: On Touch Panel

- Press [Laptop HDMI] on Left
- Press [Send to Projector] in Center



i lcons will turn blue when selected.

Example:

Laptop - HDMI



Setting up Laptop VGA

WHERE TO START?:

- Look for a type connection on laptop.
- Locate the VGA cable in room.
- Connect cable to port on laptop.
- Audio: Connect audio jack to port on Laptop.

HAVE A VGA ADAPTER?:

- Connect adapter to VGA ocable first.
- Next connect both to laptop.

SEND TO SCREEN?: On Touch Panel

- Press [Laptop VGA] on Left
- Press [Send to Projector] in Center




i lcons will turn blue when selected.

Example:

Laptop - VGA
















Blu-Ray Controls on Touch Panel



Setting up Blu-Ray

WHERE TO START?

SEND TO SCREEN?: On Touch Panel

- Press [Blu-Ray] on Left
- Press [Send to Projector] in Center
- i lcons will turn blue when selected.

Example:

Blu-Ray


WHAT IS NEXT?:

- Locate Blu-ray Player inside cabinet/podium.
- On touch panel press **Eject** to open disc tray.
- Place disc on disc tray.
- On touch panel press Play icon to close disc tray.
- Use touch panel icons to navigate disc menus and options.












Setting up Doc. Camera

WHERE TO START?

SEND TO SCREEN?: On Touch Panel

- Press [Doc Cam] on Left
- Press [Send to Projector] in Center



Example:

Doc Cam

CEILING DOCUMENT CAMERA

Zoom and Focus controls on Touch Panel

PORTABLE DOCUMENT CAMERA

- Is it ON? Green (On/Ready) | Red (Standby)
- If OFF press Silver Power button on right side.
- Takes 45 to 60 seconds to start up.
- Zoom, Lamp, and Focus controls on camera.
- Camera on adjustable arm.

Controlling Room Audio

WHERE TO START?

(i) Ro

Room Audio may contain any of the three following options at the right side of the touch panel.

Program Volume: For Desktop Computer, Laptop VGA, Laptop HDMI, and Blu-Ray.

Wireless Mic: For Wireless Microphone Lavalier or Handheld in room.

- Wireless microphones also have their own power switch on device.



Podium Mic: For the Podium-top Installed Microphone.

ADJUSTING VOLUME?:

• Tap on the speaker icons to adjust volume levels and mute/unmute audio.



Classroom Amenities

WHERE TO START?


Room Controls on Touch Panel

If available there will be a icon on touch panel.

Room Controls

Selecting it will bring up a page with amenities that can be digitally controlled.

Examples:





No Room Controls on Touch Panel?

Room Amenities (eg. Lights, Screen Controls) are located on the wall.

Contact Academic Technologies

Equipment Problem in classroom?

• Call us at 206.221.5000 extension 9; for immediate assistance.

Questions? Equipment Tutorial? Troubleshooting Session?

- Email us at help@uw.edu
- Call us at 206.221.5000 extension 2

Want to learn more about this classroom and AT?

- Visit our classroom page at https://www.washington.edu/classroom/
- Visit our home page at https://www.cte.uw.edu/academictechnologies/

Want this classroom for your course or to change rooms?

Contact Room Assignments at times@uw.edu

