

S — Set (session)		
Short	Phrase	Description
SS	Set Speed	Cruise speed mm/s ($\leq$ max_speed_1); bare reloads init_speed; live on next fill (incl. MJ). Dual MT: axis1=session, axis2 $\times$ ratio.
SA	Set Accel	Peak accel mm/s ² ($\leq$ max_accel_1); bare reloads init_accel; live on next fill (incl. MJ). Dual MT: same ratio scaling as SS.
SE	Set Enable	Driver enable 0 1; bare toggles; required before motion; off = hard stop.
ST	Set Terminal	Terminal Mode 0 1; bare toggles; local echo + UART sniff to USB (expert).
SV	Set Verbose	Verbose #... push 0 1; bare toggles; ~3 Hz (rate via verbose_rate_hz).
SD	Set Debug	USB-only debug level 0..5; bare restores default; never on UIC UART.
SL	Set Left	Session soft min (working window); bare→slider_min_N; none clears (→envelope if set); skip _; !E:limit past envelope.
SR	Set Right	Session soft max; bare→slider_max_N; none clears; skip _; !E:limit if left>right.
SP	Set Position	Set reported pose (no motion); idle only; bare/0 = here is zero; skip _.

G — Get (session)		
Short	Phrase	Description
GS	Get Speed	Current session cruise speed.
GA	Get Accel	Current session acceleration.
GE	Get Enable	Driver enable state.
GT	Get Terminal	Terminal Mode state.
GV	Get Verbose	Verbose push state.
GD	Get Debug	USB debug level.
GL	Get Left	Session soft min; effective (session else envelope); - if both None; extra fields when axis $\geq$ 2.
GR	Get Right	Session soft max; same effective / - rules as GL.

I — Is / status		
Short	Phrase	Description
IM	Is Moving	Moving or settling on any active axis.
IH	Is Homing	Homing cycle active.
IL	Is Limit	At soft-limit position (axis1).
IE	Is Error	PIN_DRV_ERROR / EMO latched.
IP	Is Position	One field per live axis (CG axis).
IA	Is Axis	Live axis count (CS axis / CG axis).
IT	Is Target	Axis-1 seek target, or - if none / soft-stop.
IR	Is Ready	1 only if idle, not homing, enabled, and not waiting.
IW	Is Waiting	1 if any WT / WM / WH / WP / WC / WN wait is active.
ID	Is Diag	Motion diag counters (FIFO underrun, peak STEP Hz, ...).
IC	Is Cause	Last chip reset: power wdt run soft debug brownout ...
IG	Is GPIO	ASCII GP / name / desc ($\leq$ 80 cols). Extra-axis rows only if that axis is live.

M — Movement		
Short	Phrase	Description
MT	Move To	Absolute user units; extra live axes; skip _; needs SE; live-retarget. Dual: time-sync ratio. Out-of-window = !E:soft (no clip).
MB	Move By	Relative move; same extra-axis/skip/named rules as MT.
MJ	Move Joy	Joy speed % of SS, signed (– left / + right); omit named extra=0; 0=soft-stop; SS/SA live; clamp max_speed_N. Hold-to-jog: MJ $\pm$ 100, MS on release.
MH	Move Home	Homing; axis 1 (default), 2, or 3; no-op if home_mode_N=0; cancel MS/HT.
MS	Move Stop	Soft decelerate both axes; keeps enable; ends joy-mode; does not cancel waits. Dual: scaled accel kept.

P — Path		
Short	Phrase	Description
PC	Path Clear	Clear path buffer (count→0); !E:busy while PG active.
PD	Path Data	Append signed μ m sample(s); extra live axes; skip _ →0; OK while PG (live stream).
PG	Path Go	Play buffer from sample 0; needs SE; !E:empty busy disabled. MS/HT ends path.
PN	Path Number	Samples in buffer; allowed during PG.
PS	Path Slice	Slice length μ s ($\geq$ 1000); bare→init_path_slice_us; !E:busy while PG.

E — Extender / beep		
Short	Phrase	Description
EO	Ext Out	Ext out n logical 0 1; bare EO0 toggles; glued EO01≡EO0 1; OK during EMO. EO4+ rejected.
BE	Beep	Pulse PIN_BUZZER ~0.1 s; not a wait. No-op if BUZZER_use=0. OK during EMO/path.

C — Config		
Short	Phrase	Description
CS	Config Set	Persist key to mc.ini; silent ok. axis / WDT_use need RB to take HW effect.
CR	Config Reset	Reset all config to compiled defaults and save mc.ini.
CG	Config Get	One key, or bare dumps all keys (multi-line).
RB	Reboot	Soft MCU reset (no power cycle); EN off first. After CS axis.

W — Wait		
Short	Phrase	Description
WT	Wait Time	Delay then continue ; chain; bare→1 s; never !E:timeout.
WM	Wait Moving	Pause chain until move ends; optional timeout → !E:timeout, cancel rest of chain.
WH	Wait Homing	Pause until homing ends; timeout same as WM.
WP	Wait Pos	Wait until axis-1 pos reached/overstepped; idle→immediate; 2nd arg=timeout.
WC	Wait Cruise	Wait until cruise (status M) or idle; optional timeout → !E:timeout.
WN	Wait Not cruise	Wait until not cruise M; idle/A/B→immediate; timeout same as WM.

V — Version		
Short	Phrase	Description
VA	Version About	About string (name, version, author).
VF	Version FW	Firmware version.
VP	Version Protoc...	Protocol version (2).

Special		
Short	Phrase	Description
HT	Halt	Immediate STEP abort; enable off; cancel waits and remaining ; chain.
VG	Version GPIO	Machine-readable pin map. Extra-axis pins if that axis is live.
HL/\$	Help	Two-column table of all commands (short + phrase).
?/#	Status now	Realtime compact status line (no newline).
!/ESC	Soft stop now	Realtime soft stop (same urgency as MS).

Wire: one command per line (`\n`); chain with `;`; axis args positional or named `X/Y/Z` (glued `MTX20Y50Z100` ok); `#` is realtime status, not a comment; bare bool setters toggle; motion/settings silent on success; errors `!E:code message`.

Realtime (no newline): `?/#` status · `!/ESC` soft stop · `Ctrl-X` (0x18) soft reset.

Status (`#X ...`): `I` idle · `A` accel · `M` cruise · `B` decel · `H` homing · `P` path · `L` hard-limit · `D` disabled · `E` error. Moving: `#M/#A/#B` pos speed accel [`target`].

Halt vs Stop: `MS/!/ESC` soft decel (enable kept, ends joy-mode); `HT` immediate abort, enable off, cancel waits. `MJ`: skip if value unchanged. Hold-to-jog: `MJ ±100`, `MS` on release.