Robot operating mode

Understand the different operating modes of the Ned2

Ned2 Robot comes with 3 diffrent operating modes.

Current mode can be determined visually via the color of the Led Ring on the robot's base.

The different modes are listed in the table below:

Operating Mode	Description
Manual mode - Robot calibration	The robot calibrate by automatically defining the Zero positions of each axis.
Collaborative mode - Programming	Available for programming, editing, loading and execution of the programs
Learning mode - FreeMotion	Realease the motors and the axes of the robot can be moved by hand.

Robot calibration

⚠Make sure the robot is properly installed on a firm surface with enough clearance to avoid shocks and collisions.

The calibration phase is fully automatic and must be completed in order to control the robot. This matches up the position of each motor with its controller.



Robot calibrating

Learning mode - FreeMotion

This mode is used to move the axes of the robot by hand in order to place it to the desired position. This mode is activated either by pressing and holding the FreeMotion button located on the control panel or by activating learning mode from programs.



⚠ **Be careful not to put your fingers and hands in the joints or openings of the robot during FreeMotion mode.**

Collaborative mode - Programming

This mode can be used to program, edit, load and run the robot's programs. The robot automatically switches to this mode once it has been calibrated.

Made with Docsie.io