Electrical interface

Electrical interface of the Conveyor Belt

Conveyor Belt electrical interface

1	Interface: Robot control connector
2	Interface: External control box connector

Control box electrical interface

Connector table

1	**Conveyor Belt (v2) control connector**	To connect the conveyor to the control box.
2	**Sensor connector**	To connect the Infrared sensor to the control box.
3	**Rotary potentiometer**	To control the speed and direction of the Conveyor Belt (v2).
4	**Emergency stop**	To stop the conveyor and cut power supply.
5	**Genral power input**	To supply voltage to the connveyor and the control box.

Infrared sensor(IR)

This infrared device can detect an object at a given distance. This distance can be adjusted between 6 and 80 cm.

The IR sensor is connected on the PIN DI5.

- **When the distance of the sensor < adjusted distance: an obstacle/object is detected.**
  The LED lights up,
  The output of the PIN DI5 is set to **0**.

- **When the distance of the sensor > adjusted distance: no obstacle/object is detected.**
  The LED lights off,
  The output of the PIN DI5 is set to **1**.

Made with Docsie.io