BeagleBone w/ MuntsOS Expansion Header Pinouts

	Р9				P8							
	DGND	1	2	DGND				DGND	1	2	DGND	
	VDD 3.3	3	4	VDD 3.3		MMC1	DAT6	GPIO38	3	4	GPIO39	MMC1 DAT7
	VDD 5V	5	6	VDD 5V		MMC1	DAT2	GPIO34	5	6	GPIO35	MMC1 DAT3
	SYS 5V	7	8	SYS 5V				GPIO66	7	8	GPIO67	
	PWR_BUT	9	10	SYS_RESETN				GPIO69	9	10	GPIO68	
UART4 RXD	GPIO30	11	12	GPIO60				GPIO45	11	12	GPIO44	
UART4 TXD	GPIO31	13	14	GPIO50	EHRPWM1A	<mark>EHRPW</mark>	VM2B	GPIO23	13	14	GPIO26	
	GPIO48	15	16	GPIO51	EHRPWM1B			GPIO47	15	16	GPIO46	
	GPIO5	17	18	GPIO4				GPIO27	17	18	GPIO65	
I2C2 SCL	GPIO13	19	20	GPIO12	I2C2 SDA	<mark>EHRPV</mark>	VM2A	GPIO22	19	20	GPIO63	MMC1 CMD
UART2 TXD	GPIO3	21	22	GPIO2	UART2 RXD	MMC1	. CLK	GPIO62	21	22	GPIO37	MMC1 DAT5
	GPIO49	23	24	GPIO15	UART1 TXD	MMC1	DAT4	GPIO36	23	24	GPIO33	MMC1 DAT1
	GPIO117	25	26	GPIO14	UART1 RXD	MMC1	DAT0	GPIO32	25	26	GPIO61	
	GPIO115	27	28	GPIO113	SPI1 SS0			GPIO86	27	28	GPIO88	
SPI1 MISO	GPIO111	29	30	GPIO112	SPI1 MOSI			GPIO87	29	30	GPIO89	
SPI1 SCLK	GPIO110	31	32	VDD_ADC				GPIO10	31	32	GPIO11	
	AIN4	33	34	GND_ADC				GPIO9	33	34	GPIO81	
	AIN6	35	36	AIN5				GPIO8	35	36	GPIO80	
	AIN2	37	38	AIN3		UART5	TXD	GPIO78	37	38	GPIO79	UART5 RXD
	AIN0	39	40	AIN1				GPIO76	39	40	GPIO77	
	GPIO20	41	42		SPI1 SS1			GPIO74	41	42	GPIO75	
	DGND	43	44	DGND				GPIO72	43	44	GPIO73	
	DGND	45	46	DGND				GPIO70	45	46	GPIO71	

^{1.} The MMC pins are available for GPIO only on the BeagleBone White, and only if the **BB-NOEMMC** device tree overlay is Applied.

Notes: