

WiFi Router Quick Start Guide

1. Package Contents

Your router package includes: one dual-band wireless router, one power adapter (12V, 1.5A), one Ethernet cable, and this quick start guide. Verify all items are present before proceeding with setup.

2. Initial Setup

Connect the power adapter to the router and to a wall outlet. Wait approximately 60 seconds for the power LED to turn solid green, indicating the router has finished booting. Connect one end of the included Ethernet cable to the WAN port on the router, and the other end to your modem.

Using a computer or mobile device, connect to the default wireless network printed on the label on the bottom of the router. Open a web browser and navigate to 192.168.1.1 to access the setup wizard.

3. Configuring Wireless Settings

In the setup wizard, you will be prompted to create a new network name (SSID) and password. We recommend using WPA3 encryption if your devices support it, or WPA2 as a fallback. Avoid using WEP encryption, as it is no longer considered secure.

The router supports simultaneous dual-band operation on both the 2.4GHz and 5GHz frequencies. The 2.4GHz band offers longer range but lower maximum speeds; the 5GHz band offers higher speeds but shorter range and is more susceptible to interference from walls.

4. Troubleshooting

If the power LED is blinking amber, the router is experiencing a firmware issue and may need to be reset. Press and hold the reset button on the back panel for 10 seconds to restore factory default settings. Note that this will erase any custom configuration.

If devices cannot connect to the internet despite a strong WiFi signal, verify the WAN cable is securely connected to the modem, and confirm the modem itself has an active internet connection by checking its own status lights.