DISHWASHER GUIDE

How to Use the Dishwasher

KitchenAid dishwasher, stainless steel tub (model to confirm)

IMPORTANT: Use only dishwasher detergent and keep it away from children. Load sharp knives with the handles up. Do not sit or stand on the door or racks, do not push down on the open door, and do not let children play in or on the dishwasher. Do not touch the heating element during or right after a cycle.

1 Load

- Load **sharp knives with the handles up**.
- Place sharp items so they cannot touch or damage the door seal.
- Plastic: only items marked **dishwasher safe**.
- Do not sit, stand or lean on the open door or the racks.

2 Detergent and rinse aid

- Use only dishwasher detergent. **Premeasured tablets or packs** are recommended.
- **Rinse aid is needed** for dry dishes and to limit hard-water spots. Keep it filled.
- The detergent cup and rinse aid cap are on the inside of the door (location to confirm with property management).

3 Start

- Choose a cycle on the control panel, for example **Normal**. Not sure which one? Ask property management.
- Press **Start/Resume**, then **close the door within 4 seconds**.
- **Start/Resume light flashing**: the door was not closed in time. Press Start/Resume again and close the door.
- Adding a dish during a cycle: add it, press Start/Resume and close the door within 4 seconds.

4 What to expect

- A load usually takes **2 to 5 hours**. This is normal: it saves energy.
- The first cycle may run longer. Some options can make a cycle longer than 3.5 hours.
- Hot water not used for **2 weeks or more**? Before using the dishwasher, run every hot tap for a few minutes. No smoking or open flame while you do this (hydrogen gas risk).

STOP AND CONTACT PROPERTY MANAGEMENT: Water leaks or pools under the dishwasher. An error code shows or the lights blink in a pattern (see Troubleshooting). A burning smell or smoke. If you are unsure, or if the problem continues, stop using the appliance and contact property management.

Based on the manufacturer's Owner's Manual W11589935 for this KitchenAid dishwasher. Pictures are taken from that manual. Updated 25 October 2026.