WASHER GUIDE

Washer Troubleshooting

LG front-load washer WM5500H*A or WM6500H*A (model to confirm)

IMPORTANT: Water leaking, or the message **Water too high**: stop using the washer, turn off its water taps if you know where they are, and contact property management right away. Opening the drain filter lets water out: only do it with towels and a shallow pan ready.


1 Won't start

- Press **Power**, choose a cycle, close the door fully, then press **Start/ Pause**. If you wait too long after choosing, the washer turns off.
- Buttons beep but nothing happens? **Control Lock** is on. Press **Options**, turn the knob to Control Lock, press ✔, choose Off, press ✔.
- **Door open** or **Door unlocked**: open and close the door. Check nothing is caught in the seal.
- Display stays dark: the breaker may be off. A washer left in the cold must warm up first.
- **Power failure**: press **Start/Pause** to restart.

2 Messages

- **Water supply**: the water taps may not be fully open, or a hose is kinked. Contact property management.
- **Unbalance**: load too small or tangled. Pause, spread the clothes out, or add a few similar items.
- **Oversudsing**: too much detergent. The washer removes suds for about 2 hours. Use less HE detergent next time.
- **Motor error**: wait 30 minutes and restart.
- **Drainage**: see the next box.
- **Freeze error**: contact property management.

3 Won't drain (Drainage)



Open the drain filter cover at the bottom front. Manual, page 43.

- Turn off and unplug the washer. Put towels and a shallow pan on the floor.
- Open the drain filter cover. Unclip the small drain hose, pull out its plug and let the water run into the pan.



Drain the water. Manual, page 43.

- Twist the filter counterclockwise to take it out. Remove lint, coins and other objects.



Twist to remove the filter. Manual, page 43.

- Put the plug back in the hose and clip it. Twist the filter clockwise until tight. Close the cover.
- Still won't drain, or water keeps coming out: contact property management.

4 Noises, smells, time

- Clicking, hissing, humming, sloshing: normal.
- Rattling: coins or keys. Check the drum and the drain filter.
- Thumping or shaking: pause and spread the load out.
- Stops for a few minutes, then restarts: motor protection, normal. Time left is only an estimate.
- Musty smell: run **Tub Clean**, clean the door seal and drain filter, leave the door open, use less HE detergent.
- Detergent left in the drawer: close it fully before starting, and do not overfill.

STOP AND CONTACT PROPERTY MANAGEMENT: Water leaks. **Water too high**, **No water detected**, **Vibration sensor**, **Steam error**, **No temp detected** or **Voltage abnormality**. **Motor error** after waiting 30 minutes. A message comes back after a restart. A burning smell or smoke. If you are unsure, or if the problem continues, stop using the appliance and contact property management.

Based on the manufacturer's Owner's Manual MFL71964314 for LG washers WM5500H*A and WM6500H*A. Pictures are taken from that manual. Updated 29 October 2026.