DRYER GUIDE

Dryer Troubleshooting

LG dryer, DL*X550, DL*X650 or DL*X670 series (model to confirm)

IMPORTANT: Duct blockage (80%, 90% or 95%): stop using the dryer. The manual warns that running it with a blocked vent is dangerous and could cause a fire. Contact property management.

1 Won't start

- Press **Power**, choose a cycle, close the door, press **Start/Pause**. If you wait too long after choosing, the dryer turns off.
- Buttons beep but nothing happens? **Control Lock** is on. Press **Options**, turn the knob to Control Lock, press ✔, choose Off, press ✔.
- Nothing lights up: the breaker may be off. Contact property management.
- Starts by itself every few minutes after the cycle: that is **Wrinkle Care**. Normal.

2 Slow drying or damp clothes

- Clean the lint filter before every load. Wash it if it looks clogged (see Appliance Care).
- Do not overload. Very small load: add a few items.
- Dry heavy items apart from light ones. Unroll a bulky comforter halfway through.
- No heat at the start of Normal: **Energy Saver** is on. Normal; you can turn it off.
- **Flow Sense** shows 4 bars: the vent is partly blocked. Contact property management.

3 Messages

- **Duct blockage**: see the IMPORTANT box.
- **Temp sensor error**: turn the dryer off and contact property management.
- **Power supply**, **Power issue**, **High voltage** or **Low voltage**: contact property management.

4 Clothes and normal things

- Wrinkles: unload right away, use a shorter time or lower Dry Level, or use **Wrinkle Care**.
- Static: shorter drying, fabric softener, or **Low Static**.
- Lint on clothes: clean the filter, dry towels apart from dark clothes. Check pockets for tissues.
- Shrinking: follow care labels, use a low heat setting.
- Steam: water drips, no visible steam, or a drum that stops: normal.
- New dryer smell: normal, goes away after a few cycles.

STOP AND CONTACT PROPERTY MANAGEMENT: Duct blockage, **Temp sensor error**, or a **Power supply**, **Power issue** or **voltage** message. A burning smell or smoke. No heat after checking the boxes below. Steam does not work. If you are unsure, or if the problem continues, stop using the appliance and contact property management.

Based on the manufacturer's Owner's Manual MFL71996102 for LG dryers DL*X550, DL*X650 and DL*X670. Pictures are taken from that manual. Updated 29 October 2026.