WASHER GUIDE

Washer Care


LG front-load washer WM5500H*A or WM6500H*A (model to confirm)

IMPORTANT: Wear rubber gloves and goggles when cleaning with bleach, and always dilute it. Never mix chlorine bleach with ammonia or vinegar. Do not spray water on or into the washer. No steel wool, abrasive cleaners, alcohol or solvents.

1 After every load

- Take the laundry out as soon as the cycle ends.
- Wipe the door, the door glass and the inside of the rubber seal dry.
- Leave the door open, overnight if you can, so the drum dries. This prevents smells. Keep children and pets out.
- Wipe spills on the outside straight away with a damp cloth.


2 Monthly drum clean



1 Power, 2 cycle knob, 3 Back and ✓ (OK), 4 display, 5 Start/Pause, 6 Temp., Spin, Soil, 7 options. Manual, page 23.

- Empty drum. Add a washer drum cleaner to the main detergent compartment, or liquid chlorine bleach to the bleach compartment (not past MAX). Cleaning tablets go in the drum.
- Press **Power**, turn the knob to **Tub Clean**, press **Start/Pause**.
- No Tub Clean on the knob? Press **Options**, choose **Cycle List Edit**, turn to Tub Clean and press ✓ to add it.
- Afterwards leave the door open to dry. If you used a cleaner or descaler, run **Rinse+Spin** (add it the same way) before the next wash.
- Smell already there? Run Tub Clean once a week for 3 weeks.

3 Dispenser drawer (once or twice a month)



Press the release button (1) to take the drawer out. Manual, page 41.

- Turn off and unplug the washer. Pull the drawer out until it stops.
- Press down hard on the release button (1) and pull the drawer all the way out. Take out the inserts.
- Clean them with warm water and a soft cloth or brush. No soap. Dry them.
- Brush out the drawer opening with a small non-metal brush, then slide the drawer back in.

4 Door seal (monthly)

- Wear rubber gloves and goggles. Mix 3/4 cup (177 mL) of liquid chlorine bleach in 1 gallon (3.8 L) of water. Never use bleach undiluted.
- Wipe all around the seal with a sponge or soft cloth, then dry it with a towel.
- Leave the door open until the seal is completely dry.
- Hard water spots on the drum: a soft cloth with stainless steel cleaner. Then run Tub Clean.

STOP AND CONTACT PROPERTY MANAGEMENT: A water hose behind the washer is leaking, kinked or cracked. A bad smell stays after three weekly Tub Clean cycles. The washer shows **Water supply** with the taps open (the water inlet filters behind it may need cleaning). The room could freeze. If you are unsure, or if the problem continues, stop using the appliance and contact property management.

Based on the manufacturer's Owner's Manual MFL71964314 for LG washers WM5500H*A and WM6500H*A. Pictures are taken from that manual. Updated 29 October 2026.