crawlspacebot controls

Left trigger:
hold for Drive mode
otherwise it is tank mode

Right trigger:
hold for fast speed
otherwise it is normal speed

Left bumper:
decrease headlight power

restart threads and video
(press this if not responding to try
and regain control)

Right bumper:
increase headlight power

reset camera angle to forward

emergency pusher
servo forward

camera angle

laser

emergency pusher
servo backward
(hold 3 sec to reset for
normal operation)

L3: press for headlight OFF

turn off signals to servos
(automatically turns back on when
servo position changed)

R3: press for headlight ON

tank mode: left tread
drive mode: power

tank mode: right tread
drive mode: direction