



Hints and Tips

Problem	Solution
No power.	• Ensure the adapter is connected securely at both ends. • Make sure that the on mode is selected.
The remote control is not functioning.	• Use the remote control near the unit. • Point the remote control at the remote sensor on the unit. • Replace the battery in the remote control with a new one. • Remove any obstacles between the remote control and the unit.
Loud hum or noise is heard.	• The plugs and sockets are dirty. Wipe them with a cloth slightly moistened with an appropriate non-abrasive cleaning solution.
Cannot connect to Wi-Fi.	• Make sure that the wireless network is not disturbed by microwave ovens, DECT phones, or other neighboring Wi-Fi devices. • Make sure that your speaker and your device share the same network. • Make sure that your router/modem is on and that you are within range of it.
I cannot find "Onn 32" Soundbar" on my Bluetooth® device.	• Ensure the Bluetooth® function is activated on your Bluetooth® device. • Ensure you have paired your unit with the Bluetooth® device.

Specifications

Model: ONN 32" 2.1 SOUNDBAR		
Soundbar	AC Power Adapter	Input AC 100-240V ~50/60Hz, 1.2A Output DC 18V, 2.0A
	Peak Power	120W
	Power Consumption	30W
	Speaker Output Power	2 x 15 W(RMS)
	Net Weight	1.6 Kg
	Dimension	812mm(W) x 68mm(D) x 82mm(H)
Subwoofer	Power Cord	internal power supply input 100-240V AC 50/60Hz US standard
	Peak Power	160W
	Power Consumption	40W
	Speaker Output Power	40W(RMS)
	Net Weight	2.7kg
	Dimension	123mm(W) x 266mm(D) x 230mm(H)

We'd love to hear from you. Scan with your Walmart app and let us know what you think.

onn.™

ONN 32" 2.1 SOUNDBAR Quick Start Guide

100004118

6 81131 28433 2